



VANTAGEO Server

BMC User Guide (BMC V4)

Version: R1.3

VANTAGEO PRIVATE LIMITED
Corporate Address: 617, Lodha Supremus II,
Road No. 22, Wagle Estate,
Thane - 400604
URL: <https://vantageo.com>
E-mail: support@vantageo.com
Helpdesk - +91 18002669898

LEGAL INFORMATION

Copyright 2024 VANTAGEO PRIVATE LIMITED.

The contents of this document are protected by copyright laws and international treaties. Any reproduction or distribution of this document or any portion of this document, in any form by any means, without the prior written consent of VANTAGEO PRIVATE LIMITED is prohibited. Additionally, the contents of this document are protected by contractual confidentiality obligations.

All company, brand and product names are trade or service marks, or registered trade or service marks, of VANTAGEO PRIVATE LIMITED or of their respective owners.

This document is provided as is, and all express, implied, or statutory warranties, representations or conditions are disclaimed, including without limitation any implied warranty of merchantability, fitness for a particular purpose, title or non-infringement. VANTAGEO PRIVATE LIMITED and its licensors shall not be liable for damages resulting from the use of or reliance on the information contained herein.

VANTAGEO PRIVATE LIMITED or its licensors may have current or pending intellectual property rights or applications covering the subject matter of this document. Except as expressly provided in any written license between VANTAGEO PRIVATE LIMITED and its licensee, the user of this document shall not acquire any license to the subject matter herein.

VANTAGEO PRIVATE LIMITED reserves the right to upgrade or make technical change to this product without further notice.

Users may visit the VANTAGEO technical support website <https://www.vantageo.com/support> to inquire for related information.

The ultimate right to interpret this product resides in VANTAGEO PRIVATE LIMITED.

Statement on the Use of Third-Party Embedded Software:

If third-party embedded software such as Oracle, Sybase/SAP, Veritas, Microsoft, VMware, and Redhat is delivered together with this product of VANTAGEO, the embedded software must be used as only a component of this product. If this product is discarded, the licenses for the embedded software must be void either and must not be transferred. VANTAGEO will provide technical support for the embedded software of this product.

Revision History

Revision No.	Revision Date	Revision Reason
R1.3	2024-11-07	Fully updated.
R1.2	2024-07-01	Fully updated.
R1.1	2024-04-24	Fully updated.
R1.0	2023-09-07	First edition.

Serial Number: VT20240301

Publishing Date: 2024-11-07 (R1.3)

Contents

1 BMC Overview.....	9
1.1 Operating Principle.....	9
1.2 Functions.....	11
1.3 Software Security.....	12
1.4 Operation Interfaces.....	15
2 Performing Client Commissioning	16
3 Logging in to the Web Portal of the BMC.....	21
4 Common Operations.....	19
4.1 Logging In to the BMC Through SSH.....	27
4.2 Logging In to the BMC Through a Serial Port.....	29
4.3 Modifying the BMC Address.....	33
4.4 Checking Server Information.....	34
4.5 Managing Storage Devices.....	36
4.6 Installing an OS Remotely.....	38
4.7 Resetting the BMC When the Web Portal Is Unavailable.....	44
4.8 Querying and Configuring Services.....	45
4.9 Configuring an NTP Server.....	47
4.10 Configuring an SMTP Server.....	49
4.11 Configuring Trap Notification Parameters.....	50
4.12 BMC Log Export.....	52
4.12.1 Exporting Logs in One Click Through the Web Portal.....	53
4.12.2 Logs by Category Through the Web Portal.....	54
4.12.3 Exporting Logs Through the CLI (SSH).....	55
4.12.3 Exporting Logs Through the CLI (Serial port).....	55
4.13 Upgrading the BMC Firmware.....	56
4.14 Restoring Factory Defaults.....	57
4.15 Backing Up BMC Configurations.....	58
4.16 Creating an SNMP User.....	59
5 System Management.....	63
5.1 Querying System Information.....	63
5.2 Querying Performance Data.....	64
5.3 Querying Fan Information.....	67
5.4 Configuring the Heat Dissipation Policy.....	67

5.5 Querying Temperature KPIs.....	69
5.6 Managing Storage Devices.....	70
5.7 Configuring the Position Indicator of a Pass-Through Disk.....	73
5.8 Powering On/Off the Server.....	74
5.9 Configuring the Server Startup Policy.....	77
5.10 Configuring Power-On Delay Parameters.....	78
5.11 Configuring the High-Temperature Power-Off Strategy.....	79
5.12 Querying Power Supply Information.....	81
5.13 Configuring the Power Mode.....	82
5.14 Querying Power Statistics.....	84
5.15 Configuring Power Control Parameters.....	85
5.16 Querying Power KPIs.....	86
5.17 Configuring Boot Options.....	87
5.18 Configuring the Serial Port output Mode.....	89
6 Diagnosis and Maintenance.....	91
6.1 Querying Alarms.....	91
6.2 Alarm Reporting Parameter Configuration.....	92
6.2.1 Configuring Trap Notification Parameters.....	93
6.2.2 Configuring Syslog Notification Parameters.....	95
6.2.3 Configuring Email Notification Parameters.....	97
6.3 Configuring Screen Recording Parameters.....	99
6.4 Viewing Recorded Videos.....	101
6.5 Taking a Screenshot.....	102
6.6 Viewing POST Codes.....	103
6.7 Downloading Server Logs.....	104
6.8 Querying BMC Logs.....	105
6.9 Querying SEL Logs.....	106
6.10 Querying Memory Health Scores.....	107
7 Service Management.....	108
7.1 Configuring Port Service Parameters.....	108
7.2 Configuring Web Service Parameters.....	110
7.3 Configuring KVM Service Parameters.....	112
7.4 Starting the KVM.....	114
7.5 Configuring Virtual Media Parameters.....	122
7.6 Mounting a Virtual Media Device.....	124
7.7 Configuring VNC Parameters.....	125
7.8 Configuring SNMP Parameters.....	127

8 BMC Management.....	130
8.1 Network Parameter Configuration.....	130
8.1.1 Configuring the Host Name.....	130
8.1.2 Configuring the Network Port Mode.....	131
8.1.3 Configuring IP Addresses of Network Ports.....	133
8.1.4 Configuring the DNS.....	135
8.1.5 Configuring an iSAC VLAN.....	137
8.1.6 Configuring an NCSI VLAN.....	138
8.1.7 Configuring USB over LAN.....	139
8.2 Setting the Time of the BMC.....	140
8.3 Resetting the BMC on the Web Portal of the BMC.....	144
8.4 Upgrading Firmware.....	145
8.5 Switching Modes.....	147
8.6 Updating BMC Configurations.....	148
8.7 Restoring Factory Defaults.....	150
9 User and Security.....	151
9.1 Adding a Local User.....	151
9.2 Configuring Authentication Parameters for Domain Users.....	154
9.3 Querying Online Users.....	158
9.4 Configuring Permissions for a Customized Role.....	159
9.5 Configuring Security Enhancement Parameters.....	160
9.6 Configuring Firewall Parameters.....	161
9.7 Configuring Two-Factor Authentication.....	163
10 Reference: Default Passwords.....	165
11 Reference: Accessing Documents.....	166
Glossary.....	169

About This Manual

Purpose

This manual describes the BMC management software of VANTAGEO servers to provide guidance on BMC configuration and management.

Intended Audience

This manual is intended for:

- Network planning engineers
- Configuration engineers
- Maintenance engineers

What Is in This Manual

This manual contains the following chapters.

Chapter 1, BMC Overview	Describes the operating principle and functions of the BMC, software security and operation interfaces.
Chapter 2, Performing Client Commissioning	Describes the debugging operations on the BMC Web portal logged in through a client.
Chapter 3, Logging In to the Web Portal of the BMC	Describes how to log in to the Web portal of the BMC.
Chapter 4, Common Operations	Describes common operations in the BMC.
Chapter 5, System Management	Describes how to perform system management operations.
Chapter 6, Diagnosis and Maintenance	Describes how to perform diagnosis and maintenance operations.
Chapter 7, Service Management	Describes how to perform service management operations.
Chapter 8, BMC Management	Describes how to perform BMC management operations.
Chapter 9, User and Security	Describes how to perform user and security management operations.
Chapter 10, Reference: Default Passwords	Describes the default passwords that are used to log in to the BMCs in VANTAGEO servers of different models.

Chapter 11, Reference: Accessing Documents	Describes the steps for accessing documents.
--	--

Conventions

This manual uses the following conventions.

	<p>Notice: indicates equipment or environment safety information. Failure to comply can result in equipment damage, data loss, equipment performance degradation, environmental contamination, or other unpredictable results.</p>
	<p>Note: provides additional information about a topic.</p>

Chapter 1

BMC Overview

Table of Contents

Operating Principle.....	9
Functions.....	11
Software Security.....	12
Operation Interfaces.....	15

The **BMC** is the management system of a VANTAGEO server, which monitors and manages server hardware, and provides a Web portal for operation and maintenance, achieving the purposes of software and hardware configuration, fault diagnosis, operating system installation, and operations on the server.


1.1 Operating Principle

The **BMC** consists of a dedicated management chip and the management software operating on the chip.

- Dedicated management chip

The server-dedicated management chip provides abundant hardware interfaces and functions. For the hardware interfaces of the BMC, see [Figure 1-1](#).

Figure 1-1 BMC Hardware Interfaces




For a description of the BMC channels, refer to [Table 1-1](#).

Table 1-1 BMC Hardware Channel Descriptions

Channel	Typical Physical Link	Typical Management Object or Function
Service peripheral supervision channel	PCIe and SMBUS	PCIe devices of a server
Host internal supervision channel	SMBUS and PECCI	Internal functional units of the CPU or bridge chip
Host interaction channel	PCIe, USB, LPC, KCS, and SMBUS	Supports KVM, virtual media function, and host serial port functions, and the IPMI protocol
Direct supervision channel for service peripherals	SMBUS and NC-SI	PCIe devices of a server
Sensor supervision channel	SMBUS, GPIO, and A/D	Temperature sensor, voltage sensor, current sensor, and presence sensor
Fan supervision channel	PWM	Fan
Power supervision channel	SMBUS	CRPS, and PMBUS power supply
Control channel	GPIO and SGPIO	Power-on, power-off, and indicator on/off
Remote management channel	Ethernet	Accesses the BMC management server

- Management software
The BMC management software communicates with hardware devices through the management channels to monitor and manage hardware. For the architecture of the BMC management software, see [Figure 1-2](#).

Figure 1-2 BMC Management Software Architecture

1.2 Functions

The **BMC** is the management system of a server. It provides abundant management functions.

- Server health status management: Checks the operational status of a server, analyzes historical data and actual monitoring data, and helps users to find and solve problems in advance, ensuring the highly reliable operation of the server.
 - The 80-code recording function provides sufficient information for analyzing startup failures.
 - When the system crashes, the last-screen capture function records the on-site scenario for analyzing system crashes.
 - Screen snapshots and screen recording on preventive maintenance and operation processes facilitate follow-up audits.
 - The alarm function supports precise fault diagnosis based on components, facilitating component fault locating and replacement.
 - The CrashDump function facilitates further analysis of system errors.
 - The BMC supports the syslog, **SNMP** trap, email and Redfish subscription functions to report alarms, so that the **NMS** can collect server fault information easily.
 - The BMC supports direct display of the server health status through the alarm indicator.
- Host system maintenance
 - Supports virtual **KVM** and virtual media functions for remote maintenance of the host system.

- Supports out-of-band monitoring and management of **RAIDs**, so that RAIDs can be monitored without depending on the host system, and the storage devices in the host system can be configured, which improves configuration efficiency and management capability.
- Supports **OS** installation through **PXE**, which improves the efficiency of remote installation of operating systems in batches.
- Device firmware management → Dual BMCs are supported to ensure the reliable operation. → Dual **BIOSs** are supported to improve the reliability of BIOS upgrade and operation.
 - The firmware (for example, the **FRU** and **EPLD**) upgrade function is supported.
- System cooling → Monitors the temperature of important components on the server, and performs different cooling controls based on different hardware thermal characteristics.
 - Supports the over-temperature power-off function to ensure that the server hardware is not damaged, extending the service life of components.
- Intelligent power consumption management → The BMC supports the power capping technology, and provides the standard **DCMI** for centralized control by the NMS, improving the deployment density of servers.
 - Energy-saving design reduces the operating costs of a server.
- BMC self-management
 - Supports synchronizing the BMC time through the network and the host, meeting the requirements in different scenarios.
 - Supports multiple authentication modes, which simplifies server management.
 - Supports **DHCP** and **DNS**, which simplifies server deployment and management.
- Diversified management interfaces

The BMC meets the requirements of various system integration interfaces by providing the following:

 - Standard **DCMI 1.5/IPMI 2.0/Redfish** interfaces → Remote command line interfaces and Web management interfaces → **SNMPv1, SNMPv2 and SNMPv3** interfaces

1.3 Software Security

Security Measures for Function Invocation

- Complete security design: Uses threat modeling for security design.
- Encrypted **KVM** access: Supports encrypted KVM access.
 - HTTPS** access with a high encryption security level: Provides an HTTPS trusted path between the server and users to protect local or remote users when they log in to the

system through the Web page and prevent communication data from being modified or leaked.

- **SSH** access with a high encryption security level: Provides an SSH trusted path between the server and users, and between servers and other devices to protect local or remote users when they log in to the system and prevent communication data from being modified or leaked.
- **SNMPv3** protocol with a high encryption security level: Supports the SNMPv3 communication security protocol, **SHA**, and **AES**.
- **IPMI 2.0** protocol with a high encryption security level: Supports the IPMI 2.0 communication protocol, and provides the encryption security technology with a higher level.
- Redfish interface with a high encryption security level: Supports the next-generation standard shelf management interface, with the encryption level higher than the IPMI protocol.
- Protocol and port anti-attack: Disables unused network services and high-risk ports as well as insecure protocols by default, including **RMCP**, Telnet.

Security Measures for User Permissions

- User role management: User permissions are allocated to logged-in users, and multiple management user roles can be allocated. Roles can be divided into different levels. By associating roles, the functional permissions of each user can be restricted to prevent unauthorized operations.
- User account security enhancement: Weak password detection, default strong password, password complexity configuration, password validity period configuration, and forbidding repeated use of the latest three historical passwords during password modification are supported.
- Authentication service: The **BMC** supports both local authentication access and remote authentication access. Remote access supports authentication through **LDAP**, and account locking upon login authentication failures. The number of login failures can be configured.
- User access restriction: User access can be restricted by port, source **IP** address, and **MAC** whitelist. The system supports the functions such as maximum number of sessions, forced exit after session timeout, configurable session expiration, multi-session concurrent restriction for a single user, online user management, and forced logout.
- Intrusion alarm: The BMC supports the chassis cover opening alarm to improve system security.
- Certificate service: The BMC supports certificate encryption and import services, which can only be operated by the administrator.

Security Measures for Log Management

- Log recording: All key system events can be recorded, including the date, time, user, event description, event result, and other related information. The BMC supports recording of component replacement logs.
- Log category: The BMC supports different log categories, including operation logs, maintenance logs, and login logs.
- Log query: The BMC provides log information query permissions for authorized users, and supports allocating log file read permissions by account to prevent log files from being accessed illegally.
- Log protection: Logs are saved in non-volatile storage media. Log information that has been stored cannot be deleted without authorization to prevent modifying the stored log information. Logs are saved for 90 days or longer.
- Centralized alarm management: The BMC supports centralized alarm management for the faults that occur during device operation, allows authorized users to export alarms, and supports alarm reporting through SNMP Trap in a centralized manner.
- Centralized log management: The BMC allows authorized users to export logs, and supports log through Syslog in a centralized manner.
- Reliable timestamp: The BMC supports local time modification and [NTP](#) to ensure the time accuracy of system logs and alarms.

Security Measures for Data Security

- Encrypted data storage: Supports data protection, encrypted data storage, and database password authentication.
- Encrypted data transmission: Supports communication protocols with high encryption security levels such as IPMI 2.0/SNMP V3/SSH/Redfish/HTTPS and the KVM encryption function to ensure data transmission security.
- Data integrity: Supports data integrity check to ensure data verification, storage and transmission.

Security Measures for Version Management

- Version integrity check: When the server system loads software, the BMC checks the integrity of the software to prevent version confusion or malicious modification caused by error codes during transmission.
- Software upgrade permission control: The BMC records software version and firmware version information. Only the administrator has the permission to upgrade software and firmware and record related operations in logs.

Version rollback: When an error occurs during the version upgrade process, the version can be rolled back.

- Venerability-free release of software: Before the product software is released, it passes the security scan by the security tools such as NSFOCUS, NESSUS, and WebInspect, and passes the source code scan for vulnerabilities. In addition, the product software passes several rounds of penetration tests to ensure no vulnerability.
- Redundancy: The BMC supports active/standby BMC boots, BMC versions and BMC management ports.
- Strict version release control process: The BMC supports security evaluation of the third-party software and plug-ins used. Before a version is released, the BMC scans it by using mainstream anti-virus software. SHA256 check codes are released to prevent version tempering.
- Secure and controllable BMC source code: The BMC source code passes the 100% code walkthrough and the Klocwork and Coverity white box security checks and tests, so that the potential security vulnerabilities are eliminated and the security is reinforced.

1.4 Operation Interfaces

The **BMC** supports common batch deployment operation interfaces and server management interfaces.

- The batch deployment operation interfaces include:
 - The **IPMI** is a standard server interface. It is used for interconnection with the upper-layer **NMS** or the monitoring software at the host side to implement the functions specified by the IPMI2.0.
 - The Redfish interface is a standard server interface. It is used for interconnection with the upper-layer NMS to monitor and manage a server.
 - The **SNMP** interface is a non-standard server interface. It is used for interconnection with the upper-layer NMS to monitor and manage a server.
- The server management interfaces include:
 - Web interface → **KVM** interface → Remote **CLI**

Chapter 2

Performing Client Commissioning

Abstract

In most cases, you can log in to the Web portal of the BMC on a client through the iSAC management network port of a server. Before logging in to the Web portal of the BMC for the first time, you need to commission the client to ensure that it is interconnected with the iSAC management network port.

Prerequisite

- All the needed tools are ready:
 - A PC (acting as the client)
 - Network cable
- One of the following browsers is already installed on the PC:
 - Google Chrome 59 or later versions
 - Firefox 54 or later versions
 - Microsoft IE 11 or later versions




Note

Google Chrome 59 and later versions are recommended.

Context

The default IP address of the iSAC management network port of a server is 192.168.5.7. [Figure 2-1](#) shows the position of the iSAC management network port on the rear panel of the server.

Figure 2-1 Position of the iSAC Management Network Port


1. iSAC management network port

Note

The network port with the **iSAC** silk screen on the rear panel of a server identifies the iSAC management network port. The locations of the iSAC management network interfaces on different servers are slightly different. This procedure uses an 2230-RE server as an example to describe the position of the iSAC management network port. For other servers, refer to the corresponding *Hardware Description*.


Steps

1. Connect the PC to the iSAC management network port on the rear panel of the server through a network cable.
2. On the PC, change the IP address of the PC to an IP address (for example, 192.168.5.8) in the same network segment as 192.168.5.7.
3. On the PC, launch the specified browser.
4. In the address bar of the browser, enter `https://192.168.5.7` and press **Enter**. The page for login is displayed, see [Figure 2-2](#).

Figure 2-2 Login Page

If the prompt information as shown in [Figure 2-3](#) is displayed before login, click **Advanced** and select **Proceed to** enter the login page.

Figure 2-3 Security Prompt



5. Enter your username and password.

 **Note**

The default username and password are as follows:

- Username: Administrator
- Password: Superuser9!


To unhide the password, you can click the  button on the right.

 **Note**

After you log in to the BMC Web portal by using the default password, you must change the default password immediately. It is recommended that you change the default password to a strong password.

6. Click **Log In**, The **Homepage** of the Web portal of the BMC is displayed, see [Figure 2-4](#).

Figure 2-4 Homepage



- Set the IP address of the iSAC management network port as planned, for example, 10.235.51.202.

Note

For how to set the IP address of the iSAC management network port, refer to [8.1.3 Configuring IP Addresses of Network Ports](#).

- Record the IP address of the iSAC management network port.
- Connect the iSAC management network port to the corresponding switch through a network cable.
- On the PC, change the IP address of the PC to an IP address (for example, 10.235.51.203) in the same network segment that the iSAC management network port belongs to.
- Connect the PC to the corresponding switch through a network cable, so that the PC and the iSAC management network port are in the same LAN.
- Run the `ping` command on the CLI of the PC to make sure that the PC can communicate with the iSAC management network port properly.

Chapter 3

Logging In to the Web Portal of the BMC

Abstract


This procedure describes how to log in to the Web portal of the **BMC** of a server through the specified browser on your **PC**. You can monitor and manage the server on the portal.

Prerequisite

The **IP** address of the **iSAC** management network port is already obtained.


Steps

1. In the address bar of the browser, enter the address of the Web portal of the BMC, and press **Enter**. The page for login is displayed, see [Figure 3-1](#).

Figure 3-1 Login Page**Note**

The address format of the Web portal of the BMC is as follows: `https://IP`. "IP" is the IP address of the iSAC management network port.

If the prompt information as shown in [Figure 3-2](#) is displayed before login, click **Advanced** and select **Proceed to** to enter the login page.

Figure 3-2 Security Prompt

- 2 Enter your username and password.

Note

The default username and password are as follows:

- Username: Administrator
- Password: Superuser9!


To unhide the password, you can click the  button on the right.

Note

After you log in to the BMC Web portal by using the default password, you must change the default password immediately. It is recommended that you change the default password to a strong password.

- 3 Click **Log In**, The **Homepage** of the Web portal of the BMC is displayed, see [Figure 3-3](#).

Figure 3-3 Homepage



For a description of the **Homepage**, refer to [Table 3-1](#).

Table 3-1 Homepage Descriptions

No.	Name	Description
1	Device Information	<p>Displays the detailed information and active alarm statistics of the server.</p> <ul style="list-style-type: none"> To modify the asset flag of the server, click . To view alarm details, click Details.
2	Menu bar	Displays all the function menus in the format of a navigation tree in the left pane after you click any main menu on the menu bar.
3	Alarm button	<p>Displays the total number of active alarms.</p> <ul style="list-style-type: none"> To view the number of alarms at each level, hover the mouse pointer over this button. To view alarm details, click this button.
4	UID button	<p>Displays the UID indicator status of the server.</p> <p>To change the status of the UID indicator, click this button and select the corresponding shortcut menu.</p> <p>The shortcut menus include:</p> <ul style="list-style-type: none"> Steady on: The UID indicator is lit, helping you to identify the current server among the servers in the equipment room.

No.	Name	Description
		<ul style="list-style-type: none"> ● Blink: The UID indicator flashes, indicating that the BMC is being operated. The UID indicator flashes automatically when the BMC, Web portal, KVM, or virtual media is being used. ● Off: The UID indicator is off. <p>The grayed shortcut menu indicates the current status of the UID indicator. For example, if the Blink shortcut menu is grayed, the UID indicator of the server is flashing.</p>
5	Power button	<p>Displays the power status of the server.</p> <p>To change the power status, click this button and select the corresponding shortcut menu.</p> <p>The shortcut menus include:</p> <ul style="list-style-type: none"> ● Power On: Power on the server. ● Normal Power Off: Power off the server. ● Forced Power Off: Forcibly power off the server. ● Power Reset: Perform a warm reboot. Warm reboot means that the server is restarted when it is not shut down. During the restart, the server is not offline. ● Power Cycle: Perform a cold reboot. Cold reboot means that the server is started after it is shut down. During the restart, the server is offline. <p>The grayed shortcut menu indicates the current power status of the server. For example, if the Power On shortcut menu is grayed, the server is in power-on status.</p>
6	Language button	<p>Displays the current language of the Web portal of the BMC.</p> <p>To change the language, click this button.</p>
7	Current user	<p>Displays the currently logged-in user.</p> <ul style="list-style-type: none"> ● To view the details of the currently logged-in user, including the IP address and login time, click this button. ● To log out the currently logged-in user, click this button and then click Log Out in the detailed information box displayed.
8	Shortcuts	<p>Displays the shortcut operation buttons on the Web portal of the BMC, including:</p> <ul style="list-style-type: none"> ● Firmware Upgrade: upgrades firmware. For details, refer to 8.4 Upgrading Firmware. ● Log: queries BMC logs. For details, refer to 6.8 Querying BMC Logs. ● Network: configures network parameters. For details, refer to 8.1 Network Parameter Configuration. ● Power: queries server power-on/off information, and power supply and power consumption information. For details, refer to 5.8 Powering On/Off the Server and 5.15 Configuring Power Control Parameters.

No.	Name	Description
		<ul style="list-style-type: none"> ● One-Click Collection: collects all configuration files, databases, and logs for fault location, packages them, and downloads them to the PC. It takes a long time to collect the required information, and no other operations can be performed during the collection period.
9	Device List	<p>Displays the components in the server by category.</p> <p>To view the details of components of a category, click the category.</p>
10	Virtual Console	<p>Displays the operations related to the virtual console, including:</p> <ul style="list-style-type: none"> ● To enable KVM preview in the Virtual Console area, click Open Preview. ● To disable KVM preview in the Virtual Console area, click Close Preview. ● To start the virtual console in HTML mode, click Operate and then select Start HTML Virtual Console from the shortcut menu. ● To start the virtual console in Java mode, click Operate and then select Start Java Virtual Console from the shortcut menu. ● To reset the virtual console, click Operate and then select Reset Virtual Console from the shortcut menu. ● Click Settings.
11	System Monitoring	<p>Displays system monitoring information.</p>

Chapter 4

Common Operations

Table of Contents

Logging In to the BMC Through SSH.....	27
Logging In to the BMC Through a Serial Port.....	29
Modifying the BMC Address.....	33
Checking Server Information.....	34
Managing Storage Devices.....	36
Installing an OS Remotely.....	38
Resetting the BMC When the Web Portal Is Unavailable.....	44
Querying and Configuring Services.....	45
Configuring an NTP Server.....	47
Configuring an SMTP Server.....	49
Configuring Trap Notification Parameters.....	50
BMC Log Export.....	52
Upgrading the BMC Firmware.....	56
Restoring Factory Defaults.....	57
Backing Up BMC Configurations.....	58
Creating an SNMP User.....	59

4.1 Logging In to the BMC Through SSH

Abstract

This procedure describes how to log in to the **BMC** through **SSH** to configure the BMC.

Prerequisite

The **PC** is already installed with SSH software, for example, *PuTTY*.




Note

The operations for different SSH software are similar. This procedure uses the *PuTTY* software as an example.

Steps

1. On the PC, start the *PuTTY* software. The **PuTTY Configuration** window is displayed, see [Figure 4-1](#).

Figure 4-1 PuTTY Configuration Window



2. Set the parameters. For a description of the parameters, refer to [Table 4-1](#).

Table 4-1 PuTTY Configuration Parameter Descriptions

Parameter	Setting
Category	Select Session .
Host Name (or IP address)	Enter the IP address of the iSAC management network port or shared network port.

Port	Enter <i>22</i> .
Parameter	Setting
Connection type	Select SSH .

- Click **Open**. The CLI is displayed.
- Enter the username and password of the administrator.

**Note**

The default administrator username is *sysadmin*. The default administrator password depends on server models and BMC versions. For details, refer to [10 Reference: Default Passwords](#).

- Press **Enter** to log in to the BMC.

4.2 Logging in to the BMC Through a Serial Port

Abstract

When neither the [iSAC](#) management network port nor the shared network port is available for accessing the [BMC](#), you can log in to the BMC through a serial port to configure the BMC.

Prerequisite

- The [PC](#) is already installed with [SSH](#) software, for example, *PuTTY*.

**Note**


The operations for different SSH software are similar. This procedure uses the *PuTTY* software as an example.

- If the PC needs to convert a [USB](#) port into a serial port, the corresponding driver must be installed.
- A serial cable is available.

Steps

- Connect the PC to the serial port on the rear panel of the server through a serial cable.
 - Connect the PC to the audio serial port on the rear panel of a G5 server, as shown in [Figure 4-2](#).

Figure 4-2 Position of the Audio Serial Port



1. Audio serial port



Note

The port with the  silk screen on the rear panel of the server identifies the audio serial port. This procedure uses an 2230-RE server as an example to describe the position of the serial port.

- Connect the PC to the **USB** serial port on the rear panel of a G6 server, as shown in [Figure 4-3](#).

Figure 4-3 Position of the USB Serial Port



1. USB Serial Port



Note

The port with the  silk screen on the rear panel of the server identifies the USB serial port. This procedure uses an R5300 G6 server as an example to describe the position of the serial port.

2. Press and hold the **UID** button on the front panel of the server for six seconds. The serial port is switched to the BMC serial port commissioning mode.

For the position of the UID button on the front panel, refer to [Figure 4-4](#).

Figure 4-4 Position of the UID Button




1. UID button



The button with the **UID** silk screen on the front panel of a server is the UID button. This procedure uses an 2230-RE server as an example to describe the position of the UID button.

3. In the **Device Manager** window on the PC, check the serial port connected with the serial cable.
4. On the PC, start the *PuTTY* software. The **PuTTY Configuration** window is displayed, see [Figure 4-5](#).

Figure 4-5 PuTTY Configuration Window



5. Set the parameters. For a description of the parameters, refer to [Table 4-2](#).

Table 4-2 PuTTY Configuration Parameter Descriptions

Parameter	Setting
Category	Select Session .
Serial line	Enter the serial port obtained in Step 3 .
Speed	Enter <i>115200</i> .
Connection type	Select Serial .

6. Click **Open**. The CLI is displayed.

7. Enter the username and password of the administrator.

**Note**

The default administrator username is *sysadmin*. The default administrator password depends on server models and BMC versions. For details, refer to [10 Reference: Default Passwords](#).

8. Press **Enter** to log in to the BMC.

4.3 Modifying the BMC Address

Abstract

To replan the IP address of the iSAC management network port or shared network port of the server, you need to modify the address of the BMC.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 4-6](#).

Figure 4-6 Network Settings Page

The screenshot shows the 'Network Protocols' configuration page. At the top, there are radio buttons for 'Dedicated Port' (selected) and 'Shared Port'. Below that, there are checkboxes for 'IPv4' and 'IPv6', both of which are checked. The page is divided into two main sections: 'IPv4' and 'IPv6'.
 In the 'IPv4' section, the 'Acquisition method' is set to 'Manually set IP address'. The fields are: Address (10.239.227.66), Mask (255.255.255.0), Default Gateway (10.239.227.1), and MAC Address (D4:2A:24:5E:AF:51).
 In the 'IPv6' section, the 'Acquisition method' is set to 'Automatically obtain IP address'. The fields are: Address (::), Prefix Length (0), Default Gateway (::), and Link Local Address (fe80::d62a:24fff:fe5eaf51).
 A blue 'Save' button is located at the bottom center of the form.

3. Set the parameters in the **Network Protocols** area. For a description of the parameters, refer to [Table 4-3](#).

Table 4-3 Network Protocol Parameter Descriptions

Parameter	Setting
Select Network Port	This parameter can be set only if Select Mode is set to Alone in the Network Port area. Select the network port for which you want to configure an IP address. <ul style="list-style-type: none"> ● Dedicated Port: configures the IP address of the iSAC management network port.
	<ul style="list-style-type: none"> ● Shared Port: configures the IP address of the shared network port.
Network Protocols	Select the network protocol(s) for the network port. <ul style="list-style-type: none"> ● The IPv4 settings need to be configured if you select IPv4 only. ● The IPv6 settings need to be configured if you select IPv6 only. ● Both IPv4 settings and IPv6 settings need to be configured if you select IPv4 and IPv6.
Acquisition method	Select the method of obtaining the IP address. The parameters below do not need to be configured if Acquisition method is set to Automatically obtain IP address .
Address	Enter the address of the BMC as planned.
Mask	Enter the mask.
Default Gateway	Enter the IP address of the default gateway.

4. Click **Save**.

4.4 Checking Server Information

Abstract

Before reporting a fault or replacing hardware, you must check the server information, including:

- Serial number
- [CPU](#)
- Memory
- [NIC](#)
- Slot that a [GPU](#) is located




Note

For the 2230-RE 4-GPU model, the operations of removing and installing a GPU are complicated. Before removing and installing the GPU, you need to query the ID of the slot where the GPU is located to ensure that the operations are correct.

Steps

1. On the **Homepage**, check the serial number of the server, see [Figure 4-7](#).

Figure 4-7 Homepage



2. Select **System**. The **System** page is displayed.
3. From the navigation tree in the left pane, select **System Information**. The **System Information** page is displayed, see [Figure 4-8](#).

Figure 4-8 System Information Page

System Information												
⊕ CPU Information ⊖ Memory Information ⊖ Disk Information ⊖ Network Adapter ⊖ FRU Information ⊖ Sensor ⊖ Other												
Details	No.	Name	Present Status	Health Status	Manufacturer	Model	TDP(Watt s)	Frequency(MHz)	Maximum Frequency(MHz)	Core s	Threa ds	Architectu re
⊖	1	CPU 0	Present	● Healthy	Intel(R) Corporation	Intel(R) Xeon(R) Platinum 8470Q	350	2100	3800	52	104	x86
⊖	2	CPU 1	Present	● Healthy	Intel(R) Corporation	Intel(R) Xeon(R) Platinum 8470Q	350	2100	3800	52	104	x86

Total 2 ⏪ < 1 > ⏩ 10 / Page To 1 Page

4. Perform the following operations as required.

To...	Do...
Check CPU information	Click CPU Information to switch to the CPU Information tab.
Check memory information	Click Memory Information to switch to the Memory Information tab.
Check NIC information	Click Network Adapter to switch to the Network Adapter tab.
Check GPU information	<ol style="list-style-type: none"> a. Click Other. The Other tab is displayed, as shown in Figure 4-9. b. Check the Position and Device BDF columns for each GPU.

To...	Do...
	<p>The last two digits in the Position column indicate the slot where a GPU is located. For example, mainboardPCleCard11 indicates that the slot number of the GPU is 11.</p> <p>c. Log in to the server as the <code>root</code> user.</p> <p>d. Run the following command to view the slot number of the GPU, as shown in Figure 4-10.</p> <pre># lspci -s 0:98:0:0 -vvv</pre> <p>In the above command, "0:98:0:0" is the BDF of the GPU.</p>

Figure 4-9 Other Tab

Position	Name	Description	Manufacturer	Type	Status	Maximum Speed (GTps)	Negotiation Speed (GTps)	Maximum bandwidth	Negotiate bandwidth	Device BDF	Root Port BDF
mainboardPCleCard11	GPU11	NVIDIA L20	Nvidia	GPU	Active	16	16	x16	x16	0:98:0:0	0:97:1:0
mainboardPCleCard12	GPU12	NVIDIA L20	Nvidia	GPU	Active	16	16	x16	x16	0:d8:0:0	0:d7:1:0
mainboardPCleCard13	GPU13	NVIDIA L20	Nvidia	GPU	Active	16	16	x16	x16	0:38:0:0	0:37:1:0
mainboardPCleCard14	GPU14	NVIDIA L20	Nvidia	GPU	Active	16	16	x16	x16	0:5a:0:0	0:59:1:0

Figure 4-10 Querying a Physical Slot of a GPU

```
[root@localhost Desktop]# lspci -s 0:98:0:0 -vvv
98:00.0 3D controller: NVIDIA Corporation Device 26ba (rev a1)
Subsystem: NVIDIA Corporation Device 1957
Physical Slot: 11
```

4.5 Managing Storage Devices

Abstract

The storage devices of a server refer to [RAID](#) controllers and hard disks.


The physical disks managed by a RAID controller can be created as logical disks.

On the **Storage Management** page, the **Storage Card** tab displays [SAS/SATA](#) disks, and the **NVMe** tab displays NVMe disks.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Storage Management**. The **Storage Management** page is displayed, see [Figure 4-11](#).

Figure 4-11 Storage Management Page



1. RAID controller
2. Logical disk
3. Physical disk

3. Perform the following operations as required.

To...	Do...
Check RAID controller and BBU information	On the Storage Card tab, click the desired RAID controller. The RAID controller and BBU information is displayed on the right.
Check logical disk information	On the Storage Card tab, click the desired logical disk. The detailed logical disk information is displayed on the right. In the logical disk information, Status includes: <ul style="list-style-type: none"> ● Optimal ● Degraded ● Part Degraded ● Offline
Set the UID indicator of a logical disk	<ol style="list-style-type: none"> a. On the Storage Card tab, click the desired logical disk. b. Click Settings on the right. The Logical Drive Setting dialog box is displayed. c. Select Open or Close. <ul style="list-style-type: none"> ● Open: turns on the UID indicators of all member disks of the logical disk. ● Off: turns off the UID indicators of all member disks of the logical disk. d. Click Submit.

Check physical disk information	On the Storage Card tab, click the desired physical disk. The detailed physical disk information is displayed on the right.
To...	Do...
Create a logical disk	<ol style="list-style-type: none"> On the Storage Card tab, click + next to a RAID controller. The Create Logical Drive area is displayed on the right, see Figure 4-12. Configure the following parameters: <ul style="list-style-type: none"> ● Logical disk name: Enter the name of the logical disk. ● RAID Level: Select the corresponding RAID level. ● Stripe Size: Select a stripe size. ● Physical Drive Configuration: Select the member disks that form the logical disk. Click Save.
Query NVMe hard disk information	On the Storage Management page, click NVMe to switch to the NVMe tab. The detailed NVMe disk information is displayed.

Figure 4-12 Create Logical Drive Area

Create Logical Drive

Logical disk name

RAID Level

Strip Size

Physical Drive Configuration

Note

Different types of RAID controllers have different pages for creating logical disks.

4.6 Installing an OS Remotely

Abstract

When you are not on the customer site, you can install the [OS](#) for a server remotely through a PC.

The operations for remote OS installation include:

1. Disabling media redirection configurations
2. Configuring a boot mode
3. Installing an OS

Prerequisite


- The *iso* file of the OS is already obtained.
- The **RAID** configuration for the system disk of the server is already completed.
- If the **KVM** needs to be started in Java mode, **JRE** (for example, *jre-8u191*) is already installed on the PC.

Steps

Disabling Media Redirection Configurations

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Virtual Media**. The **Virtual Media** page is displayed, see [Figure 4-13](#).

Figure 4-13 Virtual Media Page




The screenshot displays the 'Virtual Media' configuration page. At the top, there are two tabs: 'Media Setting' (selected) and 'Media Mounting'. Below the tabs is the 'VMedia Entity Settings' section, which contains four dropdown menus, each set to the value '1':

- CD/DVD Physical Device
- HD Physical Device
- Remote KVM CD/DVD Physical Device
- Remote KVM HD Physical Device

Below these settings is a toggle switch for 'Media Redirection Encryption', which is currently turned off. A red rectangular box highlights this toggle switch. At the bottom of the settings area is a blue 'Save' button.

3. In the **VMedia Entity Settings** area, turn off **Media Redirection Encryption**, and click **Save**.
4. From the navigation tree in the left pane, select **Virtual Console**. The **Virtual Console** page is displayed, see [Figure 4-14](#).

Figure 4-14 Virtual Console Page




5. In the **Session Settings** area, turn off **Communication Encryption**, and click **Save**.

Configuring a Boot Mode

- 6. Select **System**. The **System** page is displayed.
- 7. From the navigation tree in the left pane, select **System Settings**. The **System Settings** page is displayed, see [Figure 4-15](#).

Figure 4-15 System Settings Page



8. Set the parameters. For a description of the parameters, refer to [Table 4-4](#).

Table 4-4 Boot Option Parameter Descriptions

Parameter	Setting
Boot Medium	Select CD/DVD .
Boot Mode	Select UEFI .
Effective	Select Permanent .

9. Click **Save**.

Installing an OS

10. Select **Services**. The **Services** page is displayed.

11. From the navigation tree in the left pane, select **Virtual Console**. The **Virtual Console** page is displayed.

12. Perform the following operations as required.

To...	Do...
Start the KVM in HTML mode	<ol style="list-style-type: none"> a. Click HTML Virtual Console. The HTML Virtual Console page is displayed, see Figure 4-16. b. Click Browse File next to CD Image, and select the <i>iso</i> file from the PC. c. Click Start Media to load the <i>iso</i> file. d. Select Power > Reset Server to restart the server. The page for installing the OS is displayed.

<p>Start the KVM in Java mode</p>	<ol style="list-style-type: none"> a. In the search box in the lower left corner of the PC, enter <i>Java</i>. b. In the search result, select Configure Java. The Java Control Panel dialog box is displayed. c. Click Security. The Security window is displayed. d. Click Edit Site List. The Exception Site List dialog box is displayed. e. Click Add to add the address of the Web portal of the BMC. f. Click OK to return to the Security window. g. Click OK. h. On the Virtual Console page of the Web portal of the BMC, click Java Virtual Console. A dialog box indicating whether to keep <i>jviewer.jnlp</i> is displayed. i. Click Keep. j. In the lower left corner of the browser, click <i>jviewer.jnlp</i>. A dialog box indicating whether to proceed is displayed. k. Click Continue. The Do you want to run this application? dialog box is displayed. l. Select I accept the risk and want to continue to run this app. and click Run. The Untrusted Connection dialog box is displayed. m. Click Yes. The Java Console page is displayed, see Figure 4-17.
<p>To...</p>	<p>Do...</p>
	<ol style="list-style-type: none"> n. Select Media > Virtual Media Wizard..., and switch to the CD/DVD tab. o. Click Browse, and select the <i>iso</i> file from the PC. p. Click Connect. q. Select Power > Reset Server to restart the server. The page for installing the OS is displayed.

Note

Before starting the KVM in one mode, you must disable the KVM in another mode. For example, before starting the KVM in Java mode, you must disable the KVM started in HTML mode.

Figure 4-16 HTML Console Page





Figure 4-17 Java Console Page



4.7 Resetting the BMC When the Web Portal Is Unavailable

Abstract

If you cannot log in to the Web portal of the [BMC](#), you need reset the BMC.

You can reset the BMC through one of the following ways:

- Resetting the BMC by logging in to the server
- Resetting the BMC by using an [SSH](#) tool (for example, PuTTY)
- Resetting the BMC by using the ipmitool
- Resetting the BMC by powering off the server

Prerequisite

- If you want to reset the BMC by using the ipmitool, the **ipmi** service port number is already set to **623**.
- If you want to reset the BMC by using the ipmitool, the BMC address is successfully pinged with the ipmitool.

Steps

- Resetting the BMC by logging in to the server
 1. Log in to the server as the `root` user.
 2. Run the following commands to reset the BMC:

```
# modprobe ipmi_si
# modprobe ipmi_devintf
# ipmitool mc reset cold
```
- Resetting the BMC by using an [SSH](#) tool
 1. Log in to the BMC by using the SSH tool Enter the following parameters for login:
 - Host address: address of the BMC
 - Username: sysadmin (the default administrator username)
 - Password: The default administrator password depends on server models and BMC versions. For details, refer to [10 Reference: Default Passwords](#).
 - Port number: 22
 2. Run the following command to reset the BMC:

```
# reboot
```
- Resetting the BMC by using the ipmitool
 1. In the ipmitool, run either of the following commands to reset the BMC:
 - Warm boot: `ipmitool -I lanplus -H 10.235.51.202 -U Administrator`

```
-P Superuser9! mc reset warm Sent warm reset command to MC  
→ Cold boot: ipmitool -I lanplus -H 10.235.51.202 -U Administrator  
P Superuser9! mc reset cold Sent cold reset command to MC
```

The parameters in the above commands are described as follows:

- **10.235.51.202**: address of the BMC
- **Administrator**: username
- **Superuser9!**: password

- Resetting the BMC by powering off the server
 1. Power off the server without services.
 2. Power on the server.

4.8 Querying and Configuring Services

Abstract

By default, the **BMC** provides the following services:

- **web**: a platform-independent, low-coupling, self-contained, programmable web-based application. You can use open **XML** standards for defining, publishing, discovering, coordinating, and configuring such applications, which are used to develop distributed and interoperable applications.
- **kvm**: controls, switches between, and manages multiple devices through a keyboard, display, or mouse, playing an important role in remote scheduling and monitoring.
- **cd-media**: a virtual media service that allows a **KVM** target server to access files on physical **CD/DVD** devices on a PC (acting as the client).
- **hd-media**: a virtual media service that allows a **KVM** target server to access files on physical **HD** devices on a PC (acting as the client).
- **ssh**: a protocol that provides secure remote access and other secure network services in an insecure network.
- **vnc**: a remote control tool, which consists of the application program (vncviewer) of the client and the application program (vncserver) of the server.
- **snmp**: a network management standard protocol widely used in **TCP/IP** networks. It provides unified interfaces to achieve the unified management of devices of different manufacturers.
- **redfish**: a server management specification. The Redfish Scalable Platforms Management **API** ("Redfish") uses RESTful interface semantics to access data defined in model format to perform out-of-band systems management. It is suitable for the management and deployment of large-scale server cloud environments.
- **ipmi**: a standard applied to server management system design.

This procedure describes how to query and modify the parameters of the services above.

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Port Services**. The **Port Services** page is displayed, see [Figure 4-18](#).

Figure 4-18 Port Services Page

Port Services							
No.	Name	Status	Non Secure Port	Secure Port	Timeout(Min)	Maximum Sessions	Operation
1	web	Open	80	443	30	20	Edit
2	kvm	Open	7578	7582	30	4	Edit
3	cd-media	Open	5120	5124	--	1	Edit
4	hd-media	Open	5123	5127	--	1	Edit
5	ssh	Open	--	22	10	--	Edit
6	vnc	Open	5900	5901	10	2	Edit
7	snmp	Open	161	--	--	--	Edit
8	redfish	Open	--	--	--	--	Edit
9	ipmi	Open	--	623	--	--	

3. Click **Edit** for a service to activate the parameters.
4. Set the parameters. For a description of the parameters, refer to [Table 4-5](#).

Table 4-5 Port Service Parameter Descriptions

Parameter	Setting
Status	Select whether to enable a service.
Non Secure Port	Enter the non-secure port number of the service. <ul style="list-style-type: none"> ● Default non-secure port number of the Web service: 80. ● Default non-secure port number of the KVM service: 7578. ● Default non-secure port number of the CD media service: 5120. ● Default non-secure port number of the HD media service: 5123. ● Default non-secure port number of the VNC service: 5900. ● Default non-secure port number of the SNMP service: 161. Other services do not support non-secure ports. Range of the non-secure port numbers: 1–65535.

Secure Port	<p>Enter the secure port number of the service.</p> <ul style="list-style-type: none"> ● Default secure port number of the Web service: 443. ● Default secure port number of the KVM service: 7582. ● Default secure port number of the CD media service: 5124. ● Default secure port number of the HD media service: 5127. ● Default secure port number of the SSH service: 22. ● Default secure port number of the VNC service: 5901. ● Default secure port number of the IPMI service: 623. <p>Other services do not support secure ports. Range of the secure port numbers: 1–65535.</p>
Timeout(Min)	<p>The service exits if no operation is performed within the specified timeout period.</p> <p>Enter the timeout period (in minutes). Range: 5–60 (for the VNC service) or 1–60 (for other services).</p>



Note

You cannot configure the **Maximum Sessions** parameter.

5. Click **Save**.

Verification

- After enabling the Redfish service, you can query and configure the BMC through the Redfish interface.

For a detailed description of the Redfish interface, refer to the `VANTAGEO Server Redfish Interface Description (BMC V4)`. For how to obtain the `VANTAGEO Server Redfish Interface Description (BMC V4)` file, refer to [11 Reference: Accessing Documents](#).

- After enabling the SNMP service and configuring a correct non-secure port, you can query and configure the BMC through the SNMP interface.

For a detailed description of the SNMP interface, refer to the `VANTAGEO Server SNMP Interface Description (BMC V4)`. For how to obtain the `VANTAGEO Server SNMP Interface Description (BMC V4)` file, refer to [11 Reference: Accessing Documents](#).

4.9 Configuring an NTP Server

Abstract

An **NTP** server is a time synchronization source of the **BMC**. If the time of the **BMC** needs to be synchronized with an **NTP** server, you need to configure the NTP server.

To configure an NTP server, perform the following operations:

1. Enabling the NTP service: provides the NTP service for the devices whose time needs to be synchronized.
2. Modifying the registry: modifies the registry parameters related to the NTP service.
3. Restarting the NTP service: applies the modified registry parameters.



Note

This procedure uses the operations on a [PC](#) with the Windows Server 2012 R2 OS as an example. The operations on PCs with other Windows Server OSs are similar.

Steps

Enabling the NTP Service

1. Right-click **This PC** on the desktop, and then select **Manage** from the shortcut menu. The **Computer Management** window is displayed.
2. From the navigation tree in the left pane, select **Services and Applications > Services**. The **Services** window is displayed.
3. In the service list, right-click **Windows Time** and select **Start** from the shortcut menu.

Modifying the Registry

4. Press **Windows+R**. The **Run** dialog box is displayed.
5. In the **Open** text box, enter `regedit`, and click **OK**. The **Registry Editor** window is displayed.
6. Modify the registry parameters. For a description of the parameters, refer to [Table 4-6](#).

Table 4-6 Registry Parameter Descriptions

Registry Path	Parameter	Value
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\W32Time\Config	AnnounceFlags	5
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\W32Time\TimeProviders\NtpServer	Enabled	1
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\W32Time\Parameters	Type	NTP

Restarting the NTP Service

7. In the **Open** text box in the **Run** dialog box, enter `cmd`, and click **OK**. The command line window is displayed.
8. Run the following command to stop the NTP service:


```
C:\> net stop w32time
```

9. Run the following command to start the NTP service:

```
C:\> net start w32time
```

10. Run the following command to verify that the NTP server is configured successfully:

```
C:\> w32tm /stripchart /computer:127.0.0.1
```

If the output time is displayed after the command is executed, it indicates that the configuration is successful.

4.10 Configuring an SMTP Server

Abstract

An [SMTP](#) server receives alarm emails from the [BMC](#).

To configure an SMTP server, perform the following operations:

1. Installing the SMTP server: provides the SMTP service for the BMC.
2. Configuring the [IP](#) address and port number: sends alarm emails (if any) to the default path (`C:\inetpub\mailroot\Drop`) on the SMTP server after the IP address and port number of the SMTP server are configured on the Web portal of the BMC.



Note

This procedure uses the operations on a [PC](#) with the Windows Server 2012 R2 OS as an example. The operations on PCs with other Windows Server OSs are similar.

Steps

Installing an SMTP Server

1. Press **Windows+R**. The **Run** dialog box is displayed.
2. In the **Open** text box, enter `servermanager`, and click **OK**. The **Server Manager** window is displayed.
3. Click **Add Roles and Features**. The **Add Roles and Features Wizard** window is displayed.
4. Select **Role-based or feature-based installation**.
5. Click **Next**.
6. Select **Select a server from the server pool**, and then select the server from **Server Pool**.
7. Click **Next** until the **Features** step in **Add Roles and Features Wizard** is displayed.
8. Select **SMTP Server**.
9. Click **Install**.

Configuring the IP Address and Port Number

10. In **Control Panel > System and Security > Administrative Tools**, double-click **Internet Information Services (IIS) 6.0 Manager**.
11. Right-click **SMTP Virtual Server #1**, and select **Properties** from the shortcut menu. The **[SMTP Virtual Server #1] Properties** dialog box is displayed.
12. From the **IP address** list, select the corresponding IP address.



The selected IP address is that of the server selected in [Step 6](#).

13. Switch to the **Delivery** tab.
14. Click **Outbound connections**. The **Outbound Connections** dialog box is displayed.
15. In the **TCP port** text box, enter *25*.
16. Click **OK**.

4.11 Configuring Trap Notification Parameters

Abstract

Trap notification parameters are used by the [BMC](#) to report alarms to a third-party [NMS](#) through traps.



Trap notification parameters are provided by the third-party NMS, so the values of trap notification parameters set on the Web portal of the BMC must be the same as those on the third-party NMS.

Abstract

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Alarm Settings**. The **Alarm Settings** page is displayed, see [Figure 4-19](#).

Figure 4-19 Alarm Settings Page

Alarm Settings

Trap Notification
Syslog Notification
Email Notification

Trap Function

Trap

Trap Version:

Select V3 User:

Community Name:

Confirm Community Name:

Trap Host ID:

Event Sending Level:

[Save](#)

Trap Server Configuration

No.	Server Address	Trap Port	Current Status	Operation
1	10.239.212.117	323	Disabled	Edit Test
2	10.230.19.204	162	Enabled	Edit Test
3	10.239.211.53	53	Enabled	Edit Test
4	10.239.166.158	162	Enabled	Edit Test

- Set the parameters in the **Trap Function** area. For a description of the parameters, refer to [Table 4-7](#).

Table 4-7 Trap Function Parameter Descriptions

Parameter	Setting
Trap	Turn on the Trap switch.
Trap Version	Select the SNMP version for traps. Options: V1 , V2C , and V3 .
Select V3 User	This parameter is required if Trap Version is set to V3 . Select an SNMP user as the alarm sender. For how to create an SNMP user, refer to “ 4.16 Creating an SNMP User ”.
Community Name	This parameter is required if Trap Version is set to V1 or V2C . Enter the trap community name.
Confirm Community Name	This parameter is required if Trap Version is set to V1 or V2C . Enter the trap community name.
Trap Host ID	Select the identifier of the host that reports alarms.
Event Sending Level	Select the level of events to be reported. For example, if Event Sending Level is set to Critical , only critical alarms are reported.

- Click **Save**.

- Set the parameters in the **Trap Server Configuration** area. For a description of the parameters, refer to [Table 4-8](#).

Table 4-8 Parameter Descriptions for Trap Server Configuration

Parameter	Setting
Server Address	After you click Edit , the parameter is activated. Enter the address of the server that receives alarms. An IPv4 address, IPv6 address, or domain name is supported.
Trap Port	After you click Edit , the parameter is activated. Enter the port number of the server that receives alarms. Range: 1–65535.
Current Status	After you click Edit , the parameter is activated. Select whether to enable the current server to receive alarms.

- Click **Save**.



Note

After the **Edit** button is clicked, it is changed to the **Save** button.

- (Optional) To send a test event to the server, click **Test**.



Note

If a message indicating "sent successfully" is displayed on the page, the trap is sent successfully.

4.12 BMC Log Export

You can export [BMC](#) logs in the following ways:

- Exporting logs in one click through the Web portal
For details, refer to [4.12.1 Exporting Logs in One Click Through the Web Portal](#).
- Exporting logs by category through the Web portal
For details, refer to [4.12.2 Exporting Logs by Category Through the Web Portal](#).
- Exporting logs through [SSH](#) commands
For details, refer to [4.12.3 Exporting Logs Through the CLI \(SSH\)](#).
- Export logs through a serial port
For details, refer to [4.12.4 Exporting Logs Through the CLI \(Serial Port\)](#).

4.12.1 Exporting Logs in One Click Through the Web Portal

Abstract

The Web portal of the BMC provides the one-click log export function. The exported log file is named `bmcinfo_<product serial number>.tar.gz` and stored in the default download directory of the browser.




Note

If the product serial number is not programmed, the filename is `bmcinfo_UnknownProductSN.tar.gz`.

Steps

1. In the **Shortcuts** area on the **Homepage**, click **One-Click Collection**. The **Confirm one click acquisition** dialog box is displayed, see [Figure 4-20](#).

Figure 4-20 Confirm One Click Acquisition Dialog Box



2. Click **Submit**.



Note

During the collection process, all Web interfaces of the BMC cannot be operated. If you shut down the browser by mistake and collect logs again after relogging in to the Web portal of the BMC, the **One click acquisition is being processed, please try again later**. prompt is displayed. In this case, you need to wait for about five minutes.

4.12.2 Exporting Logs by Category Through the Web Portal

Abstract


Logs of the BMC include:

- **Operation Logs:** record the information about users' operations on the server, including manual server operations and remote server operations.
- **Audit Logs:** record users' login to and logout of the Web portal, BMC, and KVM.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **BMC Logs**. The **BMC Logs** page is displayed, see [Figure 4-21](#).

Figure 4-21 BMC Logs Page



3. Perform the following operations as required.

To...	Do...
Export operation logs	<ol style="list-style-type: none"> Click Operation Logs to switch to the Operation Logs tab. (Optional) In the Search box, enter a keyword. Click Download Logs.
Export audit logs	<ol style="list-style-type: none"> Click Audit Logs to switch to the Audit Logs tab. (Optional) In the Search box, enter a keyword. Click Download Logs.

4.12.3 Exporting Logs Through the CLI (SSH)

Abstract

If the Web portal of the BMC fails, you can log in to the BMC through SSH and export logs in one click through the CLI.

Steps

1. Connect to the BMC by using an SSH tool.
2. Run the following commands in the CLI to export logs:

```
# cd /etc/init.d/  
# ./expert_bmcdata.sh
```



After the logs are exported, they are stored in the `/var/bmcdata` directory.

3. Download the log file to the local PC by using the SFTP function.
4. Run the following commands in the CLI to delete the BMC log file:

```
# cd /var/bmcdata  
# rm bmcinfo_.tar.gz
```

4.12.4 Exporting Logs Through the CLI (Serial Port)

Abstract

If the BMC cannot be accessed due to a network error, you can export logs in one click through the serial port.

Steps

1. Connect to the serial port of the BMC by using a serial cable.
2. Press and hold the UID button on the server panel for six seconds until the indicator flashes blue.
3. Connect to the serial port of the BMC by using a serial port tool.
4. After the connection is established, log in to the serial port with the corresponding username and password.
5. Run the following commands in the CLI to export logs:

```
# cd /etc/init.d/  
# ./expert_bmcdata.sh
```

**Note**

After the logs are exported, they are stored in the `/var/bmcdata` directory.

6. Run the following command to back up the log file to the `/mnt/nandflash0/` directory:

```
# cp /var/bmcdata/bmcinfo_.tar.gz /mnt/nandflash0/
```

**Note**

After the network is restored, you can download the log file to the local PC by using the [SFTP](#) function.

4.13 Upgrading the BMC Firmware

Abstract

When the [BMC](#) firmware needs to be upgraded, you can upload the firmware online to upgrade it.

**Note**

- The Web portal of the BMC temporarily supports the upgrade of the active BMC firmware only. After the active BMC firmware is upgraded, the BMC is automatically restarted to apply it.
- If a firmware version fails to be upgraded during the upgrade process, you must upgrade it again.

Prerequisite

The BMC firmware is already obtained.

**Note**

The firmware upgrade file can be downloaded on the **Software Download** page on the Web portal of the servers and storage products (<https://VANTAGEO.com/Enterpriseservers>).

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Firmware Upgrade**. The **Firmware Upgrade** page is displayed, see [Figure 4-22](#).

Figure 4-22 Firmware Upgrade Page

Firmware Upgrade

Firmware Upgrade | Mode Switching

After the BMC is upgraded, the BMC is automatically restarted. When the system is powered off, the BIOS upgrade takes effect directly. When the system is powered on, the BIOS is updated to the backup version and takes effect automatically after the systems is powered off. It takes a period of time to make the firmware take effect automatically, and firmware upgrade cannot be performed during this period.

Firmware Operation: [Reset BMC](#)

Version Information	
BMC Primary Partition Version	04.24.04.00 (Sep 27 2024)
BMC Standby Partition Version	04.24.04.00 (Aug 26 2024)
BIOS Primary Version	04.24.03.10 (Aug 26 2024)
BIOS Standby Version	04.24.03.10 (Aug 26 2024)
EPLD Version	00.00.00.0107

Upgrade
 Don't Inherit Configuration When Upgrading BMC
 Don't Inherit Configuration When Upgrading BIOS

[Upload](#)

[Upgrade](#)

3. Click **Upload** and select the firmware upgrade file.

**Note**

After the BMC firmware is successfully uploaded, the **Don't Inherit Configuration When Upgrading BMC** check box becomes activated.

4. (Optional) To restore the factory default settings of the BMC, select **Don't Inherit Configuration When Upgrading BMC**.
5. Click **Upgrade**.

**Notice**

During the firmware upgrade process, you cannot to switch to another page. Otherwise, the upgrade process is interrupted.

4.14 Restoring Factory Defaults

Abstract

This procedure describes how to restore the server configuration items (for example, the network, user, [SNMP](#) configuration, and boot mode) to factory defaults.

**Note**

Do not perform any operation during restoration. After the factory defaults are restored, the [BMC](#) will be restarted automatically.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Configuration Update**. The **Configuration Update** page is displayed, see [Figure 4-23](#).

Figure 4-23 Configuration Update Page

The screenshot shows the 'Configuration Update' page with three main sections: 'Configure Import', 'Configure Export', and 'Restore Factory Settings'. Each section has radio buttons for 'BMC' and 'BIOS' and a corresponding action button.

Configuration Update

Configure Import

Supports importing BMC and BIOS configurations. After importing, BMC automatically restarts and the configuration takes effect. BIOS takes effect and requires manual resetting of the host.

Select Type: BMC BIOS

Select File: Upload

Import

Configure Export

Select Type: BMC BIOS

Export

Restore Factory Settings

After restoring BMC factory settings, you need to log in to BMC for the first time. Please use this function with caution.

Restore Factory Settings

3. Click **Restore Factory Settings**.

4.15 Backing Up BMC Configurations

Abstract

Before replacing the mainboard of the server, you must export the **BMC** configurations. After replacing the mainboard, you need to import the BMC configurations.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Configuration Update**. The **Configuration Update** page is displayed, see [Figure 4-24](#).

Figure 4-24 Configuration Update Page

The screenshot shows the 'Configuration Update' page with three main sections:

- Configure Import:** Includes an information icon and text: 'Supports importing BMC and BIOS configurations. After importing, BMC automatically restarts and the configuration takes effect. BIOS takes effect and requires manual resetting of the host.' Below this are radio buttons for 'Select Type' (BMC selected, BIOS unselected), an 'Upload' button, and an 'Import' button.
- Configure Export:** Includes radio buttons for 'Select Type' (BMC selected, BIOS unselected) and an 'Export' button.
- Restore Factory Settings:** Includes an information icon and text: 'After restoring BMC factory settings, you need to log in to BMC for the first time. Please use this function with caution.' Below this is a 'Restore Factory Settings' button.

3. Click **Export** to export the current BMC configurations to your local PC.
4. After replacing the mainboard, click **Upload**, and select the exported BMC configuration file in the displayed dialog box.
5. Click **Import**, and confirm the import in the displayed message box.

**Note**

After the BMC configurations are imported, the BMC is automatically restarted to apply the configurations. Do not perform any other operations until the BMC is restarted.

4.16 Creating an SNMP User

Abstract

When configuring notification parameters for SNMPv3 trap messages, you need to select an **SNMP** user as the alarm sender. This procedure describes how to create an SNMP user.

Steps


1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Local Users**. The **Local Users** page is displayed, as shown in [Figure 4-25](#).

Figure 4-25 Local Users Page



3. Click **Add User**. The **Add User** page is displayed, as shown in [Figure 4-26](#).

Figure 4-26 Add User Page



4. Set the parameters. For a description of the parameters, refer to [Table 4-9](#).

Table 4-9 Parameter Descriptions for Adding a Local User

Parameter	Description
New User ID	Select the ID of the new user. A maximum of 16 local users are supported, so the user ID ranges from 1 to 16. User 1 is a reserved user, and user 2 is the default administrator.
New UserName	Enter the name of the new user. The name contains a maximum of 16 characters, including digits, letters (case sensitive), and special characters. The new username cannot be the same as any existing one. The following cannot be used as a username: sshd, ntp, stunnel4, sysadmin, daemon, Administrator, and anonymous. The allowed special characters include hyphens (-), underscores (_), and at symbols (@).

Parameter	Description
New Password	<p>Enter the password of the new user. The password contains 8–20 characters, including digits, letters (case sensitive), and special characters. It must contain one special character and characters from at least two of the following types: digits, uppercase letters, and lowercase letters. The password can contain the following special characters: ` , ~ , ! , @ , \$, % , ^ , & , * , (,) , - , _ , = , + , \ , , [, { , } ,] , ; , ' , " , , , < , > , / , ? , # , ; .</p> <p>The function of disabling historical passwords is disabled by default. If this function is enabled, the new password cannot be the same as any of the historical passwords.</p> <p>The password cannot be the same as the username in reverse order. For example, if the username is test, the password cannot be tset.</p>
Confirm Password	Enter the password again. It must be the same as New Password .
Role	Select the role of the new user.
Login Interfaces	<p>Select one or more login interfaces available to the new user.</p> <ul style="list-style-type: none"> ● SNMP is required. It indicates SNMP interface-based login. ● For Redfish interface-based login, select Redfish. <p>SSH-based login is supported for all users by default.</p>
Current User Password	Enter the password of the currently logged-in user of the Web portal of the BMC.

- Click **Submit** to return to the **Local Users** page.
- In the **Operation** column, click **Edit** for the new user. The **Edit** page is displayed, as shown in [Figure 4-27](#).

Figure 4-27 Edit Page

7. Set the parameters. For a description of the parameters, refer to [Table 4-10](#).

Table 4-10 Parameter Descriptions for Editing a Local User

Parameter	Description
SNMPv3 Authentication Algorithm	Select an authentication algorithm. SHA256 , SHA384 , or SHA512 is recommended.
SNMPv3 Encryption Algorithm	Select an encryption algorithm. AES is recommended.
Current User Password	Enter the password of the currently logged-in user of the Web portal of the BMC.

8. Click **Submit**.

Chapter 5

System Management

Table of Contents

Querying System Information.....	63
Querying Performance Data.....	64
Querying Fan Information.....	67
Configuring the Heat Dissipation Policy.....	67
Querying Temperature KPIs.....	69
Managing Storage Devices.....	70
Configuring the Position Indicator of a Pass-Through Disk.....	73
Powering On/Off the Server.....	74
Configuring the Server Startup Policy.....	77
Configuring Power-On Delay Parameters.....	78
Configuring the High-Temperature Power-Off Strategy.....	79
Querying Power Supply Information.....	81
Configuring the Power Mode.....	82
Querying Power Statistics.....	84
Configuring Power Control Parameters.....	85
Querying Power KPIs.....	86
Configuring Boot Options.....	87
Configuring the Serial Port Output Mode.....	89

5.1 Querying System Information

Abstract

By querying system information, you can learn about the following information:

- CPU information
- Memory information
- Hard disk information
- NIC information, including Ethernet NIC and FC information
- FRU information
- Sensor information

- Other information, including GPU, PCIe card information, and hard disk backplane information.

Note

The operations for querying the above information are similar. This procedure uses how to query CPU information as an example.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **System Information**. The **System Information** page is displayed, see [Figure 5-1](#).

Figure 5-1 System Information Page

System Information												
<input checked="" type="checkbox"/> CPU Information <input type="checkbox"/> Memory Information <input type="checkbox"/> Disk Information <input type="checkbox"/> Network Adapter <input type="checkbox"/> FRU Information <input type="checkbox"/> Sensor <input type="checkbox"/> Other												
Details	No.	Name	Present Status	Health Status	Manufacturer	Model	TDP(Watts)	Frequency(MHz)	Maximum Frequency(MHz)	Cores	Threads	Architecture
▼	1	CPU 0	Present	● Healthy	Intel(R) Corporation	Intel(R) Xeon(R) Platinum 8470Q	350	2100	3800	52	104	x86
▼	2	CPU 1	Present	● Healthy	Intel(R) Corporation	Intel(R) Xeon(R) Platinum 8470Q	350	2100	3800	52	104	x86

Total 2 < 1 > 10 / Page To 1 Page

3. (Optional) To view the details of a CPU, click in the **Details** column for the CPU.

5.2 Querying Performance Data

Abstract

By querying performance data, you can learn about the following information:

- CPU usage
- Memory usage
- Disk usage
- Dynamic CPU load ratio: ratio of the currently used CPU resources to the total CPU resources of the server
- Dynamic memory load ratio: ratio of the currently used memory resources to the total memory resources of the server
- Dynamic I/O load ratio: ratio of the currently used I/O resources to the total I/O resources of the server


Note

The three types of performance data related to dynamic load ratio is displayed on the **CUPS** tab. The **CUPS** tab is displayed for a server whose CPU is supported by only the Intel platform.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Performance Monitoring**. The **Performance Monitoring** page is displayed, see [Figure 5-2](#).

Figure 5-2 Performance Monitoring Page



Note


The CPU usage, memory usage, and disk usage are displayed on the above page.

3. (Optional) Click **CUPS**. The **CUPS** tab is displayed, as shown in [Figure 5-3](#).

Note

The **CUPS** tab is displayed for a server whose CPU is supported by only the Intel platform.

Figure 5-3 CUPS Tab



 **Note**


The dynamic CPU, memory, and I/O load ratios are displayed on the above tab.

Related Tasks

To set the CPU usage, memory usage, and disk usage thresholds, perform the following operations:

1. On the **Performance Monitoring** page, click **Advanced Setting**. The **Set Alarm Threshold** dialog box is displayed, see [Figure 5-4](#).

Figure 5-4 Set Alarm Threshold Dialog Box



2. Set the alarm thresholds as required.
3. Click **Submit**.

5.3 Querying Fan Information

Abstract

By querying fan information, you can learn about the operational status and detailed information of each fan in the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Fan & Heat Dissipation**. The **Fan & Heat Dissipation** page is displayed, see [Figure 5-5](#).

Figure 5-5 Fan & Heat Dissipation Page

Fan & Heat Dissipation						
Fan Information		Heat Dissipation		Key Performance Indicator		
No.	Name	Type	Present	Speed(RPM)	Speed Ratio(%)	Health Status
1	FAN1	8038	Present	4591	30	● Normal
2	FAN2	8038	Present	4545	30	● Normal
3	FAN3	8038	Present	4610	30	● Normal
4	FAN4	8038	Present	4599	30	● Normal

Total 4 K < 1 > X 10 / Page To 1 Page

Note

- The **Speed(RPM)** column indicates the current speed of each fan.
- The **Speed Ratio(%)** column indicates the ratio of the current speed of each fan to its maximum speed.

5.4 Configuring the Heat Dissipation Policy

Abstract


A heat dissipation policy is configured in accordance with the environment where the server is held to ensure the performance and stability of the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Fan & Heat Dissipation**. The **Fan & Heat Dissipation** page is displayed.

3. Click **Heat Dissipation**. The **Heat Dissipation** tab is displayed, see [Figure 5-6](#).

Figure 5-6 Heat Dissipation Tab



4. Perform the following operations as required.

If...	Then...
There is space above the top surface of the server, and the server is insensitive to noise	Set Heat Dissipation to Auto and then set Select Mode to Balance .
Servers are stacked together, and there is no space between them	Set Heat Dissipation to Auto and then set Select Mode to Performance .
The server is placed in an office or other areas that are sensitive to noise	Set Heat Dissipation to Auto and then set Select Mode to Low Noise .
The fan speed needs to be set manually for the server	Set Heat Dissipation to Manual and then set Speed Ratio .

 **Note**

Speed Ratio indicates the ratio of the current speed of a fan to its maximum speed.

5. Click **Save**.

5.5 Querying Temperature KPIs

Abstract

Air inlet temperatures, air outlet temperatures, and CPU temperatures of a server are KPIs related to fans and heat dissipation of the server. By querying these KPIs, you can learn about heat dissipation during the operation of the server.



Note

The server supports the high-temperature power-off function. If this function is enabled, the server is powered off after the air inlet temperature reaches the preset threshold, avoiding damages to the server hardware. To ensure service operation stability, it is recommended to disable this function.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Fan & Heat Dissipation**. The **Fan & Heat Dissipation** page is displayed.
3. Click **Key Performance Indicator**. The **Key Performance Indicator** tab is displayed, as shown in [Figure 5-7](#).

Figure 5-7 Key Performance Indicator Tab



4. Select a granularity period for a query.



Note

The data on the tab is automatically refreshed after the granularity period is selected.

5. (Optional) To export data, click **Export**.

5.6 Managing Storage Devices

Abstract

The storage devices of a server refer to RAID controllers and hard disks.


The physical disks managed by a RAID controller can be created as logical disks.

On the **Storage Management** page, the **Storage Card** tab displays **SAS/SATA** disks, and the **NVMe** tab displays NVMe disks.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Storage Management**. The **Storage Management** page is displayed, see [Figure 5-8](#).

Figure 5-8 Storage Management Page



1. RAID controller
 2. Logical disk
 3. Physical disk
3. Perform the following operations as required.

To...	Do...
Check RAID controller and BBU information	On the Storage Card tab, click the desired RAID controller. The RAID controller and BBU information is displayed on the right.
Check logical disk information	On the Storage Card tab, click the desired logical disk. The detailed logical disk information is displayed on the right. In the logical disk information, Status includes: <ul style="list-style-type: none"> ● Optimal

To...	Do...
	<ul style="list-style-type: none"> ● Degraded ● Part Degraded ● Offline
Set the UID indicator of a logical disk	<ol style="list-style-type: none"> a. On the Storage Card tab, click the desired logical disk. b. Click Settings on the right. The Logical Drive Setting dialog box is displayed. c. Select Open or Close. <ul style="list-style-type: none"> ● Open: lights up the UID indicators of all member disks of the logical disk. ● Off: lights off the UID indicators of all member disks of the logical disk. d. Click Submit.
Check physical disk information	On the Storage Card tab, click the desired physical disk. The detailed physical disk information is displayed on the right.
Create a logical disk	<ol style="list-style-type: none"> a. On the Storage Card tab, click + next to a RAID controller. The Create Logical Drive area is displayed on the right, see Figure 5-9. b. Configure the following parameters: <ul style="list-style-type: none"> ● Logical disk name: Enter the name of the logical disk. ● RAID Level: Select the corresponding RAID level. ● Stripe Size: Select a stripe size. ● Physical Drive Configuration: Select the member disks that form the logical disk. c. Click Save.
Check NVMe disk information	On the Storage Management page, click NVMe to switch to the NVMe tab. The detailed NVMe disk information is displayed.

Figure 5-9 Create Logical Drive Area

Create Logical Drive

Logical disk name: test

RAID Level: RAID0

Strip Size: 1MiB

Physical Drive Configuration: 17-SSD-1920 × 22-SSD-1920 ×

Save Cancel

**Note**

Different types of RAID controllers have different pages for creating logical disks.

5.7 Configuring the Position Indicator of a Pass-Through Disk

Abstract

A pass-through disk refers to a hard disk in the server that is directly connected to a network or host through a hardware interface for data processing rather than a RAID controller or other intermediate devices.

The pass-through disks of the SATA interface type are displayed on the **Direct Harddisk** tab of the **Storage Management** page.

Setting the position indicator of a pass-through disk can help you to locate the pass-through hard disk easily.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Storage Management**. The **Storage Management** page is displayed.
3. Click **Direct Harddisk**. The **Direct Harddisk** tab is displayed, as shown in [Figure 5-10](#).

Figure 5-10 Direct Harddisk Tab

4. Click **Set** in the **Operation** column for a pass-through disk whose position indicator you want to turn on.

5.8 Powering On/Off the Server

Abstract

When you are not on the customer site, you can remotely control the server on the [PC](#) to power on or off the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed, see [Figure 5-11](#).

Figure 5-11 Power Page

3. In the **Host** area, check **Host Status**, and perform the following operations as required.

To...	Do...
Power on the server	Click Power On .
Power off the server	Click Normal Power Off . The prerequisite for selecting Normal Power Off to shut down the server is that When the Power Button is Pressed in the OS of the server is already set to Power Off . For details, refer to Related Tasks .
Forcibly power off the server	Click Forced Power Off .
Perform a warm reboot	Click Power Reset . Warm reboot means that the server is restarted when it is not shut down. During the restart, the server is not offline.
Perform a cold reboot	Click Power Cycle . Cold reboot means that the server is started after it is shut down. During the restart, the server is offline.

**Note**

The grayed button indicates the current power status of the server. For example, if the **Power On** button is grayed, the server is powered on.

Related Tasks

To set **When the Power Button is Pressed** to **Power Off**, perform the following operations:

**Note**


This procedure uses the Red Hat **OS** as an example. For other **OSs**, the operations are similar. If an **OS** does not have a GUI, you need to install the **ACPI** service.

1. Log in to the **OS** through **KVM**.
If the screen is locked, you need to enter the password to log in to the **OS**.
2. Click . The **Activities** screen is displayed, as shown in [Figure 5-12](#).

Figure 5-12 Activities Screen

3. Click **Settings**. The **Settings** screen is displayed, as shown in [Figure 5-13](#).

Figure 5-13 Settings Screen



4. Set **When the Power Button is Pressed** to **Power Off**.

5.9 Configuring the Server Startup Policy

Abstract

This procedure describes how to configure the server startup policy to specify the power status of the server after power is restored.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed, see [Figure 5-14](#).

Figure 5-14 Power Page

The screenshot shows the 'Power' page with the following sections:

- Host:** Host Status is 'Off'. Host Operation buttons include 'Power On', 'Normal Power Off', 'Forced Power Off', 'Power Reset', and 'Power Cycle'.
- Power Restore Policy Set (highlighted):** Power Restore Policy is set to 'Always-off' (selected), with options for 'Always-on' and 'Previous'. A 'Save' button is below.
- Power-On Delay:** Power-On Delay is enabled. Delay Strategy is set to 'Random(1~90s)'. A 'Save' button is below.
- High Temperature Power-off:** Enabling High-Temperature Power-Off is disabled. A 'Save' button is below.

- In the **Power Restore Policy Set** area, set the server startup policy after the power is restored.
 - **Always-off:** The server remains powered off after power is restored.
 - **Always-on:** The server is powered on automatically after power is restored.
 - **Previous:** The server goes back to the previous power status after power is restored.
- Click **Save**.

5.10 Configuring Power-On Delay Parameters


Abstract

This procedure describes how to configure power-on delay parameters to stagger the power-on of servers.

Steps

- Select **System**. The **System** page is displayed.
- From the navigation tree in the left pane, select **Power**. The **Power** page is displayed, see [Figure 5-15](#).

Figure 5-15 Power Page



3. Set the parameters in the **Power-On Delay** area. For a description of the parameters, refer to [Table 5-1](#).

Table 5-1 Power-On Delay Parameter Descriptions

Parameter	Setting
Power-On Delay	Select whether to enable the power-on delay function. <ul style="list-style-type: none"> ● To enable the power-on delay function, turn the switch on. ● To disable the power-on delay function, turn the switch off.
Delay Strategy	Select the corresponding power-on delay mode. <ul style="list-style-type: none"> ● Custom: The power-on delay time is user-defined. If Custom is selected, set Custom Delay Duration. Range: 1–120, unit: seconds. ● Random: The power-on delay time is automatically generated by the system.

4. Click **Save**.

5.11 Configuring the High-Temperature Power-Off Strategy

Abstract

If the high-temperature power-off strategy is enabled, when the air inlet temperature reaches the preset threshold, an alarm prompting server power-off is triggered. If the alarm is not

cleared within the preset power-off alarm duration (60 seconds by default), the server is automatically powered off for protection.

 **Note**

To ensure service operation stability, it is recommended to disable the high-temperature power-off strategy.

You can query and modify the high-temperature power-off alarm threshold and power-off alarm duration through [IPMI](#) commands.

Context

For the default high-temperature power-off alarm thresholds set for servers of different models, refer to [Table 5-2](#).


Table 5-2 High-Temperature Power-Off Alarm Thresholds

Server Model	Default Value
2240-RE	52 °C
2230-RE	52 °C
22G1-RE	52 °C
1240-RE	52 °C
4440-RE	47 °C

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed, as shown in [Figure 5-16](#).

Figure 5-16 Power Page



3. In the **High Temperature Power-off** area, set the parameters. For a description of the parameters, refer to [Table 5-3](#).

Table 5-3 High-Temperature Power-Off Parameter Descriptions

Parameter	Setting
Enabling High-Temperature Power-Off	<p>Sets whether to enable or disable the high-temperature power-off strategy.</p> <ul style="list-style-type: none"> ● If the Enabling High-Temperature Power-Off toggle switch is turned on, the high-temperature power-off strategy is enabled. ● If the Enabling High-Temperature Power-Off toggle switch is turned off, the high-temperature power-off strategy is disabled.

4. Click **Save**.

5.12 Querying Power Supply Information

Abstract

By querying power supply information, you can learn about the power supplies of the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed.

3. Click **Power Supply Information**. The **Power Supply Information** tab is displayed, see [Figure 5-17](#).

Figure 5-17 Power Supply Information Tab

Power

Power Control **Power Supply Information** Power Consumption Key Performance Indicator

Power Supply Information Power Mode Setting

Mainboard Power Supply

PSU1 Main Power Supply Normal

Present Status	Present
Input Mode	AC
Output Status	On
Manufacturer	Great Wall
Model	CRPS1600D2
Serial Number	22M010012057
Production Date	220108
Firmware Version	DC:1.04 PFC:1.01
Temperature Range(°C)	0~55
Current Temperature(°C)	41
Max Output Power(W)	1600
Current Input Power(W)	262
Current Output Power(W)	250
Current Input Voltage(V)	233
Current Output Voltage(V)	12.23

PSU2 Main Power Supply Normal

Present Status	Present
Input Mode	AC
Output Status	On
Manufacturer	Great Wall
Model	CRPS1600D2
Serial Number	22M010012059
Production Date	220108
Firmware Version	DC:1.04 PFC:1.01
Temperature Range(°C)	0~55
Current Temperature(°C)	35
Max Output Power(W)	1600
Current Input Power(W)	291
Current Output Power(W)	272
Current Input Voltage(V)	235
Current Output Voltage(V)	12.23

Note

The power supply input modes include: [AC](#), [HVDC](#) and [LVDC](#).
 For the R6900 G5 model, **Power Supply Information** also includes the power supply information about the [GPU](#) module.

5.13 Configuring the Power Mode

Abstract

The server power modes include:

- **Load Balancing:** The power modules supply power in load-balancing mode.


- **Active/Standby:** The power modules supply power in active/standby mode.

A proper power mode enables the power modules to supply power to the server in a reasonable manner.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed.
3. Click **Power Supply Information**. The **Power Supply Information** tab is displayed.
4. Click **Power Mode Setting**. The **Power Mode Setting** tab is displayed, see [Figure 5-18](#).

Figure 5-18 Power Mode Setting Tab



Note

For the R6900 G5 model, **Power Mode Setting** also includes power mode setting for the GPU module.

5. Select a power mode.

Note

The **Active/Standby** mode can be selected only when two or more power modules are present and in **Normal** state.

6. Click **Save**.

5.14 Querying Power Statistics


Abstract

By querying power statistics, you can learn about the current power status of the server and the power changes within the specified time period.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed.
3. Click **Power Consumption**. The **Power Consumption** tab is displayed, see [Figure 5-19](#).

Figure 5-19 Power Consumption Tab



Note

- The current power statistics of the server are displayed in the **Power Status** area.
- The historical power statistics of the server are displayed in the **Power History** area. You can specify a time range to query the corresponding power statistics.

5.15 Configuring Power Control Parameters

Abstract

The power control parameters include:

- **Power Capping:** The server power is limited to the power cap.
- **Power Threshold:** An alarm is raised when the server power exceeds the threshold.

This procedure describes how to configure the power control parameters.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed.
3. Click **Power Consumption**. The **Power Consumption** tab is displayed.
4. Click **System Power Control**. The **System Power Control** tab is displayed, see [Figure 5-20](#).

Figure 5-20 System Power Control Tab

The screenshot shows the 'Power' configuration page with the 'Power Consumption' tab selected. Under the 'System Power Control' sub-tab, there are two sections: 'Power Capping' and 'Power Threshold'. Each section has a toggle switch, a text input field for a value (both set to 500), a unit dropdown (both set to 'W'), and a 'Save' button.

Section	Toggle	Value	Unit	Action
Power Capping	<input type="checkbox"/>	500	W	Save
Power Threshold	<input type="checkbox"/>	500	W	Save

5. Perform the following operations as required.

To...	Do...
Set the power cap	<ol style="list-style-type: none"> In the Power Capping area, turn on the Power Capping switch. In the Power Cap Value text box, set the power cap (range: 1–32767, unit: W). Click Save.
Set the power threshold	<ol style="list-style-type: none"> In the Power Threshold area, turn on the Power Threshold switch. In the Power Threshold Value text box, enter the power threshold (range: 5–32767, unit: W). Click Save.

5.16 Querying Power KPIs


Abstract

Input voltage and output voltage of a server are **KPIs** related to power modules and energy consumption of the server. By querying these KPIs, you can learn about power supply during the operation of the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **Power**. The **Power** page is displayed.
3. Click **Key Performance Indicator**. The **Key Performance Indicator** tab is displayed, as shown in [Figure 5-21](#).

Figure 5-21 Key Performance Indicator Tab



4. Select a granularity period for a query.



Note

The data on the tab is automatically refreshed after the granularity period is selected.

5. (Optional) To export data, click **Export**.

5.17 Configuring Boot Options


Abstract

This procedure describes how to configure the boot device, boot mode, and boot option effectiveness for the server.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **System Settings**. The **System Settings** page is displayed, see [Figure 5-22](#).

Figure 5-22 System Settings Page



3. Set the parameters. For a description of the parameters, refer to [Table 5-4](#).

Table 5-4 Boot Option Parameter Descriptions

Parameter	Setting
Boot Medium	<p>Select the device used to boot the server.</p> <ul style="list-style-type: none"> ● No Override: configures no boot device and uses the default boot device configured in the BIOS. ● Hard Drive: forcibly boots from a hard drive. ● PXE: forcibly boots from the PXE. ● CD/DVD: forcibly boots from the CD-ROM or DVD-ROM drive. ● BIOS Setup: enters the BIOS menu after the server is booted. ● FDD/Removable Device: forcibly boots from a floppy drive or removable device (for example, USB).
Parameter	Setting
Boot Mode	<p>Select a server boot mode.</p> <ul style="list-style-type: none"> ● No Override: No server boot mode is set. The default server boot mode set in BIOS prevails. ● Legacy: a traditional boot mode with certain limitations, which supports the PXE boot only through a CPU-connected NIC. ● UEFI: a newer boot mode, which supports the PXE function in an IPv6/IPv4 network and provides the UEFI Shell environment. <p>UEFI mode is recommended.</p>

Effective	<p>Select whether the reconfigured server boot options are applied to the current restart only.</p> <ul style="list-style-type: none"> ● One-time: only effective for the current restart. ● Permanent: permanently effective.
-----------	--

4. Click **Save**.

5.18 Configuring the Serial Port Output Mode

Abstract

In common cases, the serial port output modes on the panel include:

- **COM0**: The recorded information in the **BIOS** phase is output, which can be configured in the BIOS.
- **COM1**: There is no output in the BIOS phase and the system hot key cannot be responded. The recorded information in the **OS** phase is output.



Note

The servers of the HG4 model supports only COM0 mode.

For servers of the ARM model (such as, R5310 G3), the serial port output modes of CPUs in different power-on phases of a host are different and include UEFI/OS, ATF, CPU0SCP0, and CPU1SCP0.




Note

This procedure uses a server of non-ARM model as an example.

Steps

1. Select **System**. The **System** page is displayed.
2. From the navigation tree in the left pane, select **System Settings**. The **System Settings** page is displayed.
3. Click **Board Panel Uart Config**. The **Board Panel Uart Config** tab is displayed, see [Figure 5-23](#).

4. **Figure 5-23 Board Panel Uart Config Tab**



The screenshot shows a web interface for 'System Settings'. There are two tabs: 'Boot Options' and 'Board Panel Uart Config', with the latter being the active tab. Under the 'Board Panel Uart Config' tab, there is a 'Uart Mode' section with two radio button options: 'COM0' (which is selected) and 'COM1'. A blue 'Save' button is located at the bottom right of the configuration area.

5. Select a serial port output mode.
6. Click **Save**.

Chapter 6

Diagnosis and Maintenance

Table of Contents

Querying Alarms.....	91
Alarm Reporting Parameter Configuration.....	92
Configuring Screen Recording Parameters.....	99
Viewing Recorded Videos.....	101
Taking a Screenshot.....	102
Viewing POST Codes.....	103
Downloading Server Logs.....	104
Querying BMC Logs.....	105
Querying SEL Logs.....	106
Querying Memory Health Scores.....	107

6.1 Querying Alarms

Abstract

By querying alarms, you can learn about the active alarms and system events of the server. System events include notifications and cleared alarms.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Alarm & Event**. The **Alarm & Event** page is displayed, see [Figure 6-1](#).

Figure 6-1 Alarm & Event Page

No.	Severity	Alarm Name	Description	Generation Time	Object Type	Position	Event Code	Handling Suggestions
4	Critical	Hard disk RAID array is offline	Raid Card(RM243B(Embedded1)) logical driver(id:1, name:54645) is offline assert.	2023-05-24 22:16:56	Disk	LD_1	0x1a000083	Details
3	Major	Hard disk is missing	Disk19 is missing(SN:unknown).	2023-05-23 16:48:55	Disk	DISK_19	0x1a000016	Details
2	Critical	Hard disk RAID array is offline	Raid Card(RM243B(Embedded1)) logical driver(id:0, name:iosredhat75) is offline assert.	2023-05-23 16:38:36	Disk	LD_0	0x1a000083	Details
1	Minor	Redundancy Lost	PS_Redundant Redundancy Lost assert.	2023-05-23 16:37:18	PSU	PSU_0	0x0a0b0801	Details

3. Perform the following operations as required.

To...	Do...
Query alarms by keyword	In the Search box, enter a keyword.
Query alarms based on the advanced parameters	<ol style="list-style-type: none"> Click Advanced Query. Advanced query conditions are displayed. Set the query parameters. Click Query.
View the handling suggestions for an alarm	Click Details for the alarm.
Save alarm information to the local PC	Click Download Alarms .
Query system events	Click System Events . The System Events tab is displayed.

6.2 Alarm Reporting Parameter Configuration

Alarms can be reported in the following ways:

- Reported through trap packets
For how to configure trap notification parameters, refer to [6.2.1 Configuring Trap Notification Parameters](#).
- Reported through syslog packets
For how to configure syslog notification parameters, refer to [6.2.2 Configuring Syslog Notification Parameters](#).
- Reported through emails
For how to configure email notification parameters, refer to [6.2.3 Configuring Email Notification Parameters](#).

6.2.1 Configuring Trap Notification Parameters

Abstract

Trap notification parameters are used by the **BMC** to report alarms to a third-party **NMS** through traps.



Note

Trap notification parameters are provided by the third-party NMS, so the values of trap notification parameters set on the Web portal of the BMC must be the same as those on the third-party NMS.

Abstract

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Alarm Settings**. The **Alarm Settings** page is displayed, see [Figure 6-2](#).

Figure 6-2 Alarm Settings Page

Alarm Settings

Trap Notification Syslog Notification Email Notification

Trap Function

Trap

Trap Version: V2C

Select V3 User: Administrator

Community Name: public

Confirm Community Name: public

Trap Host ID: Host Name

Event Sending Level: Critical

[Save](#)

Trap Server Configuration

No.	Server Address	Trap Port	Current Status	Operation
1	10.239.212.117	323	Disabled	Edit Test
2	10.230.19.204	162	Enabled	Edit Test
3	10.239.211.53	53	Enabled	Edit Test
4	10.239.166.158	162	Enabled	Edit Test

3. Set the parameters in the **Trap Function** area. For a description of the parameters, refer to [Table 6-1](#).

Table 6-1 Trap Function Parameter Descriptions

Parameter	Setting
Trap	Turn on the Trap switch.
Trap Version	Select the SNMP version for traps. Options: V1 , V2C , and V1 .
Parameter	Setting
Select V3 User	This parameter is required if Trap Version is set to V3 . Select a user that has permission to send alarms through SNMP. For how to create an SNMP user, refer to “ 4.16 Creating an SNMP User ”.
Community Name	This parameter is required if Trap Version is set to V1 or V2C . Enter the trap community name.
Confirm Community Name	This parameter is required if Trap Version is set to V1 or V2C . Enter the trap community name.
Trap Host ID	Select the identifier of the host that reports alarms.
Event Sending Level	Select the level of events to be reported. For example, if Event Sending Level is set to Critical , only critical alarms are reported.

- Click **Save**.
- Set the parameters in the **Trap Server Configuration** area. For a description of the parameters, refer to [Table 6-2](#).

Table 6-2 Parameter Descriptions for Trap Server Configuration

Parameter	Setting
Server Address	After you click Edit , the parameter is activated. Enter the address of the server that receives alarms. An IPv4 address, IPv6 address, or domain name is supported.
Trap Port	After you click Edit , the parameter is activated. Enter the port number of the server that receives alarms. Range: 1–65535.
Current Status	After you click Edit , the parameter is activated. Select whether to enable the current server to receive alarms.

6. Click **Save**.



After the **Edit** button is clicked, it is changed to the **Save** button.

7. (Optional) To send a test event to the server, click **Test**.



If a message indicating "sent successfully" is displayed on the page, the trap is sent successfully.

6.2.2 Configuring Syslog Notification Parameters

Abstract

This procedure describes how to configure syslog notification parameters so that the **BMC** can send logs to the syslog server. The sent logs include:

- **Operation Log**: records the information about users' operations on hardware devices, including manual operations and remote operations.
- **Audit Log**: records users' login to and logout of the Web portal of the **BMC**, **BMC**, and **KVM**.
- **Event Log**: records log and alarm information generated during the operation of the server.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Alarm Settings**. The **Alarm Settings** page is displayed.
3. Click **Syslog Notification**. The **Syslog Notification** tab is displayed, see [Figure 6-3](#).

Figure 6-3 Syslog Notification Tab

4. Set the parameters in the **Syslog Function** area. For a description of the parameters, refer to [Table 6-3](#).

Table 6-3 Syslog Function Parameter Descriptions

Parameter	Setting
Syslog	Turn on the Syslog switch.
Syslog Server Identity	Select the identifier of the syslog server to which logs are sent.
Transport Protocol	Select a log transmission protocol.
Parameter	Setting
Authentication Mode	<p>When Transport Protocol is set to TLS, this parameter should be configured.</p> <p>You can select unidirectional authentication or two-way authentication for TLS.</p> <ul style="list-style-type: none"> ● Unidirectional Authentication: The server sends a certificate to the Syslog server for unidirectional authentication. ● Two-way Authentication: The server and the Syslog server exchange certificates mutually for two-way authentication.
Upload certificate	<p>When Transport Protocol is set to TLS, this parameter should be configured.</p> <p>Click the corresponding certificate button and upload the certificate.</p>

5. Click **Save**.

- Set the parameters in the **Syslog Server Configuration** area. For a description of the parameters, refer to [Table 6-4](#).

Table 6-4 Syslog Server Parameter Descriptions

Parameter	Setting
Server Address	After you click Edit , the parameter is activated. Enter the address of the syslog server. An IPv4 address, IPv6 address, or domain name is supported.
Port	After you click Edit , the parameter is activated. Enter the port number of the syslog server. Range: 1–65535, default: 514.
Log Type	After you click Edit , the parameter is activated. Select one or more log types.
Current Status	After you click Edit , the parameter is activated. Select whether to enable the current syslog server to receive logs.

- Click **Save**.



Note

After the **Edit** button is clicked, it is changed to the **Save** button.

- (Optional) To send a test log to the syslog server, click **Test**.



Note

If a message indicating "sent successfully" is displayed on the page, the test log is sent successfully.

6.2.3 Configuring Email Notification Parameters

Abstract

This procedure describes how to configure email notification parameters so that the [BMC](#) can send emails to the specified mailbox.

Prerequisite

An [SMTP](#) server is already deployed. For details, refer to [4.10 Configuring an SMTP Server](#).

Abstract

- Select **Maintenance**. The **Maintenance** page is displayed.

2. From the navigation tree in the left pane, select **Alarm Settings**. The **Alarm Settings** page is displayed.
3. Click **Email Notification**. The **Email Notification** tab is displayed, see [Figure 6-4](#).

Figure 6-4 Email Notification Tab

No.	Mailing Address	Description	Current Status	Operation
1	test@vantageo.com	test	Enabled	Edit Test
2	test01@vantageo.com	123456789	Enabled	Edit Test
3				Edit Test
4				Edit Test

4. Set the parameters in the **SMTP Function** area. For a description of the parameters, refer to [Table 6-5](#).

Table 6-5 SMTP Function Parameter Descriptions

Parameter	Setting
SMTP	Turn on the SMTP switch.
Parameter	Setting
SMTP Server Address	Enter the IP address of the SMTP server in IPv4 or IPv6 format.
SMTP Server Port	Enter the port number of the SMTP server. Range: 1–65535, default: 25.
TLS	Select whether to enable the encryption function.
Use Anonymous	Select whether emails are sent anonymously.
Sender User Name	Required if the Use Anonymous switch is turned off. Enter the username for SMTP authentication.

Sender Password	Required if the Use Anonymous switch is turned off. Enter the password of the email sender.
Sender Email Address	Enter the email address of the sender.
Message Subject	Enter the subject of alarm emails.
Subject Attached	Select the information to be attached to the email subject. One or more options can be selected.

- Click **Save**.
- Set the parameters in the **Email Address For Receiving Alarm** area. For a description of the parameters, refer to [Table 6-6](#).

Table 6-6 Mailbox Address Parameter Descriptions

Parameter	Setting
Mailing Address	After you click Edit , the parameter is activated. Enter the email address to which alarms are sent.
Description	After you click Edit , the parameter is activated. Enter the description of the email address.
Current Status	After you click Edit , the parameter is activated. Select whether to enable the current email address to receive alarms.

- Click **Save**.



Note

After the **Edit** button is clicked, it is changed to the **Save** button.

- (Optional) To send a test alarm email to the email address, click **Test**.



Note

If a message indicating "sent successfully" is displayed on the page, the alarm email is sent successfully.

6.3 Configuring Screen Recording Parameters

Abstract

By configuring screen recording parameters, you can specify the events that trigger screen recording and the recording duration.

The recorded videos can be viewed on the **Screenshot&Video** page.

Prerequisite

Before enabling the screen recording function, you need to enable the KVM service. For details, refer to "[7.3 Configuring KVM Service Parameters](#)".


Note

The launch of a KVM or [VNC](#) session temporarily disables recording. After the KVM or VNC session is closed, recording is automatically resumed.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Screenshot&Video**. The **Screenshot&Video** page is displayed, as shown in [Figure 6-5](#).

Figure 6-5 Screenshot&Video Page



3. Click **Configuration** in the upper right corner. The **Video recording function configuration** dialog box is displayed, as shown in [Figure 6-6](#).

Figure 6-6 Video Recording Function Configuration Dialog Box

4. Set the parameters. For a description of the parameters, refer to [Table 6-7](#).

Table 6-7 Parameter Descriptions for the Screen Recording Function

Parameter	Description
Video recording function enabling	Turn on the toggle switch.
Recording time	Enter the screen recording duration. Options: 10, 20, 30, 40, 50, and 60. Unit: seconds.
Video type	Select the events that trigger screen recording.

5. Click **Submit**.

6.4 Viewing Recorded Videos

Abstract

After the screen recording function is enabled, the system automatically records the screen in accordance with the configured recording parameters before the server crashes, restarts, or powers off. You can view the recorded videos for fault diagnosis.

Prerequisite


The screen recording function is enabled. For details, refer to "[6.3 Configuring Screen Recording Parameters](#)".

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.

- From the navigation tree in the left pane, select **Screenshot&Video**. The **Screenshot&Video** page is displayed, as shown in [Figure 6-7](#).

Figure 6-7 Screenshot&Video Page



Note

The **Video playback** area displays the latest three recorded videos.

- Click  to play a recorded video.

6.5 Taking a Screenshot

Abstract

The screenshot function is used for fault diagnosis.



Note

Before using the screenshot function, you must disable the **KVM** function.

Screenshots can be taken in the following ways:

- Automatic
 - Automatic screenshot is triggered when one of the following conditions is met:
 - The server is restarted after a fatal error (for example, a **CPU** fault) occurs.
 - The **BMC** triggers **Power Reset**.
 - The **BMC** triggers **Power Cycle**.
 - The **BMC** triggers **Forced Power Off**.


For a description of the power operations that can be triggered by the BMC, refer to [5.8 Powering On/Off the Server](#).

- Manual

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Screenshot&Video**. The **Screenshot&Video** page is displayed, see [Figure 6-8](#).

Figure 6-8 Screenshot&Video Page



3. Perform the following operations as required.

To...	Do...
Take screenshots automatically	Turn on the Last Screen switch.
Take a screenshot manually	Click Screenshot . The screenshot of the current screen is displayed at the bottom of the page. To delete the current screenshot, click Delete .

6.6 Viewing POST Codes


Abstract

The **POST** code records the status of the server during power-on.
Check the POST code for fault diagnosis.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **POST Code**. The **POST Code** page is displayed, see [Figure 6-9](#).

Figure 6-9 POST Code Page



3. (Optional) If the POST code is not enabled, open **POST Code** and click **Save**.
4. View **Server Power Status**, **Current POST Code**, and **Last POST Code**.

6.7 Downloading Server Logs


Abstract

When a fault occurs, the server logs are written to the serial port. You can download these logs for fault diagnosis.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Host Logs**. The **Host Logs** page is displayed, see [Figure 6-10](#).

Figure 6-10 Host Log Page



3. Click **Download**.

6.8 Querying BMC Logs

Abstract


BMC logs include:

- **Operation Logs:** record the information about users' operations on the server, including manual operations and remote operations.
- **Audit Logs:** record users' login to and logout of the Web portal of the BMC, BMC, and **KVM**.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **BMC Logs**. The **BMC Logs** page is displayed, see [Figure 6-11](#).

Figure 6-11 BMC Logs Page



3. Perform the following operations as required.

To...	Do...
Query operation logs	a. Click Operation Logs to switch to the Operation Logs tab. b. (Optional) In the Search box, enter a keyword. c. (Optional) Click Download Logs .
Query audit logs	a. Click Audit Logs to switch to the Audit Logs tab. b. (Optional) In the Search box, enter a keyword. c. (Optional) Click Download Logs .

6.9 Querying SEL Logs

Abstract

The **SEL** logs record event logs reported by sensors in the server system.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **SEL Logs**. The **SEL Logs** page is displayed, see [Figure 6-12](#).

Figure 6-12 SEL Logs Page

Event ID	Generation Time	Sensor Name	Sensor Type	Description	Status
67	2023-07-20 09:21:53	BMC_BOOT_UP	System Boot/Restart Initiated	Initiated by hard reset	Asserted
66	2023-07-20 09:21:53	ACPI_STATUS	System ACPI Power State	S0/G0 'working'	Asserted
65	2023-07-20 09:20:14	System	Version Change	Software or F/W Change detected with associated Entity was successful.(deassertion event means 'unsuccessful')	Asserted
64	2023-07-20 09:19:00	System	Version Change	Firmware or software change detected with associated Entity,Informational. Success or failure not implied	Asserted
63	2023-07-19 15:59:50	SYS_RESTART	System Boot/Restart Initiated	Initiated by warm reset	Asserted
62	2023-07-19 15:59:48	ACPI_STATUS	System ACPI Power State	S0/G0 'working'	Asserted
61	2023-07-19 15:59:41	OS_STOP	OS Stop / Shutdown	OS Graceful Shutdown	Asserted
60	2023-07-19 15:59:41	ACPI_STATUS	System ACPI Power State	S5/G2 'soft-off'	Asserted
59	2023-07-19 15:57:30	ACPI_STATUS	System ACPI Power State	S0/G0 'working'	Asserted
58	2023-07-19 15:57:23	OS_STOP	OS Stop / Shutdown	OS Graceful Shutdown	Asserted

3. (Optional) Click **Advanced Query**, set the query conditions, and click **Query**.
4. Perform the following operations as required.

To...	Do...
Download SEL Logs	Click Download SEL Logs .

Clear SEL Logs

Click **Clear SEL Logs**.

6.10 Querying Memory Health Scores

Abstract

You can query memory health scores through the memory fault prediction function to learn about the operational status of memory.



Note

The memory fault prediction function is disabled by default. To enable this function, run the corresponding [IPMI](#) commands.

Steps

1. Select **Maintenance**. The **Maintenance** page is displayed.
2. From the navigation tree in the left pane, select **Memory Fault Prediction**. The **Memory Fault Prediction** page is displayed, as shown in [Figure 6-13](#).

Figure 6-13 Memory Fault Prediction Page

Memory Index	CPU Slot Number	Controller Number	Channel Number	Slot	Slot Identification	SN Number	Health Score
 No data.							

Total 0 K < 1 > X 10 / Page To 1 Page

3. Check memory health scores.

Chapter 7

Service Management

Table of Contents

Configuring Port Service Parameters.....	108
Configuring Web Service Parameters.....	110
Configuring KVM Service Parameters.....	112
Starting the KVM.....	114
Configuring Virtual Media Parameters.....	122
Mounting a Virtual Media Device.....	124
Configuring VNC Parameters.....	125
Configuring SNMP Parameters.....	127

7.1 Configuring Port Service Parameters

Abstract

By configuring port service parameters, you can configure the status, secure port, non-secure port, and timeout period of each service of the [BMC](#).

The parameters configured on the **Port Services** page are synchronized with the parameters configured on the following pages:

- **Web Services** page
- **Virtual Console** page
- **Virtual Media** page
- **VNC** page
- **SNMP** page

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Port Services**. The **Port Services** page is displayed, see [Figure 7-1](#).

Figure 7-1 Port Services Page

Port Services							
No.	Name	Status	Non Secure Port	Secure Port	Timeout(Min)	Maximum Sessions	Operation
1	web	Open	80	443	30	20	Edit
2	kvm	Open	7578	7582	30	4	Edit
3	cd-media	Open	5120	5124	--	1	Edit
4	hd-media	Open	5123	5127	--	1	Edit
5	ssh	Open	--	22	10	--	Edit
6	vnc	Open	5900	5901	10	2	Edit
7	snmp	Open	161	--	--	--	Edit
8	redfish	Open	--	--	--	--	Edit
9	ipmi	Open	--	623	--	--	

3. Click **Edit** for a service to activate the parameters.
4. Set the parameters. For a description of the parameters, refer to [Table 7-1](#).

Table 7-1 Port Service Parameter Descriptions

Parameter	Setting
Status	Select whether to enable a service.
Non Secure Port	<p>Enter the non-secure port number of the service.</p> <ul style="list-style-type: none"> ● Default non-secure port number of the Web service: 80. ● Default non-secure port number of the KVM service: 7578. ● Default non-secure port number of the CD media service: 5120. ● Default non-secure port number of the HD media service: 5123. ● Default non-secure port number of the VNC service: 5900. ● Default non-secure port number of the SNMP service: 161. <p>Other services do not support non-secure ports. Range of the non-secure port numbers: 1–65535.</p>
Secure Port	<p>Enter the secure port number of the service.</p> <ul style="list-style-type: none"> ● Default secure port number of the Web service: 443. ● Default secure port number of the KVM service: 7582. ● Default secure port number of the CD media service: 5124. ● Default secure port number of the HD media service: 5127. ● Default secure port number of the SSH service: 22. ● Default secure port number of the VNC service: 5901. ● Default secure port number of the IPMI service: 623. <p>Other services do not support secure ports. Range of the secure port numbers: 1–65535.</p>
Timeout(Min)	<p>Timeout period after which the service exits if no operation is performed. Enter the timeout period (in minutes). Range: 5–60 (for the VNC service) or 1–60 (for other services).</p>



You cannot configure the **Maximum Sessions** parameter.

5. Click **Save**.

7.2 Configuring Web Service Parameters

Abstract

By configuring the Web service parameters, you can securely access the Web portal of the [BMC](#) through the local PC.

To configure the Web service parameters, perform the following operations:

1. Configuring basic parameters
2. Uploading the [SSL](#) certificate to the browser
3. Uploading the SSL certificate to the Web portal of the BMC

Prerequisite

The *.pem* file (containing the certificate file and private key file) is already obtained.

Steps

Configuring Basic Parameters

1. On the Web portal of the BMC, select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Web Services**. The **Web Services** page is displayed, see [Figure 7-2](#).

Figure 7-2 Web Services Page

- Set the parameters. For a description of the parameters, refer to [Table 7-2](#).

Table 7-2 Basic Parameter Descriptions

Parameter	Setting
HTTP	Turn on the HTTP switch.
HTTP Port	Enter the non-secure port number of the Web service. Range: 1–65535, default: 80.
HTTPS	Turn on the HTTPS switch.
HTTPS Port	Enter the secure port number of the Web service. Range: 1–65535, default: 443.
Timeout Period	The Web service exits if no operation is performed within the specified timeout period. Enter the timeout period. Range: 1–60, unit: minutes.

Uploading the SSL Certificate to the Browser

- On the **Settings** page of the browser (for example, Google Chrome) on the PC, select **Privacy and security**. The **Privacy and security** page is displayed.
-  Click on the right of **Manage certificates** and upload the SSL certificate.

Uploading the SSL Certificate to the Web Portal of the BMC

- On the **Web Services** page on the Web portal of the BMC, click **Upload SSL**. The **Upload SSL** dialog box is displayed, see [Figure 7-3](#).

Figure 7-3 Upload SSL Dialog Box

Upload SSL

Current Certificate: Fri Dec 31 16:00:02 1999

New Certificate:

Current Private Key: Fri Dec 31 16:00:02 1999

New Private Key:

- Select the prepared certificate file and private key file.
- Click **Submit**.

Verification

In the address bar of your browser, enter the address of the Web portal of the BMC, and press **Enter** to see if the login page is displayed directly and there is no "Not secure" warning displayed, see [Figure 7-4](#).

Figure 7-4 Secure Access



[Figure 7-5](#) shows the "Not secure" warning displayed in the address bar of the browser.

Figure 7-5 Insecure Access



7.3 Configuring KVM Service Parameters

Abstract

Before starting the **KVM**, you need to configure the KVM service parameters.

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Virtual Console**. The **Virtual Console** page is displayed, see [Figure 7-6](#).

Figure 7-6 Virtual Console Page

The screenshot shows the 'Virtual Console' configuration page. At the top, there is a 'Start KVM' section with two buttons: 'HTML Virtual Console' and 'Java Virtual Console'. Below this is the 'Session Settings' section, which includes:

- 'Communication Encryption' with a toggle switch turned off.
- 'Single Port' with a toggle switch turned off.
- 'Retry Times' with a text input field containing the number '3'.
- 'Retry Interval' with a text input field containing '10' and a unit selector dropdown set to 's'.

 A blue 'Save' button is located at the bottom center of the settings area.

3. Set the parameters in the **Session Settings** area. For a description of the parameters, refer to [Table 7-3](#).

Table 7-3 Session Setting Parameter Descriptions

Parameter	Setting
Communication Encryption	Select whether to encrypt KVM communication.
Single Port	Select whether to use port 443 in a unified manner when the KVM is started in HTML mode. <ul style="list-style-type: none"> ● If the Single Port switch is turned on, port 443 is used in a unified manner. ● If the Single Port switch is turned off, port 443 is not used in a unified manner.
Retry Times	Enter the number of session retries. Range: 1–20.
Retry Interval	Enter the session retry interval. Range: 5–30, unit: seconds.

4. Click **Save**.

7.4 Starting the KVM

Abstract

When you are not on the customer site, you can start the [KVM](#) to remotely control the server.

Prerequisite

If the KVM needs to be started in Java mode, [JRE 8](#) or a later version (for example, `jre-8u191`) is already installed on the PC.

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Virtual Console**. The **Virtual Console** page is displayed, see [Figure 7-7](#).

Figure 7-7 Virtual Console Page

3. Perform the following operations as required.

To...	Do...
Start the KVM in HTML mode	<ol style="list-style-type: none"> a. Click HTML Virtual Console. The Remote KVM (HTML) page is displayed, see Figure 7-8. b. Perform the following operations as required. For a description of the operations, refer to Table 7-4.

To...	Do...
<p>Start the KVM in Java mode</p>	<ol style="list-style-type: none"> a. In the search box in the lower left corner of the PC, enter <i>Java</i>. b. In the search result, select Java. The Java Control Panel dialog box is displayed. c. Click Security. The Security window is displayed. d. Click Edit Site List. The Exception Site List dialog box is displayed. e. Click Add to add the address of the Web portal of the BMC. f. Click OK to return to the Security window. g. Click OK. h. On the Virtual Console page of the Web portal of the BMC, click Java Virtual Console. A dialog box indicating whether to keep <i>jviewer.jnlp</i> is displayed. i. Click Keep. j. In the lower left corner of the browser, click <i>jviewer.jnlp</i>. A dialog box indicating whether to proceed is displayed. k. Click Continue. The Do you want to run this application? dialog box is displayed. l. Select I accept the risk and want to continue to run this app. and click Run. The Untrusted Connection dialog box is displayed. m. Click Yes. The Remote KVM (JAVA) page is displayed, see Figure 7-9. n. Perform the following operations as required. For a description of the operations, refer to Table 7-5.

 **Note**

Before starting the KVM in one mode, you must disable the KVM in another mode. For example, before starting the KVM in Java mode, you must disable the KVM started in HTML mode.

Figure 7-8 Remote KVM (HTML)




Table 7-4 Descriptions for the Remote KVM (HTML) Operations

Operation	Description
Stop the KVM	Click Stop KVM to exit the Remote KVM (HTML) page.
Mount a local <i>iso</i> file	<ol style="list-style-type: none"> a. Click Browse File next to CD Image, and select the <i>iso</i> file from the PC. b. Click Start Media.
Display the notifications received	Click  .
Lock the display of the server	<p>Lock the server display through either of the following ways:</p> <ul style="list-style-type: none"> ● Click . ● Select Video > Display OFF. <p>After the server display is locked, if another user wants to view a server screen, a permission request is sent to the current active user. The user can view the server screen only after being authorized by the current active user.</p>

Unlock the server display	Unlock the server display through either of the following ways: <ul style="list-style-type: none"> • Click  . • Select Video > Display ON.  is converted to .
---------------------------	--

Operation	Description
Pause a remote control screen	Select Video > Pause Video .
Resume a remote control screen	Select Video > Resume Video .
Refresh a remote control screen	Select Video > Refresh Video .
Capture the current screen	Select Video > Capture Screen .
Display or hide the mouse pointer on the server screens	<ul style="list-style-type: none"> • To display the mouse pointer on the server screens, click Mouse, and select Show Client Cursor. • To hide the mouse pointer on the server screens, click Mouse, and clear Show Client Cursor.
Set the mouse mode	Click Mouse , and select Absolute Mouse Mode . In absolute mouse mode, the absolute position of the local mouse is transferred to the server to make the mouse on the server move.
Set keyboard layout	a. Select Keyboard . b. In the displayed submenu, select the keyboard layout, including English U.S , German and Japanese . English U.S is selected by default.
Set video recording time length	a. Select Video Record > Record Settings . The Record Settings dialog box is displayed. b. Set the video recording time length with a range of 1–1800 seconds. c. Click OK .
Record videos	Select Video Record > Record Video .
Stop recording	Select Video Record > Stop Recording .
Shut down the server	Shut down the server through either of the following ways: <ul style="list-style-type: none"> • Select Power > Orderly shutdown. • Click  .

Start the server	<p>Start the server through either of the following ways:</p> <ul style="list-style-type: none"> • Select Power > Power On Server. • Click  .
Perform a cold reboot	<p>Select Power > Power Cycle Server.</p> <p>Cold reboot means that the server is started after it is shut down. During the restart, the server is offline.</p>
Perform a warm reboot	<p>Select Power > Reset Server.</p> <p>Warm reboot means that the server is restarted when it is not shut down. During the restart, the server is not offline.</p>
Operation	Description
View the users that are using remote control	Select Active Users .

Figure 7-9 Remote KVM (Java) Page




Table 7-5 Descriptions for the Remote KVM (JAVA) Operations

Operation	Description
Pause a remote control screen	<p>Pause a remote control screen through one of the following ways:</p> <ul style="list-style-type: none"> ● Select Video > Pause Redirection. ● Click  . ● Press Alt+P.
Resume a remote control screen	<p>Resume the remote control screen through one of the following ways:</p> <ul style="list-style-type: none"> ● Select Video > Resume Redirection. ● Click  . ● Press Alt+R.
Operation	Description
Refresh a remote control screen	<p>Refresh the remote control screen through either of the following ways:</p> <ul style="list-style-type: none"> ● Select Video > Refresh Video. ● Press Alt+E.
Switch the host screen display mode	<ul style="list-style-type: none"> ● To display the remote screen on the host, select Video > Turn ON Host Display. ● To not display the remote screen on the host, select Video > Turn OFF Host Display. <p>Note: You can use either of the following methods to rapidly switch between the remote screen display modes of the host.</p> <ul style="list-style-type: none"> ● Click  . ● Press Alt+N.
Capture the current screen	<p>Capture the current screen through either of the following ways:</p> <ul style="list-style-type: none"> ● Select Video > Capture Screen. ● Press Alt+S.
Set a video decoding mode	<ol style="list-style-type: none"> Select Video > Compression Mode. Select a video decoding mode from the displayed submenu.
Set the video display quality	<ol style="list-style-type: none"> Select Video > DCT Quantization Table. Select the video display quality from the displayed submenu. <p>The video display quality is divided into eight levels from 0 through 7, with video quality degraded in turn.</p>

Define a key combination	<ol style="list-style-type: none"> a. Select Keyboard > Hot Keys > add Hot Keys. The User Defined Macros page is displayed. b. Click add. The Add Macros page is displayed. c. Press and then release the user-defined key combination. d. Click OK.
Enable full keyboard support	<ul style="list-style-type: none"> ● To enable full keyboard support, click Keyboard, and select Full Keyboard Support. ● To disable full keyboard support, click Keyboard, and clear Full Keyboard Support.
Display or hide the mouse pointer	<ul style="list-style-type: none"> ● To display the mouse pointer, click Mouse, and select Show Client Cursor. ● To hide the mouse pointer, click Mouse, and clear Show Client Cursor. <p>You can use either of the following methods to rapidly change the mouse display modes on the PC.</p> <ul style="list-style-type: none"> ● Press Alt+C. ●  Click
Set the network bandwidth	<ol style="list-style-type: none"> a. Select Options > Bandwidth.

Operation	Description
	<ol style="list-style-type: none"> b. Select the desired network bandwidth from the displayed submenu.
Change the encryption status of the mouse/keyboard	<ul style="list-style-type: none"> ● To enable mouse/keyboard encryption, click Options, and select Keyboard/Mouse Encryption. ● To disable mouse/keyboard encryption, click Options, and clear Keyboard/Mouse Encryption.
Set the scaling mode of a remote screen	<ol style="list-style-type: none"> a. Select Options > Zoom. b. In the displayed submenu, set the zoom scale of the remote screen. <ul style="list-style-type: none"> ● Zoom In: zooms in the remote screen. ● Zoom Out: zooms out the remote screen. ● Actual Size: displays the remote screen in the proportion of 100%. ● Fit to Client Resolution: displays the remote screen in the resolution of the local client system. ● Fit to Host Resolution: displays the remote screen in the resolution of the remote server system.

Send an IPMI command to the server	<ol style="list-style-type: none"> Select Options > Send IPMI Command. The IPMI Command Dialog window is displayed. Enter the IPMI command. Click Send. The IPMI command supports hex format and ASCII format.
Set the GUI language	<ol style="list-style-type: none"> Select Options > GUI Languages. Select the GUI language from the displayed submenu.
Set the privilege request mode	<ol style="list-style-type: none"> Select Options > Block Privilege Request. Select a privilege request block mode from the displayed submenu. <ul style="list-style-type: none"> Allow only Video: The permission for viewing the information displayed on the server is automatically granted to the user who initiates a privilege request. Deny Access: Privilege requests in the system are blocked.
Mount a local <i>iso</i> file	<ol style="list-style-type: none"> Open the Virtual Media window in either of the following ways: <ul style="list-style-type: none"> Select Media > Virtual Media Wizard..., and switch to the CD/DVD tab. Click . Click Browse and select a local <i>iso</i> file. Click Connect.
Mount a local folder	<ol style="list-style-type: none"> Create an <i>iso</i> file on the PC. Open the Virtual Media window in either of the following ways: <ul style="list-style-type: none"> Select Media > Virtual Media Wizard..., and switch to the Hard Disk/USB tab. Click . Select physical drive > folder path.

Operation	Description
	<ol style="list-style-type: none"> Click Browse and select a local folder path. Set Size and folder path. Click Connect. The value of Size must be 2ⁿ, such as 2, 4 and 8. The path specified by folder path needs to be the same as that of the new <i>iso</i> file.
Set keyboard layout	<ol style="list-style-type: none"> Select Keyboard Layout. Select the keyboard layout from the displayed submenu.
Open the soft keyboard	Click  .

<p>Configure video recording</p>	<p>a. Select Video Record > Settings. The Video Record window is displayed.</p> <p>b. Set the video recording time length in seconds and the video storage position.</p> <p>c. Click OK.</p> <p>The video recording time length ranges from 1 through 1800 seconds.</p>
<p>Record videos</p>	<p>a. Start recording a video in either of the following ways:</p> <ul style="list-style-type: none"> ● Select Video Record > Start Record. ●  Click <p>b. (Optional) Stop recording a video in either of the following ways:</p> <ul style="list-style-type: none"> ● Select Video Record > Stop Record. ●  Click <p>c. After the preset recording time length is reached or the recording is stopped manually, click OK. The recorded video file is saved to the <i>VideoCaptures</i> folder in the preset path.</p>
<p>Set the server power mode</p>	<p>a. Select Power.</p> <p>b. Select a server power option from the displayed submenu. The server power options are as follows:</p> <ul style="list-style-type: none"> ● Reset Server: restarts the system without shutting down the power supply (warm reboot). ● Immediate Shutdown: shuts down the server immediately by shutting down the power supply. ● Orderly Shutdown: shuts down the server in order through program control. ● Power On Server: starts the server. ● Power Cycle Server: shuts down the server and restarts it (cold reboot).
<p>Check active users</p>	<p>Select Active Users to view the users using remote control.</p>

7.5 Configuring Virtual Media Parameters

Abstract

Before mounting a **CD/DVD** or **HD** of the PC to the server through the **KVM**, you must configure virtual media parameters.

Steps

1. Select **Services**. The **Services** page is displayed.

- From the navigation tree in the left pane, select **Virtual Media**. The **Virtual Media** page is displayed, see [Figure 7-10](#).

Figure 7-10 Virtual Media Page

- Set the parameters. For a description of the parameters, refer to [Table 7-6](#).

Table 7-6 Parameter Descriptions for VMedia Instance Settings

Parameter	Setting
CD/DVD Physical Device	Select the number of CD/DVD devices on the PC. Keep the default value 1 .
HD Physical Device	Select the number of HD devices on the PC. Keep the default value 1 .
Remote KVM CD/DVD Physical Device	Select the number of CD/DVD devices to be mounted through the KVM. The number cannot exceed the number of CD/DVD physical device. Keep the default value 1 .
Remote KVM HD Physical Device	Select the number of HD devices to be mounted through the KVM. The number cannot exceed the number of HD physical device.
Parameter	Setting
	Keep the default value 1 .
Media Redirection Encryption	Turn off the Media Redirection Encryption switch.

- Click **Save**.

7.6 Mounting a Virtual Media Device

Abstract

This procedure describes how to enable the virtual media function and remotely mount a virtual media device.

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **Virtual Media**. The **Virtual Media** page is displayed.
3. Click **Media Mounting**. The **Media Mounting** tab is displayed, as shown in [Figure 7-11](#).

Figure 7-11 Virtual Media Page—Media Mounting Tab

Start Media Type	Server Address	File Path	Shared File System	Username	Password	Status	Operation
CD/DVD	10.239.20.11	/home/mount_test/isocfg-tool-v1.iso	CIFS	test	****	Disabled	Start Mount
HD	10.239.20.11	/home/mount_test/isocfg-tool-v1.img	NFS			Disabled	Start Mount

4. Set the parameters. For a description of the parameters, refer to [Table 7-7](#).

Table 7-7 Parameter Descriptions for Mounting a Virtual Media Device

Parameter	Description
Virtual Media Enable	Turn on the toggle switch. If the Virtual Media Enable switch is turned off, the mounted virtual media devices are cleared.
Start Media Type	The number of virtual media devices in the Start Media Type column must be the same as that of the devices set in Remote KVM CD/DVD Physical Device and Remote KVM HD Physical Device on the Media Setting tab. For example, if Remote KVM CD/DVD Physical Device is set to 1, there is only one CD/DVD entry displayed in the Start Media Type column.
Parameter	Description
Server Address	Enter the IP address of the server that provides the remote image mounting service. Domain names are not supported.

File Path	<p>Enter the storage path of the image file on the remote server. A maximum of 256 characters can be entered. The name of each mounted image file must be unique.</p> <ul style="list-style-type: none"> ● If Start Media Type is CD/DVD, the suffix of the image filename must be <i>iso</i>. ● If Start Media Type is HD, the suffix of the image filename must be <i>img</i> or <i>ima</i>.
Shared File System	<p>Select a file system protocol for file sharing. Options: NFS, CIFS, and HTTPS.</p> <ul style="list-style-type: none"> ● If Start Media Type is CD/DVD, NFS, CIFS, and HTTPS are supported. ● If Start Media Type is HD, NFS and CIFS are supported.
Username	<p>Enter the username for logging in to the remote server. This parameter does not need to be set if Shared File System is set to NFS.</p>
Password	<p>Enter the password for logging in to the remote server. This parameter does not need to be set if Shared File System is set to NFS.</p>

5. In the **Operation** column, click **Start Mount** for the desired virtual media device.



Note

After the virtual media device is successfully mounted, its status in the **Status** column is changed to **Enabled**.

Related Tasks

To disable a mounted virtual media device, click **End Mount** in the **Operation** column for it.

7.7 Configuring VNC Parameters

Abstract

A server can be remotely controlled through the [KVM](#) and [VNC](#). Before remotely controlling the server in VNC mode, you must configure the VNC parameters.



Note

For KVM-related parameter configuration, refer to [7.3 Configuring KVM Service Parameters](#). For KVMbased remote server control operations, refer to [7.4 Starting the KVM](#).

Steps

1. Select **Services**. The **Services** page is displayed.

- From the navigation tree in the left pane, select **VNC**. The **VNC** page is displayed, see [Figure 7-12](#).

Figure 7-12 VNC Page

VNC

Secure Port: 5901

Non Secure Port: 5900

Timeout Period: 10 Min

Maximum Sessions: 2

Modify Password:

Password complexity check:

VNC Password:

Confirm VNC Password:

Save

- Set the parameters. For a description of the parameters, refer to [Table 7-8](#).

Table 7-8 VNC Parameter Descriptions

Parameter	Setting
Secure Port	Enter the secure port number of the VNC service. Range: 1–65535, default: 5901.
Non Secure Port	Enter the non-secure port number of the VNC service. Range: 1–65535, default: 5900.
Timeout Period	The VNC service exits if no operation is performed within the specified timeout period. Enter the timeout period. Range: 5–60, unit: minutes.
Modify Password	Whether to modify the VNC password. <ul style="list-style-type: none"> To modify the VNC password, turn on the Modify Password switch. To not modify the VNC password, turn off the Modify Password switch.
Parameter	Setting

Password complexity check	Whether to check the complexity of the VNC password. <ul style="list-style-type: none"> ● To check the complexity of the VNC password, turn on the Password complexity check switch. ● To not check the complexity of the VNC password, turn off the Password complexity check switch.
VNC Password	This parameter can be set when the Modify Password switch is turned on. Enter the new VNC password. The requirements for the VNC password are as follows: <ul style="list-style-type: none"> ● The password contains a maximum of eight characters. ● The password must contain at least one special character except spaces. ● The password must contain at least two of the following types: uppercase letters, lowercase letters, and digits. If the configuration is null, the default password is restored.
Confirm VNC Password	This parameter can be set when the Modify Password switch is turned on. Confirm the new VNC password, which must be the same as VNC Password .

4. Click **Save**.

7.8 Configuring SNMP Parameters

Abstract

This procedure describes how to configure **SNMP** parameters for communication between the **BMC** and a third-party NMS.



Note

SNMP parameters are provided by the third-party NMS, so the values of SNMP parameters set on the Web portal of the BMC must be the same as those on the third-party NMS.

Steps

1. Select **Services**. The **Services** page is displayed.
2. From the navigation tree in the left pane, select **SNMP**. The **SNMP** page is displayed, see [Figure 7-13](#).

Figure 7-13 SNMP Page

- Set the parameters. For a description of the parameters, refer to [Table 7-9](#).

Table 7-9 SNMP Parameter Descriptions

Parameter	Setting
SNMP	Turn on the SNMP switch.
Port	Enter the non-secure port number of the SNMP service. Range: 1–65535, default: 161.
Complex Password	Whether to enable the complex password function. <ul style="list-style-type: none"> To enable the complex password function, turn on the Complex Password switch. To disable the complex password function, turn off the Complex Password switch.

Edit Read-only Community	<p>Whether to edit the read-only community name.</p> <ul style="list-style-type: none"> ● To edit the read-only community name, turn on the Edit Read-only Community switch. ● To not edit the read-only community name, turn off the Edit Read-only Community switch.
Parameter	Setting
Read-only Community	<p>This parameter can be set when the Edit Read-only Community switch is turned on.</p> <p>Enter the read-only community name (default: roAdmin9!).</p>
Confirm Read-only Community	<p>This parameter can be set when the Edit Read-only Community switch is turned on.</p> <p>Confirm the read-only community name, which must be the same as that specified by Read-only Community.</p>
Edit Read-write Community	<p>Whether to edit the read-write community name.</p> <ul style="list-style-type: none"> ● To edit the read-write community name, turn on the Edit Read-write Community switch. ● To not edit the read-only community name, turn off the Edit Readwrite Community switch.
Read-write Community	<p>This parameter can be set when the Edit Read-write Community switch is turned on.</p> <p>Enter the read-write community name (default: rwAdmin9!).</p>
Confirm Read-write Community	<p>This parameter can be set when the Edit Read-write Community switch is turned on.</p> <p>Confirm the read-write community name, which must be the same as that specified by Read-write Community.</p>

4. Click **Save**.

Chapter 8

BMC Management

Table of Contents

Network Parameter Configuration.....	130
Setting the Time of the BMC.....	140
Resetting the BMC on the Web Portal of the BMC.....	144
Upgrading Firmware.....	145
Switching Modes.....	147
Updating BMC Configurations.....	148
Restoring Factory Defaults.....	150

8.1 Network Parameter Configuration

8.1.1 Configuring the Host Name


Abstract

This procedure describes how to configure the host name to identify the server.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-1](#).

Figure 8-1 Network Settings Page



Host Name

Host Name Settings: Automatic Manual

Host Name: test

Save

3. Set the parameters in the **Host Name** area. For a description of the parameters, refer to [Table 8-1](#).

Table 8-1 Host Name Parameter Descriptions

Parameter	Setting
Host Name Settings	<p>Select the desired host name setting mode.</p> <ul style="list-style-type: none"> ● Automatic: A host name is automatically set by the system. ● Manual: A host name needs to be manually entered in the Host Name text box.
Host Name	<p>This parameter is required if Host Name Settings is set to Manual. Enter the host name. The host name contains a maximum of 64 characters, including digits, letters, and hyphens. The host name cannot begin or end with hyphens.</p>

4. Click **Save**.

8.1.2 Configuring the Network Port Mode


Abstract

This procedure describes how to configure the network port mode to specify the management network port and shared network port.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-2](#).

Figure 8-2 Network Settings Page



3. Set the parameters in the **Network Port** area. For a description of the parameters, refer to [Table 8-2](#).

Table 8-2 Parameter Descriptions for Configuring a Network Port Mode

Parameter	Setting
Select Mode	<p>Select the desired network port mode.</p> <ul style="list-style-type: none"> ● Automatic: The dedicated network port (namely the iSAC network port) is preferentially used as the management network port. If the dedicated network port does not operate properly, an onboard NCSI that is operating properly is automatically used as the management network port to replace the dedicated network port. ● Fixed: A network port (the dedicated network port or an onboard NCSI) specified in the Dedicated Port box in the Specify Network Port area is used as the management network port. ● Alone: The management network port and shared network port are configured separately. The dedicated network port is used as the management network port, and an onboard NCSI is used as the shared network port.

Parameter	Setting
	If Select Mode is set to Automatic , the following parameters do not need to be configured.
NCSI Mode	<p>This parameter is required when Alone is selected.</p> <p>Select the desired shared network port mode.</p> <ul style="list-style-type: none"> ● Automatic: If the shared network port does not operate properly, an onboard NCSI that is operating properly is automatically used as the shared network port to replace the faulty shared network port. ● Manual: An onboard NCSI specified in the Network Card box in the Specify Network Port area is used as the shared network port. If NCSI Mode is set to Automatic, no shared network port needs to be specified.
Specify Network Port	<ul style="list-style-type: none"> ● If Select Mode is set to Automatic, no network port needs to be specified. ● If Select Mode is set to Fixed, a network port (the dedicated network port or an onboard NCSI) needs to be specified as the management network port. ● If Select Mode is set to Alone and NCSI Mode is set to Manual, the dedicated network port is used as the management network port, and an onboard NCSI needs to be specified in the Network Card box as the shared network port.

4. Click **Save**.

8.1.3 Configuring IP Addresses of Network Ports

Abstract

To replan the IP address of the iSAC management network port or shared network port of the server, you must configure the IP address, subnet mask, default gateway, and other related information.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-3](#).

Figure 8-3 Network Settings Page

The screenshot shows the 'Network Protocols' configuration page. At the top, there are radio buttons for 'Dedicated Port' (selected) and 'Shared Port'. Below that, checkboxes for 'IPv4' and 'IPv6' are both checked. The 'Settings' section is divided into two panels: 'IPv4' and 'IPv6'.
 In the 'IPv4' panel, the 'Acquisition method' is set to 'Manually set IP address'. The 'Address' field contains '10.', the 'Mask' is '255.255.255.0', and the 'Default Gateway' is '10.'. The 'MAC Address' is 'D4:2A:24:5E:AF:51'.
 In the 'IPv6' panel, the 'Acquisition method' is set to 'Automatically obtain IP address'. The 'Address' field is empty, the 'Prefix Length' is '0', and the 'Default Gateway' is empty. The 'Link Local Address' is 'fe80::d62a:24ff:fe5e:af51'.
 A 'Save' button is located at the bottom center of the form.

3. Set the parameters in the **Network Protocols** area. For a description of the parameters, refer to [Table 8-3](#).

Table 8-3 Network Protocol Parameter Descriptions

Parameter	Setting
Select Network Port	This parameter can be set only if Select Mode is set to Alone in the Network Port area. Select the network port for which you want to configure an IP address. <ul style="list-style-type: none"> ● Dedicated Port: configures the IP address of the iSAC management network port. ● Shared Port: configures the IP address of the shared network port.
Network Protocols	Select the network protocol(s) for the network port. <ul style="list-style-type: none"> ● The IPv4 settings need to be configured if you select IPv4 only. ● The IPv6 settings need to be configured if you select IPv6 only. ● Both IPv4 settings and IPv6 settings need to be configured if you select IPv4 and IPv6.
Acquisition method	Select the method of obtaining the IP address. The parameters below do not need to be configured if Acquisition method is set to Automatically obtain IP address .
Address	Enter the address of the BMC as planned.
Mask	Enter the mask.
Default Gateway	Enter the IP address of the default gateway.

Prefix Length	Prefix is the digits of an IP address that represent the network. Value range: 0–128.
---------------	--

4. Click **Save**.

8.1.4 Configuring the DNS

Abstract

To access the Web portal of the BMC through a FQDN, you must configure the DNS information about the server.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-4](#).

Figure 8-4 Network Settings Page

The screenshot shows the DNS configuration interface. At the top, there is a 'DNS' toggle switch which is turned on. Below it, 'DNS Server Settings' has three radio button options: 'Manual' (selected), 'Automatically obtain DNS IPv4 address', and 'Automatically obtain DNS IPv6 address'. Under 'Registration Options', there are two radio button options: 'Host Name' (selected) and 'DHCP Client FQDN'. There are four text input fields: 'Domain Name' (containing 'test.vantageo.com'), 'Preferred Server' (containing '10'), 'Alternate Server 1', and 'Alternate Server 2'. A blue 'Save' button is located at the bottom of the form.

3. Set the parameters in the **DNS** area. For a description of the parameters, refer to [Table 8-4](#).

Table 8-4 DNS Parameter Descriptions

Parameter	Setting
DNS	<p>Select whether to enable the DNS service.</p> <ul style="list-style-type: none"> ● To enable the DNS service, turn on the DNS switch. In this case, the following parameters need to be configured. ● To disable the DNS service, turn off the DNS switch. In this case, the following parameters do not need to be configured.
DNS Server Settings	Select the desired DNS setting method.

Parameter	Setting
	<ul style="list-style-type: none"> ● Manual: If Acquisition method is set to Manually set IP address in the Network Protocols area, this parameter must be set to Manual. When Manual is selected, you need to configure the following parameters. ● Automatically obtain DNS IPv4 address: If Acquisition method is set to Automatically obtain IP address and Network Protocols is set to IPv4 in the Network Protocols area, this parameter must be set to Automatically obtain DNS IPv4 address. When Automatically obtain DNS IPv4 address is selected, you do not need to configure the following parameters. ● Automatically obtain DNS IPv6 address: If Acquisition method is set to Automatically obtain IP address and Network Protocols is set to IPv6 in the Network Protocols area, this parameter must be set to Automatically obtain DNS IPv6 address. When Automatically obtain DNS IPv6 address is selected, you do not need to configure the following parameters.
Registration Options	<p>Select the option used to register with the DNS.</p> <ul style="list-style-type: none"> ● Host Name: uses DHCP option 12 to register with the DNS. ● DHCP Client FQDN: uses DHCP option 81 to register with the DNS. <p>If the DHCP server does not support DHCP option 81, select Host Name. If DNS Server Settings is set to Manual, only Host Name can be selected. If DNS Server Settings is set to Automatically obtain DNS IPv4 address or Automatically obtain DNS IPv6 address, Host Name or DHCP Client FQDN can be selected.</p>
Domain Name	<p>Enter a domain name. The domain name consists of a maximum of 67 characters, including digits, letters, hyphens, and dots. It cannot start with a hyphen or dot or end with a hyphen. No more than 63 characters are allowed between any two dots.</p>
Preferred Server	<p>Enter the IP address of the preferred DNS server.</p> <p>This parameter is required if DNS Server Settings is set to Manual.</p>
Alternate Server 1	<p>Enter the IP address of alternate DNS server 1.</p> <p>This parameter is optional if DNS Server Settings is set to Manual.</p>
Alternate Server 2	<p>Enter the IP address of alternate DNS server 2.</p> <p>This parameter is optional if DNS Server Settings is set to Manual.</p>

4. Click **Save**.

8.1.5 Configuring an iSAC VLAN

Abstract

This procedure describes how to configure an **iSAC VLAN** so that the iSAC management network port can be added to the VLAN.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-5](#).

Figure 8-5 Network Settings Page

3. Set the parameters in the **ISAC VLAN Configuration** area. For a description of the parameters, refer to [Table 8-5](#).

Table 8-5 iSAC VLAN Parameter Descriptions

Parameter	Setting
iSAC VLAN	<p>Select whether to enable the iSAC VLAN function.</p> <ul style="list-style-type: none"> ● To enable the iSAC VLAN function, turn on the iSAC VLAN switch. In this case, the following parameters need to be configured. ● To disable the iSAC VLAN function, turn off the iSAC VLAN switch. In this case, the following parameters do not need to be configured. <p>iSAC VLAN can be enabled if one of the following conditions is met:</p> <ul style="list-style-type: none"> ● The Select Mode parameter in the Network Port area is set to Automatic, and the iSAC management network port is connected. ● The Select Mode parameter is set to Fixed in the Network Port area, and the iSAC management network port is specified as the management network port.
iSAC VLAN ID	Enter the iSAC VLAN ID. Range: 2–4094.

ISAC VLAN Priority	Enter the iSAC VLAN priority. Range: 0–7. A greater value indicates a higher priority.
--------------------	--

4. Click **Save**.

8.1.6 Configuring an NCSI VLAN

Abstract

This procedure describes how to configure an **NCSI VLAN** so that an onboard NCSI can be added to the VLAN.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, see [Figure 8-6](#).

Figure 8-6 Network Settings Page



3. Set the parameters in the **NCSI VLAN Configuration** area. For a description of the parameters, refer to [Table 8-6](#).

Table 8-6 NCSI VLAN Parameter Descriptions

Parameter	Setting
NCSI VLAN	<p>Select whether to enable the VLAN function.</p> <ul style="list-style-type: none"> ● To enable the VLAN function, turn on the VLAN switch. In this case, the following parameters need to be configured. ● To disable the VLAN function, turn off the VLAN switch. In this case, the following parameters do not need to be configured. <p>The VLAN function can be enabled if any of the following conditions is met:</p> <ul style="list-style-type: none"> ● The Select Mode parameter is set to Automatic in the Network Port area, and an onboard NCSI is connected. ● The Select Mode parameter is set to Fixed in the Network Port area, and an onboard NCSI is specified as the management network port.
NCSI VLAN ID	Enter the VLAN ID. Range: 2–4094.
Parameter	Setting
NCSI VLAN Priority	Enter the VLAN priority. Range: 0–7. A greater value indicates a higher priority.

4. Click **Save**.

8.1.7 Configuring USB over LAN

Abstract

This procedure describes how to configure **USB** over **LAN** to establish a communication channel between the **BMC** and a host.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Network Settings**. The **Network Settings** page is displayed, as shown in [Figure 8-7](#).

Figure 8-7 Network Settings Page



3. In the **Lan Over USB Configuration** area, set the parameters. For a description of the parameters, refer to [Table 8-7](#).

Table 8-7 USB over LAN Parameter Descriptions

Parameter	Setting
Lan Over USB Enabled	<p>Select whether to enable USB over LAN.</p> <ul style="list-style-type: none"> ● Turn on the Lan Over USB Enabled toggle switch to enable USB over LAN and configure the following parameters. ● Turn off the Lan Over USB Enabled toggle switch to disable USB over LAN. The following parameters do not need to be configured.
Network Protocols	<p>Select a network protocol and set the network parameters such as IP address.</p>

4. Click **Save**.

8.2 Setting the Time of the BMC

Abstract

The time of the [BMC](#) must be correct.

This procedure describes how to set the time of the BMC in either of the following ways:

- Setting time manually
- Synchronizing time with an [NTP](#) server

To make the manually set time permanently valid, you need to disable NTP-based time synchronization.

Steps

- Setting Time Manually
 1. Select **BMC Settings**. The **BMC Settings** page is displayed.
 2. From the navigation tree in the left pane, select **Time Zone & NTP**. The **Time Zone & NTP** page is displayed, as shown in [Figure 8-8](#).

Figure 8-8 Time Zone & NTP Page

Time Zone & NTP

i The expected time set by the set sel time command will take effect permanently. Please disable NTP synchronization.

Time Zone

Time 2024-01-11 11:07:09 ✎

Current Timezone UTC+08:00

Region

NTP

NTP

Polling Interval 5

Main Server

Secondary Server

Tertiary Server

Save

3. Click ✎ and then set the time.



Note

The time is automatically saved on the page after being set.

- Synchronizing Time with an NTP Server
 1. Select **BMC Settings**. The **BMC Settings** page is displayed.
 2. From the navigation tree in the left pane, select **Time Zone & NTP**. The **Time Zone & NTP** page is displayed, as shown in [Figure 8-9](#).

Figure 8-9 Time Zone & NTP Page

- Set the parameters in the **NTP** area. For a description of the parameters, refer to [Table 8-8](#).

Table 8-8 NTP Parameter Descriptions

Parameter	Description
NTP	Enable NTP .
Polling Interval	Enter the time synchronization period. Range: 60–65535, unit: seconds.
Parameter	Description
Main Server	Enter the IP address or FQDN of the primary NTP server. The length cannot exceed 127 characters. This parameter is required.
Secondary Server	Enter the IP address or FQDN of the secondary NTP server. The length cannot exceed 127 characters. This parameter is optional.

Tertiary Server	Enter the IP address or FQDN of the tertiary NTP server. The length cannot exceed 127 characters. This parameter is optional.
-----------------	---

**Note**

The BMC first synchronizes time with the primary NTP server. If the synchronization fails, it synchronizes time with the secondary NTP server and tertiary NTP server in turn.

-
4. Click **Save**.

Verification

If NTP-based time synchronization is used, perform the following operations:

1. On the **Time Zone & NTP** page, view the date and time, as shown in [Figure 8-10](#).

Figure 8-10 Time Zone & NTP Page

Time Zone & NTP

Time Zone & NTP

Time Zone & NTP

The expected time set by the set sel time command will take effect permanently. Please disable NTP synchronization.

Time Zone

Time 2024-01-11 11:09:18

Current Timezone UTC+08:00

Region INDIA / MUMBAI

NTP

NTP

Polling Interval 60 s

Main Server 10

Secondary Server time.nist.gov

Tertiary Server

Save

2. On the NTP server, check whether the time is the same as the time of the BMC.

8.3 Resetting the BMC on the Web Portal of the BMC

Abstract

After some configurations (for example, [MAC](#) address and chassis information programming), you must reset the [BMC](#) to apply the changes.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Firmware Upgrade**. The **Firmware Upgrade** page is displayed, see [Figure 8-11](#).

Figure 8-11 Firmware Upgrade Page

Firmware Upgrade

i After the BMC is upgraded, the BMC is automatically restarted. When the system is powered off, the BIOS upgrade takes effect directly. When the system is powered on, the BIOS is updated to the backup version and takes effect automatically after the systems is powered off. It takes a period of time to make the firmware take effect automatically, and firmware upgrade cannot be performed during this period.

Firmware Operation:

Version Information:

BMC Primary Partition Version	04.24.02.00 (Feb 26 2024)
BMC Standby Partition Version	04.24.01.00 (Jan 08 2024)
BIOS Primary Version	01.23.04.00 (Dec 27 2023)
BIOS Standby Version	01.23.04.00 (Dec 27 2023)
EPLD Version	00.00.00.0102

Upgrade
 Don't Inherit Configuration When Upgrading BMC
 Don't Inherit Configuration When Upgrading BIOS

3. Click **Reset BMC**, and confirm the reset in the displayed message box.



Note

Relogin is allowed only after the BMC is reset.

8.4 Upgrading Firmware

Abstract

If the firmware on the mainboard of a server needs an upgrade, you can upload the firmware online for upgrade.

If multiple firmware versions need an upgrade, the following sequence is recommended:

1. **FRU** firmware

After the FRU firmware is upgraded, the **BMC** is automatically restarted to apply the new version.

2. **BMC** firmware

The Web portal of the BMC temporarily supports the upgrade of the active BMC firmware only. After the active BMC firmware is upgraded, the BMC is automatically restarted to apply it.

3. **EPLD** firmware

After the EPLD firmware is upgraded, the new version takes effect only after the server is restarted. Therefore, it is recommended that you stop the services running on the server before the upgrade.

4. **BIOS** firmware

After the BIOS firmware is upgraded, the new version takes effect only after the server is restarted. Therefore, it is recommended that you stop the services running on the server before the upgrade.

- If the BIOS firmware is upgraded when the server is powered off, the upgraded BIOS firmware takes effect directly.
- If the BIOS firmware is upgraded when the server is powered on, the upgraded BIOS firmware is displayed as a standby version on the Web portal and takes effect automatically after the server is powered off and restarted. It takes time for the new version to take effect automatically. During this period, firmware upgrade is not allowed.

5. VR firmware



Note

If a firmware version fails to be upgraded during version upgrade, you must upgrade it again.

Prerequisite

The firmware to be upgraded is already obtained.



Note

Firmware files can be obtained on the **Software Download** page on the Web portal of the servers and storage products (<https://enterprise.VANTAGEO.com.cn>).

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Firmware Upgrade**. The **Firmware Upgrade** page is displayed, see [Figure 8-12. Figure 8-12 Firmware Upgrade Page](#)

Firmware Upgrade

i After the BMC is upgraded, the BMC is automatically restarted. When the system is powered off, the BIOS upgrade takes effect directly. When the system is powered on, the BIOS is updated to the backup version and takes effect automatically after the systems is powered off. It takes a period of time to make the firmware take effect automatically, and firmware upgrade cannot be performed during this period.

Firmware Operation Reset BMC

Version Information

BMC Primary Partition Version	04.24.01.20 (Mar 17 2024)
BMC Standby Partition Version	04.24.01.00 (Jan 08 2024)
BIOS Primary Version	01.23.04.00 (Dec 27 2023)
BIOS Standby Version	01.23.04.00 (Dec 27 2023)
EPLD Version	00.00.00.0102

Upgrade Don't Inherit Configuration When Upgrading BMC Don't Inherit Configuration When Upgrading BIOS

Upload

Upgrade

3. Click **Upload** and select the firmware file in the displayed dialog box.

**Note**

Only one firmware file can be selected at a time. During the firmware upgrade process, the firmware file automatically matches the firmware type.

After the BMC or BIOS firmware is successfully uploaded, the **Don't Inherit Configuration When Upgrading BMC** or **Don't Inherit Configuration When Upgrading BIOS** check box becomes activated.

-
4. (Optional) Perform either of the following operations:
 - To restore the factory default settings of the BMC, select **Don't Inherit Configuration When Upgrading BMC**.
 - To restore the factory default settings of the BIOS, select **Don't Inherit Configuration When Upgrading BIOS**.
 5. Click **Upgrade**.

**Notice**

During the firmware upgrade process, you cannot switch to another page. Otherwise, the upgrade process is interrupted.

8.5 Switching Modes

Abstract

A mode refers to a working mode of a [PCIe](#) switch board. By switching modes, [CPU](#)s and [GPU](#)s can work in a proper mode.

**Note**

Only R6500 G5 servers support mode switching.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Firmware Upgrade**. The **Firmware Upgrade** page is displayed.
3. Click **Mode Switching**. The **Mode Switching** tab is displayed, as shown in [Figure 8-13](#).

Figure 8-13 Mode Switching Tab

- Set the parameters. For a description of the parameters, refer to [Table 8-9](#).

Table 8-9 Mode Switching Parameter Descriptions

Parameter	Setting
Firmware Mode	Firmware mode is determined by the hardware topology of a PCIe switch board, including Single uplink and Dual uplink . It cannot be configured.
Mode Selection	Select the working mode of a PCIe switch board. <ul style="list-style-type: none"> ● Cascade Mode: provides the best point-to-point communication between GPUs and the worst I/O bandwidth between CPUs and GPUs. ● Normal Mode: provides the suboptimal point-to-point communication between GPUs and suboptimal I/O bandwidth between CPUs and GPUs. ● Balancing Mode: provides the worst point-to-point communication between GPUs and the best I/O bandwidth between CPUs and GPUs. When Firmware Mode is set to Dual uplink, you can select only Normal Mode or Balancing Mode.

- Click **Save**.

8.6 Updating BMC Configurations

Abstract

This procedure describes how to update [BMC/BIOS](#) configurations online.


Before replacing the mainboard of a server, you can back up the BMC/BIOS configurations by using the configuration update function.

Steps

- Select **BMC Settings**. The **BMC Settings** page is displayed.

- From the navigation tree in the left pane, select **Configuration Update**. The **Configuration Update** page is displayed, see [Figure 8-14](#).

Figure 8-14 Configuration Update Page



- Perform the following operations as required.

If...	Then...
There is an existing BMC/BIOS configuration file	<ol style="list-style-type: none"> Click Upload, and select the BMC configuration file in the displayed dialog box. Click Import, and confirm the import in the displayed message box.
There is no BMC/BIOS configuration file	<ol style="list-style-type: none"> Click Export to export the current BMC configurations to your local PC. Edit the exported BMC configuration file. Click Upload, and select the BMC configuration file in the displayed dialog box. Click Import, and confirm the import in the displayed message box.

Note

After the BMC configurations are imported, the BMC is automatically restarted to apply the configurations. Do not perform any other operations until the BMC is restarted.
 After the BIOS configuration is imported, you need to manually reset the host to validate the configuration.

Related Tasks

To back up BMC configurations, perform the following operations:

1. Click **Export** to export the current BMC configurations to your local PC.
2. After replacing the mainboard, click **Upload**, and select the exported BMC configuration file in the displayed dialog box.
3. Click **Import**, and confirm the import in the displayed message box.

8.7 Restoring Factory Defaults

Abstract

By restoring factory defaults, you can restore the server configuration items (for example, the network, user, **SNMP** configuration and startup mode) to factory defaults.



Note

Do not perform any operation during restoration.
After the factory defaults are restored, the **BMC** will be restarted automatically.

Steps

1. Select **BMC Settings**. The **BMC Settings** page is displayed.
2. From the navigation tree in the left pane, select **Configuration Update**. The **Configuration Update** page is displayed, see [Figure 8-15](#).

Figure 8-15 Configuration Update Page

Configuration Update

Configure Import

Supports importing BMC and BIOS configurations. After importing, BMC automatically restarts and the configuration takes effect. BIOS takes effect and requires manual resetting of the host.

Select Type: BMC BIOS

Select File: Upload

Import

Configure Export

Select Type: BMC BIOS

Export

Restore Factory Settings

After restoring BMC factory settings, you need to log in to BMC for the first time. Please use this function with caution.

Restore Factory Settings

3. Click **Restore Factory Defaults**.

Chapter 9

User and Security

Table of Contents

Adding a Local User.....	151
Configuring Authentication Parameters for Domain Users.....	154
Querying Online Users.....	158
Configuring Permissions for a Customized Role.....	159
Configuring Security Enhancement Parameters.....	160
Configuring Firewall Parameters.....	161
Configuring Two-Factor Authentication.....	163

9.1 Adding a Local User

Abstract

Local users refer to users of the **BMC** itself. This procedure describes how to add a local user to configure and manage the BMC.

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Local Users**. The **Local Users** page is displayed, see [Figure 9-1](#).

Figure 9-1 Local Users Page

User ID	User Name	Role	Login Interfaces	Operation
1	anonymous	Administrator	SNMP SSH Redfish	Edit Enable Delete
2	Administrator	Administrator	SNMP SSH Redfish	Edit Disable Delete

3. Click **Add User**. The **Add User** page is displayed, see [Figure 9-2](#).

Figure 9-2 Add User Page

4. Set the parameters. For a description of the parameters, refer to [Table 9-1](#).

Table 9-1 Parameter Descriptions for Adding a Local User

Parameter	Setting
New User ID	Select the ID of the new user. A maximum of 16 local users are supported, so the user ID ranges from 1 to 16. User 1 is a reserved user, and user 2 is the default administrator.
New UserName	Enter the name of the new user. The name contains a maximum of 16 characters, including digits, letters (case sensitive), and special characters. The new username cannot be the same as another existing username. The following cannot be used as a username: sshd, ntp, stunnel4, sysadmin, daemon, Administrator, and anonymous. The allowed special characters include hyphens (-), underscores (_), and at symbols (@).
New Password	Enter the password of the new user. The password contains 5–20 characters (If Login Interfaces is set to SNMP , the password contains 8–20 characters.), including digits, letters (case sensitive), and special characters. It must contain one special character and characters from at least two of the following types: digits, uppercase letters, and lowercase letters. The allowed special characters include ` , ~ , ! , @ , \$, % , ^ , & , * , (,) , - , _ , = , + , \ , , [, { , } ,] , ; , ' , " , , , < , > , / , ? , # , ; .

Parameter	Setting
	<p>The function of disabling historical passwords is disabled by default. If this function is enabled, the new password cannot be the same as any of the historical passwords.</p> <p>The password cannot be the same as the username in reverse order. For example, if the username is test, the password cannot be tset.</p>
Confirm Password	Enter the same password again for confirmation.
Role	Select the role that the new user belongs to, including Administrator , Operator , Common User , and Custom Role . The permissions of each role can be viewed on the Security Management page.
Login Interfaces	<p>Select one or more login interfaces available to the new user.</p> <ul style="list-style-type: none"> • For SNMP interface-based login, select SNMP. • For Redfish interface-based login, select Redfish. <p>SSH-based login is supported for all users by default.</p>
Current User Password	Enter the password of the currently logged-in user.

5. Click **Submit**.
6. (Optional) If **Login Interfaces** is set to **SNMP**, click **Edit** in the **Operation** column for the new user. The **Edit** page is displayed. Set **SNMPv3 Authentication Algorithm** and **SNMPv3 Encryption Algorithm**.
 - Options of **SNMPv3 Authentication Algorithm** include **SHA**, **MD5**, **SHA256**, **SHA384**, and **SHA512**. It is recommended that you select **SHA256**, **SHA384**, or **SHA512**
 - Options of **SNMPv3 Encryption Algorithm** include **DES**, **AES**, and **AES256**. It is recommended that you select **AES**.

Related Tasks

Perform either of the following operations as needed.

To...	Do...
Disable a local user	<ol style="list-style-type: none"> 1. In the Operation column, click Disable for the user. The Confirm dialog box is displayed. 2. Enter the password of the currently logged-in user. 3. Click Submit.
Delete a local user	<ol style="list-style-type: none"> 1. In the Operation column, click Delete for the user. The Confirm dialog box is displayed. 2. Enter the password of the currently logged-in user. 3. Click Submit.

9.2 Configuring Authentication Parameters for Domain Users

Abstract

Domain users are not the users of the BMC itself. The detailed information about domain users is stored on an LDAP server or AD server.

This procedure describes how to configure authentication parameters for domain users to authenticate them through an LDAP or AD server.



Note

If you log in to the BMC as a domain user, the current server must be interconnected with the LDAP server or AD server.

Prerequisite

The parameters of the LDAP server or AD server are already obtained.

Steps

- Configuring LDAP Server Authentication Parameters
 1. Select **User & Security**. The **User & Security** page is displayed.
 2. From the navigation tree in the left pane, select **Domain Users**. The **Domain Users** page is displayed, see [Figure 9-3. Figure 9-3 Domain Users Page](#)

LDAP
AD

LDAP Authentication

Basic Attributes

Server Address

Port

Bind DN

Password

Search Base

Attribute of User Login cn uid

Encryption Type No encryption SSL StartTLS

[Save](#)

LDAP Role Group

ID	Name	Search Domain	Permissions	Operation
1	<input type="text" value="test"/>	<input type="text" value="cn=admin,ou=login,dc=ladpdomain,dc=com"/>	<input type="radio"/> Administrator <input type="radio"/> Operator <input checked="" type="radio"/> User	Save Cancel
2				Edit
3				Edit
4				Edit
5				Edit

3. Turn on the **LDAP Authentication** switch.
4. Set the parameters in the **Basic Attributes** area. For a description of the parameters, refer to [Table 9-2](#).

Table 9-2 Parameter Descriptions for Basic LDAP Authentication Attributes

Parameter	Setting
Server Address	Enter the IP address or FQDN of the LDAP server.
Port	Enter the port number. Range: 1–65535. Default: 389. If Encryption Type is set to SSL , enter the port number <i>636</i> .
Bind DN	Enter the DN of the LDAP server, for example, <i>cn=admin,dc=ldapdomain,dc=com</i> .
Password	Enter the password for logging in to the LDAP server. It cannot be left blank. Range: 1–47 characters. Bind DN and Password are used to access the LDAP server.
Search Base	Enter the storage location of the user information on the LDAP server, for example, <i>dc=ldapdomain,dc=com</i> .
Attribute of User Login	Select the user login attribute identified by the LDAP server. → If Bind DN contains cn , select cn . → If Bind DN contains uid , select uid .
Encryption Type	Select the type of encryption used by the LDAP server. → No encryption : indicates that no encryption is used. → SSL : indicates that SSL encryption is used. → StartTLS : indicates that StartTLS encryption is used.
Upload certificate	Click the corresponding certificate button and upload the certificate. If Encryption Type is set to No encryption , no certificate needs to be uploaded.

5. Click **Save**.
6. In the **LDAP Role Group** area, click **Edit** in the **Operation** column for a role group to activate role group parameters.
7. Set the role group parameters. For a description of the parameters, refer to [Table 9-3](#).

Table 9-3 LDAP Role Group Parameter Descriptions

Parameter	Setting
Name	Enter the name of the role group that domain users belong to. The name contains a maximum of 64 characters, including digits, letters, spaces, and special characters. It cannot begin with a space. The allowed special characters include hyphens and underscores.
Parameter	Setting
Search Domain	Enter the storage location of the user group information on the LDAP server, for example, <i>cn=admin,ou=login,dc=ldapdomain,dc=com</i> .
Permissions	Select the permissions of the role group that domain users belong to in the BMC, including Administrator , Operator , and User . The permissions of each role can be viewed on the Security Management page.

8. Click **Save** in the **Operation** column.

- **Configuring AD Server Authentication Parameters**

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Domain Users**. The **Domain Users** page is displayed.
3. Click **AD**. The **AD** tab is displayed, see [Figure 9-4](#).

Figure 9-4 AD Tab

The screenshot shows the 'Domain Users' configuration page with the 'AD' tab selected. Under 'Basic Attributes', 'AD Certification' and 'SSL Encryption' are toggled on. The 'User Name' field contains 'test', 'Password' is masked with dots, and 'User Domain Name' is 'mydomain.com'. There are three 'Domain Control Server Address' fields; the first contains '10' and the others are empty. A blue 'Save' button is visible. Below is the 'AD Role Group' table:

ID	Name	Domain Name	Permissions	Operation
1	test01	mydomain.com	<input type="radio"/> Administrator <input type="radio"/> Operator <input checked="" type="radio"/> User	Save Cancel
2	6786786785	6786786654645	User	Edit Delete
3				Edit
4				Edit
5				Edit

4. Turn on the **AD Authentication** switch.
5. Set the parameters in the **Basic Attributes** area. For a description of the parameters, refer to [Table 9-4](#).

Table 9-4 Parameter Descriptions for Basic AD Authentication Attributes

Parameter	Setting
SSL Encryption	Select whether SSL encryption is used when logging in to the AD server. → To enable SSL encryption, turn on the SSL Encryption switch. → To disable SSL encryption, turn off the SSL Encryption switch.
User Name	Enter the username for logging in to the AD server. The username contains a maximum of 64 characters, including digits, letters (case sensitive), spaces, and special characters. It must begin with a letter. The allowed special characters include hyphens and underscores. If the username and password are not required, leave this parameter blank.
Password	Enter the password for logging in to the AD server. Range: 6–127 characters. If the username and password are not required, leave this parameter blank.
User Domain Name	Enter the domain name of the AD server, for example, <i>mydomain.com</i> , and is required.
Domain Control Server Address 1	Enter the IP address of AD server 1, which supports IPv4 and IPv6 formats, and is required.
Domain Control Server Address 2	Enter the IP address of AD server 2, which supports IPv4 and IPv6 formats, and is optional.
Domain Control Server Address 3	Enter the IP address of AD server 3, which supports IPv4 and IPv6 formats, and is optional.

6. Click **Save**.
7. In the **AD Role Group** area, click **Edit** in the **Operation** column for a role group to activate role group parameters.
8. Set the role group parameters. For a description of the parameters, refer to [Table 9-5](#).

Table 9-5 AD Role Group Parameter Descriptions

Parameter	Setting
Name	Enter the name of the role group that domain users belong to. The name contains a maximum of 64 characters, including digits, letters, spaces, and special characters. It cannot begin with a space. The allowed special characters include hyphens and underscores.
Domain Name	Enter the domain name of the role group, for example, <i>mydomain.com</i> .
Permissions	Select the permissions of the role group that domain users belong to in the BMC, including Administrator , Operator , and User . The permissions of each role can be viewed on the Security Management page.

9. Click **Save** in the **Operation** column.

9.3 Querying Online Users

Abstract

By querying online users, administrator can learn about all online users, including their **IDs**, usernames, login modes, login **IP** addresses, and login time.



Note

The ID is the serial number of a user's connection session rather than the user ID.

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Online Users**. The **Online Users** page is displayed, see [Figure 9-5](#).

Figure 9-5 Online Users Page

ID	User Name	Login Method	Login IP	Login Time	Operation
12	Administrator	Web HTTPS	10. [redacted]	2024-03-07 15:06:15	Delete

Total 1 K < 1 > X 10 / Page To 1 Page

3. (Optional) To force a user to log out of the Web portal of the BMC, click **Delete** in the **Operation** column for the user, and click **Submit** in the displayed message box.



Note

You cannot delete yourself.

9.4 Configuring Permissions for a Customized Role

Abstract

The following roles exist in the system by default:

- Common user
- Operator
- Administrator
- Customized roles 1–4

The permissions of common users, operators, and administrators cannot be configured, while the permissions of customized roles can be configured.



Note

Only administrators can configure the permissions of customized roles.

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Security Management**. The **Security Management** page is displayed, see [Figure 9-6](#).

Figure 9-6 Security Management Page

Security Management										
Permission Management Security Enhancements Firewall										
Role	User Mgmt	Basic Mgmt	Remote Control	VMM	Security Mgmt	Power Control	Diagnosis	Query	Configure Itself	Operation
Common User								✓	✓	
Operator		✓	✓	✓		✓		✓	✓	
Administrator	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Custom Role 1								✓	✓	Edit Disable
Custom Role 2								✓	✓	Edit Disable
Custom Role 3								✓	✓	Edit Disable
Custom Role 4								✓	✓	Edit Disable

3. In the **Operation** column, click **Edit** for a customized role to activate the permission check boxes, see [Figure 9-7](#).

Figure 9-7 Activating the Permission Check Boxes

Security Management										
Permission Management Security Enhancements Firewall										
Role	User Mgmt	Basic Mgmt	Remote Control	VMM	Security Mgmt	Power Control	Diagnosis	Query	Configure Itself	Operation
Common User								✓	✓	
Operator		✓	✓	✓		✓		✓	✓	
Administrator	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Custom Role 1		<input checked="" type="checkbox"/>	<input type="checkbox"/>	✓	<input checked="" type="checkbox"/>	Save Cancel				
Custom Role 2								✓	✓	Edit Disable
Custom Role 3								✓	✓	Edit Disable
Custom Role 4								✓	✓	Edit Disable

4. Select the corresponding permissions.
5. Click **Save**.

Related Tasks

To disable or enable a customized role, perform the following operations:

- In the **Operation** column, click **Disable** to disable the customized role.
- In the **Operation** column, click **Enable** to enable the customized role.



Note

You cannot disable or enable common users, operators, and administrators.

9.5 Configuring Security Enhancement Parameters

Abstract

To enhance user login security, you can configure security enhancement parameters, including:

- **Password Complexity Check**
- **Password Validity**
- **User Lockout Policy**

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Security Management**. The **Security Management** page is displayed.
3. Click **Security Enhancements**. The **Security Enhancements** tab is displayed, see [Figure 9-8](#).

Figure 9-8 Security Enhancements Tab

4. Set the parameters. For a description of the parameters, refer to [Table 9-6](#).

Table 9-6 Security Enhancement Parameter Descriptions

Parameter	Setting
Password Complexity Check	Select whether to enable password complexity check. <ul style="list-style-type: none"> ● To enable password complexity check, turn on the Password Complexity Check switch. ● To disable password complexity check, turn off the Password Complexity Check switch.
Password Validity	Enter the password validity period. Range: 0–365, unit: days. If the password validity period is 0, there is no limit to the validity period.
User Lockout Policy	Select the maximum number of login failures and enter the locking duration. If the maximum number is exceeded, a user is locked.

5. Click **Save**.

9.6 Configuring Firewall Parameters

Abstract

By configuring firewall parameters, you can add IP or MAC addresses to the blacklist and whitelist to control access to the [BMC](#).

- The devices in the blacklist are forbidden to access the BMC all the time or within the specified time period.
- The devices in the whitelist are allowed to access the BMC all the time or within the specified time period.

Note: When enabling the whitelist policy, you must first add the **IP** or **MAC** address of your local **PC** (acting as a client PC) to the whitelist to ensure that your local PC can access the Web portal of the BMC.

This procedure describes how to configure firewall parameters.

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Security Management**. The **Security Management** page is displayed.
3. Click **Firewall**. The **Firewall** tab is displayed, as shown in [Figure 9-9](#).

Figure 9-9 Firewall Tab

The screenshot shows the 'Security Management' page with the 'Firewall' tab selected. It contains two main sections: 'Blacklist' and 'Whitelist'. Each section has a table with columns for 'No.', 'Time Segment', 'IP Segment', 'MAC Segment', and 'Operation'. The 'Blacklist' section has one rule with IP segment 10.239.10.10 and MAC segment Required. The 'Whitelist' section has one rule with IP segment 10.239.20.10 and MAC segment Required. There are also 'Add Rule', 'Save', and 'Cancel' buttons for each rule.

4. Perform the following operations as needed.

To...	Do...
Add an item to the blacklist	<ol style="list-style-type: none"> In the Blacklist area, click Add Rule. The blacklist parameters are activated. Set the parameters. For a description of the parameters, refer to Table 9-7. Click Save.
Add an item to the whitelist	<ol style="list-style-type: none"> In the Whitelist area, click Add Rule. The whitelist parameters are activated. Set the parameters. For a description of the parameters, refer to Table 9-7. Click Save.

Table 9-7 Blacklist/Whitelist Parameter Descriptions

Parameter	Description
Time Segment	<p>From the Time Type list, select the desired time type, and set the time period accordingly.</p> <p>The format of the start time and end time must be the same.</p> <p>Before selecting Working days only, you must specify a time period. If the time period is left blank, the devices in the blacklist are permanently forbidden to access the BMC or those in the whitelist are permanently allowed to access the BMC.</p>
IP Segment	<p>Enter an IP address or an IP address segment. IPv4 or IPv6 format is supported.</p> <p>For a single IP address, 127.0.0.1 is disallowed.</p>
	<p>For an IP address segment, the format of the start address and end address must be the same.</p>
MAC Segment	<p>Enter a MAC address or a MAC address segment. The format is xx:xx:xx:xx:xx:xx.</p> <p>A MAC address segment can contain a maximum of 64 MAC addresses. At least one of the IP Segment and MAC Segment parameters must be set.</p>

9.7 Configuring Two-Factor Authentication

Abstract

Two-factor authentication requires another credential for access to the [BMC](#) in addition to a static password. It improves the security of the BMC.

Steps

1. Select **User & Security**. The **User & Security** page is displayed.
2. From the navigation tree in the left pane, select **Two-factor Authentication**. The **Two-factor Authentication** page is displayed, as shown in [Figure 9-10](#).

Figure 9-10 Two-factor Authentication Page

Two-factor Authentication

Turning authentication on or off

Turning authentication on or off enable disable

Save

Mobile Phone Binding Account

i Use the mobile app to scan the QR code, enter the dynamic password generated by the mobile app, and complete the binding.

Generate QR code

3. Select whether to enable two-factor authentication. Options:
 - **enable**: enables two-factor authentication.
 - **disable**: disables two-factor authentication.
4. Click **Save**.
5. (Optional) If two-factor authentication is enabled, click **Generate QR code**, and then scan the code and enter the correct token to bind your mobile number to.

**Note**

The bound mobile number will be used as the other credential in addition to the static password. In addition, the BMC time must be the same as the Internet time. Otherwise, the verification fails.

Chapter 10

Reference: Default Passwords

The default administrator username for logging in to the **BMC** of a server is *sysadmin*. The default administrator password depends on server models and BMC versions. For details, refer to [Table 10-1](#).

Table 10-1 Default Password Descriptions

Server Model	BMC Version	Default Password
2240-RE	Versions earlier than V04.23.01.02P1	superuser
	V04.23.01.02P1 and later	Superuser@123
2230-RE	Versions earlier than V04.23.02.01	superuser
	V04.23.02.01 and later	Superuser@123
1240-RE	Versions earlier than V04.23.04.00	superuser
	V04.23.04.00 and later	Superuser@123
	V04.23.01.02 and later	Superuser@123
22G1-RE	Versions earlier than V04.23.01.01P2	superuser
	V04.23.01.01P2 and later	Superuser@123

Note

After logging in to the BMC by using the default password, you must change it immediately. It is recommended that you change the password to a strong password.

Chapter 11

Reference: Accessing Documents

Abstract

Documents are readily available at [VANTAGEO.com Enterprise Servers](https://VANTAGEO.com), select the model and at every model page will have the document download links



Note

This procedure uses VANTAGEO Server Redfish Interface Description (BMC V4) as an example, and other documents can be accessed by similar steps.


Prerequisite

You have registered successfully at VANTAGEO.com and select the product

Steps


1. In the address bar of your browser, enter `https://VANTAGEO.com` and press **Enter**. The home page is displayed.
2. Click **Login** in the upper right corner. The **User Login** page is displayed, see [Figure 11-1](#).

Figure 11-1 User Login Page




3. Enter the username, password, and verification code.
4. Click **Login** to log in the VANTAGEO.com/partner-portal/ website.
5. Select **Support** on the menu. The **Support** page is displayed, see [Figure 11-2](#).

Figure 11-2 Support Page



6. Click **Document Download**. The **Document Download** page is displayed, see Figure 11-3.

Figure 11-3 Document Download Page (Select your model from Enterprise Servers and below every model you can find the download link)



7. On the server list of servers at the lower part of the page, click the server that the document to be accessed is about.

8. In the **document** list, select **Interface Description**, and all the documents about interface description are display on the right side of the page.

9. Click **Download** to the right of **VANTAGEO Server Redfish Interface Description (BMC V4)**, and download the document.

Glossary

A/D

- Analog to Digital

AC

- Alternating Current

ACPI

- Advanced Configuration and Power Interface

AD

- Active Directory

AES

- Advanced Encryption Standard

API

- Application Programming Interface

ASCII

- American Standard Code for Information Interchange

BBU

- Battery Backup Unit

BDF

- Bus/Device/Function

BIOS

- Basic Input/Output System

BMC

- Baseboard Management Controller

CD

- Compact Disk

CLI

- Command Line Interface

CPU

- Central Processing Unit

CRPS

- Common Redundant Power Supplies

DCMI

- Data Center Manageability Interface

DHCP

- Dynamic Host Configuration Protocol

DNS

- Domain Name Server

DVD

- Digital Versatile Disc

EPLD

- Erasable Programmable Logic Device

FC

- Fiber Channel

FQDN

- Fully Qualified Domain Name

FRU

- Field Replaceable Unit

GPIO

- General Purpose Input Output

GPU

- Graphics Processing Unit

GUI

- Graphical User Interface

HD

- Hard disk

HTML

- HyperText Markup Language

HTTP

- Hypertext Transfer Protocol

HTTPS

- Hypertext Transfer Protocol Secure

HVDC

- High-Voltage Direct Current

I/O

- Input/Output

ID

- Identification

IE

- Internet Explorer

IP

- Internet Protocol

IPMI

- Intelligent Platform Management Interface

IPv4

- Internet Protocol Version 4

IPv6

- Internet Protocol Version 6

JRE

- Java Runtime Environment

KPI

- Key Performance Indicator

KVM

- Keyboard, Video and Mouse

LAN

- Local Area Network

LDAP

- Lightweight Directory Access Protocol

LPC

- Lower order Path Connection

LVDC

- Low-Voltage Direct Current

MAC

- Media Access Control

NCSI

- Network Controller Sideband Interface

NIC

- Network Interface Card

NMS

- Network Management System

NTP

- Network Time Protocol

NVMe

- Non-Volatile Memory Express

OS

- Operating System

PC

- Personal Computer

PCIe

- Peripheral Component Interconnect Express

PECI

- Platform Environment Control Interface

POST

- Power-On Self-Test

PWM

- Pulse-Width Modulation

PXE

- Preboot eXecution Environment

RAID

- Redundant Array of Independent Disks

RMCP

- Remote Management Control Protocol

RPM

- Rotations Per Minute

SAS

- Serial Attached SCSI

SATA

- Serial ATA

SEL

- System Event Log

SFTP

- Secure File Transfer Protocol

SGPIO

- Serial GPIO

SHA

- Secure Hash Algorithm

SMBUS

- System Management BUS

SMTP

- Simple Mail Transfer Protocol

SNMP

- Simple Network Management Protocol

SSH

- Secure Shell

SSL

- Secure Sockets Layer

TCP

- Transmission Control Protocol

TLS

- Transport Layer Security

UEFI

- Unified Extensible Firmware Interface

UID

- Unit Identification Light

USB

- Universal Serial Bus

iSAC

- Integrated Server Administrator Controller

VNC

- Virtual Network Console

VR

- Voltage Regulator

XML

- Extensible Markup Language

iSAC

- Integrated Server Administrator Controller