# vantageo

# **VANTAGEO Server**

# BMC User Guide (for BMC Version 3)

Version: R1.5

**VANTAGEO PRIVATE LIMITED** 

Corporate Address: 617, Lodha Supremus II,

Road No. 22, Wagle Estate,

Thane - 400604

URL: https://vantageo.com

E-mail: <a href="mailto:support@vantageo.com">support@vantageo.com</a>
Helpdesk - +91 18002669898

#### **LEGAL INFORMATION**

Copyright 2024 VANTAGEO PRIVATE LIMITED.

The contents of this document are protected by copyright laws and international treaties. Any reproduction or distribution of this document or any portion of this document, in any form by any means, without the prior written consent of VANTAGEO PRIVATE LIMITED is prohibited. Additionally, the contents of this document are protected by contractual confidentiality obligations.

All company, brand and product names are trade or service marks, or registered trade or service marks, of VANTAGEO PRIVATE LIMITED or of their respective owners.

This document is provided as is, and all express, implied, or statutory warranties, representations or conditions are disclaimed, including without limitation any implied warranty of merchantability, fitness for a particular purpose, title or non-infringement. VANTAGEO PRIVATE LIMITED and its licensors shall not be liable for damages resulting from the use of or reliance on the information contained herein.

VANTAGEO PRIVATE LIMITED or its licensors may have current or pending intellectual property rights or applications covering the subject matter of this document. Except as expressly provided in any written license between VANTAGEO PRIVATE LIMITED and its licensee, the user of this document shall not acquire any license to the subject matter herein.

VANTAGEO PRIVATE LIMITED reserves the right to upgrade or make technical change to this product without further notice.

Users may visit the VANTAGEO technical support website <a href="https://www.vantageo.com/support">https://www.vantageo.com/support</a> to inquire for related information.

The ultimate right to interpret this product resides in VANTAGEO PRIVATE LIMITED.

Statement on the Use of Third-Party Embedded Software:

If third-party embedded software such as Oracle, Sybase/SAP, Veritas, Microsoft, VMware, and Redhat is delivered together with this product of VANTAGEO, the embedded software must be used as only a component of this product. If this product is discarded, the licenses for the embedded software must be void either and must not be transferred. VANTAGEO will provide technical support for the embedded software of this product.

### **Revision History**

Revision No.	Revision Date	Revision Reason
R1.5	2024-11-27	Full-text update.
R1.4	2023-12-12	Full-text update.
R1.3	2023-09-08	Full-text update.
R1.2	2022-11-17	Full-text update.
R1.1	2022-06-27	Full-text update.
R1.0	2021-09-09	First edition.

Serial Number: VT20230301

Publishing Date: 2024-11-27 (R1.5)

# **Contents**

1.BMC O	verview	7
1.1	Operating Principle	7
1.2	Functions	9
1.3	Software Security	10
1.4	Operation Interfaces	13
2.Perforn	ning Client Commissioning	14
	eb Operations	19
3.1	Logging In to the Web Portal of the BMC	
3.2	Basic Operations	
3.3	Querying Sensor Information	22
3.4	Querying System Inventory	25
3.5	Querying FRU Information	28
3.6	Alarm and Log Query	28
3.7	Configuration Management	34
3.8	Remotely Controlling a Server	114
3.9	Controlling the Server Power Supply	123
3.10	NIC Information Query	125
3.11	Fan Information and Air Intake Temperature Query	127
3.12	Power Supply Management	128
3.13	Querying KPIs	132
3.14	Maintenance Management	134
3.15	Fault Diagnosis Management	144
4.Commo	on Operations	148
4.1	Logging In to the BMC Management Backend in SSH Mode	
4.2	Logging In to the BMC Management Backend Through the Se- rial Port	150
4.3	Logging In to the Web Portal of the BMC Through the Shared Network Port	153
4.4	Modifying the BMC Address	154
4.5	Querying Server Information	157
4.6	Managing RAIDs	158
4.7	Installing the Operating System Remotely	162
4.8	Resetting the BMC	168
4.9	Querying and Configuring a Temperature Policy	169
4.10	Querying and Configuring Services	172
4.11	Configuring the NTP Server	175
4.12	Configuring the SMTP Server	
4.13	Configuring SNMP Trap	178
4.14	Handling Network Port Alarms	181
4.15	Exporting BMC Logs	181

4.16	Upgrading the BMC Version	186
4.17	Restoring Factory Defaults	188
4.18	Backing Up BMC Configurations	189
4.19	Identifying a Liquid-Cooled Server	189
4.20	Creating an SNMP User	191
5.Referen	nce: Default Passwords	198
	nce: Accessing Documents	
Figures		203
Glossary	/	210

# **About This Manual**

#### **Purpose**

This manual describes the BMC management software of VANTAGEO servers to provide guidance on BMC configuration and management.

#### **Intended Audience**

This manual is intended for:

- Network planning engineers
- Configuration engineers
- Maintenance engineers

#### What Is in This Manual

This manual contains the following chapters.

Chapter 1, BMC Overview	Describes the operating principle and functions of the BMC, software security and operation interfaces.
Chapter 2, Performing Client Commissioning	Describes the debugging operations on the BMC Web portal logged in through a Client.
Chapter 3, BMC Web Operations	Describes the operations on the BMC Web portal.
Chapter 4, Common Operations	Describes common operations in the BMC.
Chapter 5, Reference: Default Passwords	Describes the default passwords that are used to log in to the BMCs in VANTAGEO servers of different models.
Chapter 6, Reference: Accessing Documents	Describes the steps for accessing documents.

#### Conventions

This manual uses the following conventions.

•	Notice: indicates equipment or environment safety information.  Failure to comply can result in equipment damage, data loss, equipment performance degradation, environmental contamination, or other unpredictable results.
	Note: provides additional information about a topic.

# **Chapter 1 BMC Overview**

#### **Table of Contents**

Operating Principle	7
Functions	9
Software Security	10
Operation Interfaces	13

The BMC is the management system of a VANTAGEO server, which monitors and manages server hardware, and provides a Web portal for operation and maintenance, achieving the purposes of software and hardware configuration, fault diagnosis, operating system installation, and operations on the server.

### 1.1 Operating Principle

The BMC consists of a dedicated management chip and the management software operating on the chip.

Dedicated management chip

The server-dedicated management chip provides abundant hardware interfaces and functions. For the hardware interfaces of the BMC, see Figure 1-1.

PCIe device PCIe device PCIe device PCle PCle PCle Host system Host internal Host interaction Remote supervision channel channel management channel BMC Sensor Fan Power Direct supervision Control supervision supervision supervision channel for channel service peripherals channel channel channel PCle Sensor Fan Power LED device

**Figure 1-1 BMC Hardware Interfaces** 

For a description of the BMC channels, refer to Table 1-1.


**Table 1-1 BMC Hardware Channel Descriptions** 

Channel	Typical Physical Link	Typical Management Object or Func-
		tion
Service peripheral su- pervision channel	PCIe and SMBUS	PCIe devices of a server
Host internal supervision channel	SMBUS and PECI	Internal functional units of the CPU or bridge chip
Host interaction channel	PCIe, USB, LPC, KCS, and SM-BUS	Supports KVM, virtual media function, and host serial port functions, and the IP-MI protocol
Direct supervision chan- nel for service peripher- als	SMBUS and NC-SI	PCIe devices of a server
Sensor supervision channel	SMBUS, GPIO, and A/D	Temperature sensor, voltage sensor, current sensor, and presence sensor
Fan supervision channel	PWM	Fan
Power supervision chan- nel	SMBUS	CRPS, and PMBUS power supply
Control channel	GPIO and SGPIO	Power-on, power-off, and indicator on/off
Remote management channel	Ethernet	Accesses the BMC management server

#### Management software

The BMC management software communicates with hardware devices through the management channels to monitor and manage hardware. For the architecture of the BMC management software, see Figure 1-2.

Figure 1-2 BMC Management Software Architecture



#### 1.2 Functions

The BMC is a the management system of a server. It provides abundant management functions.

- Server health status management: Checks the operational status of a server, analyzes historical data and actual monitoring data, and helps users to find and solve problems in advance, ensuring the highly reliable operation of the server.
  - → The 80-code recording function provides sufficient information for analyzing startup failures.
  - → When the system crashes, the last-screen capture function records the on-site scenario for analyzing system crashes.
  - → Screen snapshots and screen recording on preventive maintenance and operation processes facilitate follow-up audits.
  - → The alarm function supports precise fault diagnosis based on components, facilitating component fault locating and replacement.
  - → The CrashDump function facilitates further analysis of system errors.
  - → The BMC supports Syslog, SNMP Trap, e-mails and Redfish subscription functions to report alarms, so that the NMS can collect server fault information easily.
  - → The BMC supports direct display of the server health status through the alarm indicator.
- Host system maintenance

- → Supports virtual KVM and virtual media functions for remote maintenance of the host system.
- → Supports out-of-band monitoring and management of RAIDs, so that RAIDs can be monitored without depending on the host system, and the storage devices in the host system can be configured, which improves configuration efficiency and management capability.
- → Supports OS installation through PXE, which improves the efficiency of remote installation of operating systems in batches.
- Device firmware management
  - → Dual BMCs are supported to ensure the reliable operation.
  - → Dual BIOSs are supported to improve the reliability of BIOS upgrade and operation.
  - → The firmware (for example, the FRU and EPLD) upgrade function is supported.
- System cooling
  - → Monitors the temperature of important components on the server, and performs different cooling controls based on different hardware thermal characteristics.
  - → Supports the over-temperature power-off function to ensure that the server hardware is not damaged, extending the service life of components.
- Intelligent power consumption management
  - → The BMC supports the power capping technology, and provides the standard DCMI for centralized control by the NMS, improving the deployment density of servers.
  - → Energy-saving design reduces the operating costs of a server.
- BMC self-management
  - → Supports synchronizing the BMC time through the network and the host, meeting the requirements in different scenarios.
  - → Supports multiple authentication modes, which simplifies server management.
  - → Supports DHCP and DNS, which simplifies server deployment and management.
- Diversified management interfaces

The BMC meets the requirements of various system integration interfaces by providing the following:

- → Standard DCMI1.5/IPMI2.0/Redfish interfaces
- → Remote command line interfaces and Web management interfaces
- → SNMPv1, SNMPv2 and SNMPv3 interfaces

# 1.3 Software Security

#### **Security Measures for Function Invocation**

- Complete security design: Uses threat modeling for security design.
- Encrypted KVM access: Supports encrypted KVM access.

- HTTPS access with a high encryption security level: Provides an HTTPS trusted path between the server and users to protect local or remote users when they log in to the system through the Web page and prevent communication data from being modified or leaked.
- SSH access with a high encryption security level: Provides an SSH trusted path between
  the server and users, and between servers and other devices to protect local or remote
  users when they log in to the system and prevent communication data from being modified
  or leaked.
- SNMPv3 protocol with a high encryption security level: Supports the SNMPv3 communication security protocol, SHA, and AES.
- IPMI 2.0 protocol with a high encryption security level: Supports the IPMI 2.0 communication protocol, and provides the encryption security technology with a higher level.
- Redfish interface with a high encryption security level: Supports the next-generation standard shelf management interface, with the encryption level higher than the IPMI protocol.
- Protocol and port anti-attack: Disables unused network services and high-risk ports as well
  as insecure protocols by default, including RMCP, Telnet.

#### **Security Measures for User Permissions**

- User role management: User permissions are allocated to logged-in users, and multiple
  management user roles can be allocated. Roles can be divided into different levels. By associating roles, the functional permissions of each user can be restricted to prevent unauthorized operations.
- User account security enhancement: Weak password detection, default strong password, password complexity configuration, password validity period configuration, and forbidding repeated use of the latest three historical passwords during password modification are supported.
- Authentication service: The BMC supports both local authentication access and remote authentication access. Remote access supports authentication through LDAP, and account locking upon login authentication failures. The number of login failures can be configured.
- User access restriction: User access can be restricted by port, source IP address, and MAC
  whitelist. The system supports the functions such as maximum number of sessions, forced
  exit after session timeout, configurable session expiration, multi-session concurrent restriction for a single user, online user management, and forced logout.
- Intrusion alarm: The BMC supports the chassis cover opening alarm to improve system security.
- Certificate service: The BMC supports certificate encryption and import services, which can only be operated by the administrator.

#### **Security Measures for Log Management**

- Log recording: All key system events can be recorded, including the date, time, user, event description, event result, and other related information. The BMC supports recording of component replacement logs.
- Log category: The BMC supports different log categories, including operation logs, system logs, and login logs.
- Log query: The BMC provides log information query permissions for authorized users, and supports allocating log file read permissions by account to prevent log files from being accessed illegally.
- Log protection: Logs are saved in non-volatile storage media. Log information that has been stored cannot be deleted without authorization to prevent modifying the stored log information. Logs are saved for 90 days or longer.
- Centralized alarm management: The BMC supports centralized alarm management for the faults that occur during device operation, allows authorized users to export alarms, and supports alarm reporting through SNMP Trap in a centralized manner.
- Centralized log management: The BMC allows authorized users to export logs, and supports log through Syslog in a centralized manner.
- Reliable timestamp: The BMC supports local time modification and NTP to ensure the time accuracy of system logs and alarms.

#### **Security Measures for Data Security**

- Encrypted data storage: Supports data protection, encrypted data storage, and database password authentication.
- Encrypted data transmission: Supports communication protocols with high encryption security levels such as IPMI 2.0/SNMP V3/SSH/Redfish/HTTPS and the KVM encryption function to ensure data transmission security.
- Data integrity: Supports data integrity check to ensure data verification, storage and transmission.

#### **Security Measures for Version Management**

- Version integrity check: When the server system loads software, the BMC checks the integrity of the software to prevent version confusion or malicious modification caused by error codes during transmission.
- Software upgrade permission control: The BMC records software version and firmware version information. Only the administrator has the permission to upgrade software and firmware and record related operations in logs.

- Version rollback: When an error occurs during the version upgrade process, the version can be rolled back.
- Venerability-free release of software: Before the product software is released, it passes the
  security scan by the security tools such as NSFOCUS, NESSUS, and WebInspect, and
  passes the source code scan for vulnerabilities. In addition, the product software passes
  several rounds of penetration tests to ensure no vulnerability.
- Redundancy: The BMC supports active/standby BMC boots, BMC versions and BMC management ports.
- Strict version release control process: The BMC supports security evaluation of the thirdparty software and plug-ins used. Before a version is released, the BMC scans it by using mainstream anti-virus software. SHA256 check codes are released to prevent version tempering.
- Secure and controllable BMC source code: The BMC source code passes the 100% code
  walkthrough and the Klocwork and Coverity white box security checks and tests, so that the
  potential security vulnerabilities are eliminated and the security is reinforced.

### 1.4 Operation Interfaces

The BMC supports common batch deployment operation interfaces and server management interfaces.

- The batch deployment operation interfaces include:
  - → The IPMI is a standard server interface. It is used for interconnection with the upper-layer NMS or the monitoring software at the host side to implement the functions specified by the IPMI2.0.
  - → The Redfish interface is a standard server interface. It is used for interconnection with the upper-layer NMS to monitor and manage a server.
  - → The SNMP interface is a non-standard server interface. It is used for interconnection with the upper-layer NMS to monitor and manage a server.
- The server management interfaces include:
  - → Web interface
  - → KVM interface
  - → Remote CLI

# **Chapter 2**

# **Performing Client Commissioning**

#### **Abstract**

In most cases, a client (namely, PC) logs in to the Web portal of the BMC through a server's iSAC management network port. Before logging in for the first time, you must debug the iSAC management network port to ensure that the communication with the client is proper.

#### **Prerequisite**

- All the needed tools are ready:
  - → A client PC
  - → Network cables
- One of the following browsers is already installed on the client PC:
  - → Google Chrome 59 or later versions
  - → Firefox 54 or later versions
  - → Microsoft IE 11 or later versions



Google Chrome 59 and later versions are recommended.

The server is powered on.

#### Context

For the position of the iSAC management network port on the rear panel, see Figure 2-1.

Figure 2-1 Position of the iSAC Management Network Port



1

The positions of the iSAC management network ports on the rear panels of the servers are basically the same. This procedure uses the position of the iSAC management network port on the rear panel of an 2230-RE server as an example.

#### **Steps**

- 1. Connect the client PC to the iSAC management network port on the rear panel of the server through a network cable.
- 2. On the client PC, change the IP address of the client PC to an IP address in the same network segment as 192.168.5.7, for example, 192.168.5.8.



The default IP address of the iSAC management network port of the server is 192.168.5.7.


3. On the client PC, start the browser.



The browsers supported include Google Chrome 59, Firefox 54, Microsoft IE 11 and later versions. Google Chrome 59 and later versions are recommended.


4. In the address bar of your browser, enter https://192.168.5.7 and press Enter. The Welcome page is displayed, see Figure 2-2.

Figure 2-2 Welcome Page



If the following information is displayed before the **Welcome** page is displayed, click **Advanced** and select **Proceed to**. The **Welcome** page is displayed.

Figure 2-3 Security Alarm



5. Enter your username and password.



The default username and password are as follows:


- Username: root
- Password: Superuser9!



After you log in to the BMC Web portal by using the default password, you must change the default password immediately. It is recommended that you change the default password to a strong password.

- 6. (Optional) To remember the username, select **Remember Username**.
- 7. Click **Sign me in**. The home page of the Web portal of the BMC is displayed, see Figure 2-4

\_



- 1. Host online status
- 2. Alarm button
- 3. Synchronization button
- 4. Refresh button
- 5. Language button
- 6. Current user
- 7. Overview
- 8. Device control area
- 9. Menu bar
- 8. Set the IP address of the iSAC management network port as planned, for example, 10.235.53.84.

For details, refer to "3.7.8 Configuring IP Settings".

- 9. Record the IP address of the iSAC management network port.
- 10. Connect the iSAC management network port to a switch through a network cable.
- 11. On the client PC, change the IP address of the client PC to one that is in the same network segment as that of the iSAC management network port, for example, 10.235.53.85.
- 12. Connect the client PC to the switch through a network cable.
- 13. Run the ping command in the command line on the client PC to test the connection between the client PC and the iSAC management network port.

# **Chapter 3**

# **BMC Web Operations**

#### **Table of Contents**

Logging In to the Web Portal of the BMC	19
Basic Operations	21
Querying Sensor Information	22
Querying System Inventory	25
Querying FRU Information	28
Alarm and Log Query	28
Configuration Management	34
Remotely Controlling a Server	114
Controlling the Server Power Supply	123
NIC Information Query	125
Fan Information and Air Intake Temperature Query	127
Power Supply Management	128
Querying KPIs	132
Maintenance Management	134
Fault Diagnosis Management	144

# 3.1 Logging In to the Web Portal of the BMC

#### **Abstract**

You can log in to the server BMC Web portal through the specified browser. On this portal, you can configure and manage the server, view server and user information, and perform KVM-based remote control.


#### **Prerequisite**

The IP address of the iSAC management network port is obtained.

#### **Steps**

1. In the address bar of your browser, enter the address of the BMC Web portal, and press **Enter**. The **Welcome** page is displayed, see Figure 3-1.

Figure 3-1 Welcome Page





The address format of the BMC Web portal is as follows: https://IP. "IP" is the IP address of the iSAC management network port.

2. Enter Username and Password.



The default username and password are as follows:

- Username: root
- Password: Superuser9!



After you log in to the BMC Web portal by using the default password, you must change the default password immediately. It is recommended that you change the default password to a strong password.

3. (Optional) To save the login username, select Remember Username.

4. Click **Sign me in**. The home page of the BMC Web portal is displayed.

#### **Related Tasks**

Log out the current user through either of the following ways:

- From the menu bar in the left pane, select **Sign Out**.
- In the upper right corner of the page, click the current user. In the displayed menu, select
   Sign Out.

# 3.2 Basic Operations

For the basic operations that can be performed on the BMC Web portal, refer to Table 3-1.

**Table 3-1 Basic Operation Descriptions** 

Action	Description
View the server overview	From the menu bar in the left pane, select <b>Overview</b> .  The <b>Overview</b> page displays the product information, server information and BMC status information.
View firmware version information	In the <b>Product Information</b> area on the <b>Overview</b> page, view the BMC and BIOS firmware version information.
View the online help	Click in the upper right corner of the page. The help information of the current page is displayed.
View the current user information	After you log in to the BMC Web portal, the current user is displayed in the upper right corner of the page.  Click the current user. On the displayed page, click My Profile. The My Profile page is displayed.
Modify the current user information	<ol> <li>In the upper right corner of the page, click the current user. On the displayed page, click My Profile. The My Profile page is displayed.</li> <li>Select Change Password and change the password.</li> <li>In the Email ID text box, enter your e-mail address.</li> <li>Click Save.</li> </ol>
Sign out the current user	In the upper right corner of the page, click the current user. On the displayed page, click <b>Sign Out</b> .
Control the UID indicator	From the menu bar in the left pane, select <b>Overview</b> .  In the <b>Device Control</b> area in the lower part of the <b>Overview</b> page, you can control the UID indicator on the server panel.  Click <b>UID On</b> . The UID indicator is turned on.  Click <b>UID flashing</b> . The UID indicator flashes, indicating that the administrator is operating the BMC.

Action	Description
	The UID light flashes automatically when the administrator uses the BMC management backend, Web portal, KVM, and virtual media.  Click UID Off. The UID indicator is turned off.  An inactive button indicates the current state of the UID indicator. For example: If the UID flashing button is inactive, it indicates that the UID indicator is flashing.
Check alarms	Click in the upper right corner of the page. All the alarm information received is displayed.
Synchronize sensor information and event logs	Click in the upper right corner of the page. The sensor information and event logs are synchronized.
Refresh the current page	Click Refresh in the upper right corner of the page. The current page is refreshed.
Switch languages	Click the language button in the upper-right corner to change the GUI language.

# 3.3 Querying Sensor Information

#### **Abstract**

By querying sensor information, you can learn about the names, actual values, and operational statuses of all available sensors on the server to help understand server indicators.

Sensor types include:

- Discrete sensor: a sensor used to monitor the presence of components such as hard disks,
   CPUs, fans, or power supplies.
- Normal sensor: a sensor used to monitor KPIs such as temperature, voltage, fan rotation speed, or power.



The Sensor Reading page includes the following areas:

- Critical Sensors
- Discrete Sensor States
- Normal Sensors
- Disabled Sensors

When the actual value of a normal sensor reaches or exceeds the corresponding threshold, the sensor information is displayed in the **Critical Sensors** area. When a sensor is disabled, the sensor information is displayed in the **Disabled Sensors** area.

#### Context

For a description of common sensors, refer to Table 3-2.

**Table 3-2 Sensor Descriptions** 

Sensor Name	Test Object
CPU1(/2)_PCORE	Core power voltage of CPU1 or CPU2
CPU1(/2)_PSOC	SOC power voltage of CPU1 or CPU2
CPU1(/2)_VDDQ_01(/02)	01 or 02 channel memory voltage of CPU1 or CPU2
CPU1(/2)_VCC1V8	1.8 V power voltage of CPU1 or CPU2
CPU1(/2)_VCC0V9S5	0.9 V power voltage of CPU1 or CPU2
CPU1(/2)_VCC1V8S5	1.8 V power voltage of CPU1 or CPU2
BD_VCC3V3	3.3V management power voltage of the mainboard
BAT_VOLTS	CMOS battery voltage of the mainboard
INPUT_TEMP	Intake temperature of the server
OUTPUT_TEMP	Outlet temperature of the server
SYS_TEMP_01	Mainboard temperature of the server
CPU_TEMP_01(/02)	Core temperature of CPU1 or CPU2
CPU_STATUS_01(/02)	Presence status of CPU1 or CPU2
PSU_STATUS_01(/02)	Presence status of the server power module 1 or 2
MEM_TEMP_*1	Surface temperature of each memory bar of the server
FAN_SPEED_01F(/01R/02F/02R/03F/03R/04F/04R)	Actual rotation speed of each fan on the server Only 8056 fans support FAN_SPEED_01R/02R/03R/04R.
FAN_STATUS_01(/02/03/04)	Presence status of each fan on the server
POWER_WATTS	Overall power consumption of the server
INPUT_VOLTS_01(/02)	Input voltage of the server power module 1 or 2
OUTPUT_VOLTS_01(/02)	Working voltage input to the mainboard by the server power module 1 or 2
CPU_VOLTS_01(/02)	Core voltage output by the power supply chip of CPU1 or CPU2
MEM_VOLTS_*1	Power voltage output by the power supply chip of the memory bar on the mainboard

Sensor Name	Test Object
VCORE_TEMP01(/02)	Temperature of the power supply chip for the VCORE voltage of CPU1 or CPU2
PSOC_TEMP_01(/02)	Temperature of the power supply chip for the SOC voltage of CPU1 or CPU2
VDDQ_TEMP_01(/02)_1(/2)	Temperature of the power supply chip for the 01 or 02 channel memory voltage of CPU1 or CPU2
INTRUSION	Cover opening intrusion protection alarm of the server
MEM_STATUS_*1	Presence status of each memory bar on the server




\*1 is the 32 memory bars represented by 1A1-2H2.

#### **Steps**

1. From the menu bar in the left pane, select **Sensor**. The **Sensor Reading** page is displayed, see Figure 3-2.

Figure 3-2 Sensor Reading Page






The **Sensor Reading** page is long, so only a part of it is displayed here.

2. (Optional) Click the icon or name of the sensor whose detailed information is to be viewed. The **Sensor Detail** page is displayed, see Figure 3-3.

Figure 3-3 Sensor Detail Page



3. (Optional) Click **Change Thresholds** to change the alarm thresholds for the sensor.



Thresholds can be changed for only Normal Sensors.

# 3.4 Querying System Inventory

#### **Abstract**

By querying the system inventory, you can learn about the status and details of the CPU and memory of the server.



The CPU, memory, and their corresponding relationships can be displayed in a block diagram or tabular form.

#### **Steps**

1. From the menu bar in the left pane, select **System Inventory**. The **System Inventory** page is displayed, see Figure 3-4.





Figure 3-4 System Inventory—Block Diagram



The colors in the device block diagram have the following meanings:


- Yellow: The CPU is present.
- Green: The memory is present.
- Grey: The memory is not present.
- 2. (Optional) To view the details of a component present, click the component. For example, click any area of **CPU1**, the details of CPU1 are displayed, see Figure 3-5.

Figure 3-5 CPU1 Details Page



3. (Optional) On the **System Inventory** page, select **Table View**. The system inventory is displayed in a tabular form, see Figure 3-6.

Figure 3-6 System Inventory—Table





The **System Inventory** page is long, so only a part of it is displayed here.

# 3.5 Querying FRU Information


#### **Abstract**

FRUs include the mainboard, backplane, and cards that can be replaced on site. Before replacement, you must query the FRU information to learn about the details of the replaceable unit to be replaced.

#### **Steps**

 From the menu bar in the left pane, select FRU Information. The FRU page is displayed, see Figure 3-7.

#### Figure 3-7 FRU Page



2. From the **FRU Device ID** list, select the slot number of the FRU device. The detailed information of the FRU device is displayed in the lower part of the page.

# 3.6 Alarm and Log Query

# 3.6.1 Querying Alarms


#### **Abstract**

By querying alarms, you can learn about the alarm information of the actual system events on the server.

#### **Steps**

 From the menu bar in the left pane, select Alarms & Logs > Current Alarm. The Current Alarm page is displayed, see Figure 3-8.

Figure 3-8 Current Alarm Page



2. Perform the following operations as required.

То	Do
Filter alarms by date	Click in the <b>Filter by Date</b> area and set the start date and end date for querying operation alarms.
Filter alarms by keyword	<ul><li>a. In the Filter by Keyword text box, enter a keyword.</li><li>b. Press Enter. The results filtered by the keyword are displayed on the page.</li></ul>
Save the alarm information to the local PC	Click <b>Download Current Alarms</b> and save the alarm information to the local PC.

### 3.6.2 Querying Login Logs


#### **Abstract**

Login logs record user logins and logouts of the BMC Web portal, BMC command lines, and KVM information.

#### **Steps**

 From the menu bar in the left pane, select Alarms & Logs > Audit Log. The Audit Log page is displayed, see Figure 3-9.

Figure 3-9 Audit Log Page



2. Perform the following operations as required.

То	Do
Filter logs by date	Click in the <b>Filter by Date</b> area and set the start date and end date for querying login logs.
Filter logs by keyword	<ul><li>a. In the Filter by Keyword text box, enter a keyword.</li><li>b. Press Enter. The results filtered by the keyword are displayed on the page.</li></ul>
Save logs to the local PC	Click <b>Download Audit Logs</b> and save the login logs to the local PC.

### 3.6.3 Querying Operation Logs


#### **Abstract**

Operation logs record the information about users' operations on the server, including manual server operations and remote server operations.

#### **Steps**

From the menu bar in the left pane, select Alarms & Logs > Operation Log. The Operation Log page is displayed, see Figure 3-10.

Figure 3-10 Operation Log Page



2. Perform the following operations as required.

То	Do
Filter logs by date	Click on the <b>Filter by Date</b> area and set the start date and end date for querying operation logs.
Filter logs by keyword	a. In the <b>Filter by Keyword</b> text box, enter a keyword.     b. Press <b>Enter</b> . The results filtered by the keyword are displayed on the page.
Save logs to the local PC	Click <b>Download Operation Logs</b> and save the operation logs to the local PC.

### 3.6.4 Querying System Logs


#### **Abstract**

System logs record log and alarm information generated during the operation of the server.

#### **Steps**

1. From the menu bar in the left pane, select **Alarms & Logs > System Log**. The **System Log** page is displayed, see Figure 3-11.

Figure 3-11 System Log Page



2. Perform the following operations as required.

То	Do
Filter logs by date	Click on the <b>Filter by Date</b> area and set the start date and end date for querying system logs.
Filter logs by keyword	<ul><li>a. In the Filter by Keyword text box, enter a keyword.</li><li>b. Press Enter. The results filtered by the keyword are displayed on the page.</li></ul>
Save logs to the local PC	Click <b>Download System Logs</b> and save the system logs to the local PC.
Clear logs	Click Clear System Logs to clear logs.

### 3.6.5 Querying Event Logs


#### **Abstract**

Event logs record event information generated during the operation of the server.

#### **Steps**

1. From the menu bar in the left pane, select **Alarms & Logs > Event Log**. The **Event Log** page is displayed, see Figure 3-12.

Figure 3-12 Event Log Page



2. Perform the following operations as required.

То	Do
Filter logs by date	Click in the <b>Filter by Date</b> area and set the start date and end date for querying system logs.
Filter logs by event type	From the <b>Filter by type</b> list, select the event log type to be queried.
Filter logs by sensor	From the Sensor list, select the sensor to be queried.
Save logs to the local PC	Click <b>Download Event Logs</b> and save the event logs to the local PC.
Clear logs	Click Clear Event Logs to clear logs.

### 3.6.6 Querying Video Logs

#### **Abstract**

Video logs record the contents displayed on the screen before a server crashes, restarts, or is powered off.

#### **Prerequisite**

The video recording function is enabled. For details, refer to "3.7.25 Configuring Screen Recording Parameters".

#### **Steps**

- From the menu bar in the left pane, select Alarms & Logs > Video Log. The Video Log
  page is displayed.
- 2. Perform the following operations as required.

То	Do
Filter logs by date	Click in the <b>Filter by Date</b> area and set the start date and end date for querying video logs.
Play video logs	In the log list, click the details of the video logs that you want to play. A dialog box for playing videos is displayed.
Clear logs	Click on the right side of the logs that you want to clear.

# 3.7 Configuration Management

### 3.7.1 Configuring the Time Synchronization Mode

#### **Abstract**

This procedure describes how to configure the time synchronization mode so that the BMC can obtain the correct time.


#### **Prerequisite**

To select **Sync from DHCPv4 NTP** or **Sync from DHCPv6 NTP**, you must enable the DHCP function on the management network port or shared network port. For details, refer to "3.7.8 Configuring IP Settings".

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Date & Time. The Date & Time page is displayed, see Figure 3-13.

Figure 3-13 Date & Time Page



3. Select the BMC time synchronization mode and configure the corresponding parameters.

То	Do
Perform NTP-based synchronization	<ul> <li>a. Select Syn from NTP.</li> <li>b. Configure the following parameters:</li> <li>Primary NTP Server: Enter the IP address or FQDN of the primary NTP server, with the length not exceeding 127 characters. This parameter is required.</li> <li>Secondary NTP Server: Enter the IP address or FQDN of the secondary NTP server, with the length not exceeding 127 characters. The parameter is optional.</li> <li>Tertiarydary NTP Server: Enter the IP address or FQDN of the tertiary NTP server, with the length not exceeding 127 characters. The parameter is optional.</li> <li>Sync Period(s): Enter the time synchronization period in seconds, range: 60–65535.</li> <li>The parameters of the three NTP servers cannot be the same.</li> </ul>
Perform DHCPv4 NTP-based synchronization	Select Sync from DHCPv4 NTP.

То	Do
Perform DHCPv6 NTP-based synchronization	Select Sync from DHCPv6 NTP.
Perform BIOS-based synchronization	<ul> <li>a. Select Syn from BIOS.</li> <li>b. Configure BIOS Time: <ul> <li>If the server runs the Linux operating system, select either Local time or UTC time, and configure the time zone the same as that of the server.</li> <li>If the server runs the Windows operating system and the operating system uses UTC time, select either Local time or UTC time, and configure the time zone to 0.</li> <li>If the server runs the Windows operating system and the operating system uses local time, select Local time, and configure the time zone the same as that of the server.</li> <li>UTC time is the universal time coordinated (UTC time = local time - time zone difference). For example, if Beijing time is 08:00, the UTC time is 00:00.</li> </ul> </li> </ul>



If **Sync from NTP** is selected as the time synchronization mode, the BMC synchronizes with **Primary NTP Server** first. If the synchronization fails, the BMC will synchronize time with **Secondary NTP Server** and **Tertiarydary NTP Server** in turn.


4. Click Save.

#### Verification

If **Sync from NTP** is selected, perform the following operations to check time consistency:

1. Check the date and time on the **Configure Date & Time** page, see Figure 3-14.

Figure 3-14 Configure Date & Time Page



2. Check the NTP server to see if the time is consistent with the time of the BMC.

# 3.7.2 Configuring Authentication Parameters for External Users

#### Abstract

To authenticate external users through the LDAP server or AD server, you must configure authentication parameters for external users.



External users refer to non-BMC users.

### **Prerequisite**

The following parameters of the LDAP server or AD server are obtained:

- LDAP server
  - → Server address
  - → Port
  - → Bound identity name
  - → Password

- → Search base
- → User login attribute
- → CA file
- → Certificate file
- → Private key
- → Group name
- → Group domain




If **Encryption Type** is set to **StarTLS**, the following parameters are needed:

- → CA file
- → Certificate file
- → Private key
- AD server
  - → Username
  - → Password
  - → User's domain name
  - → Server address of the domain controller
  - → Group name
  - → Group domain

- Configuring LDAP Server Authentication Parameters
  - 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
  - 2. Click External User Services. The External User Services page is displayed.
  - 3. Click LDAP/E-directory Settings. The LDAP/E-directory Settings page is displayed.
  - 4. Click **General Settings**. The **General LDAP Settings** page is displayed, see Figure 3-15.

Figure 3-15 General LDAP Settings Page



5. Configure the parameters. For a description of the parameters, refer to Table 3-3.


**Table 3-3 Parameter Descriptions for the General LDAP Settings** 

Parameter	Description	Setting
Enable LDAP/E-di-	Whether to enable LDAP au-	→ Select Enable LDAP/E-directory Authentica-
rectory Authentica-	thentication.	tion to enable LDAP authentication.
tion		

Parameter	Description	Setting
		→ Clear Enable LDAP/E-directory Authentica- tion to disable LDAP authentication.
Encryption Type	LDAP encryption type.	Select the corresponding encryption type:  → No Encryption: No encryption.  → SSL: The SSL is used for encryption.  → StarTLS: The StarTLS is used for encryption.
Common Name Type	Address type of the LDAP server.	Select the corresponding name type:  → IP Address: The LDAP server address is identified in IP format.  → FQDN: The LDAP server address is identified in FQDN format.  The FQDN option is available only when Encryption Type is set to StarTLS.
Server Address	Address of the LDAP server.	<ul> <li>→ If Common Name Type is set to IP Address, enter the IP address of the LDAP server, which supports the IPv4 and IPv6 formats.</li> <li>→ If Common Name Type is set to FQDN, enter the FQDN address of the LDAP server.</li> </ul>
Port	Port number of the LDAP server.	Enter the port number, with a range of 1–65535.  The default port number is 389.  If <b>Encryption Type</b> is set to <b>SSL</b> , enter the port number 636.
Bind DN	Identity name used to log in to the LDAP server.	Enter the bound identity name, for example, cn=manager,ou=login, dc=domain,d-c=com.
Password	Password used to log in to the LDAP server.	Enter the password. It cannot be left blank. Range of password length: 1–48 characters.
Search Base	Directory where external user information is stored on the LDAP server.	Enter the search base, for example, ou=lo-gin, dc=domain, dc=com.
Attribute of User Login	User login attribute.	Select the corresponding attribute of user login.
CA certificate file	-	The CA file needs to be uploaded only when Encryption Type is set to StarTLS.
Certificate File	-	The certificate file needs to be uploaded only when <b>Encryption Type</b> is set to <b>StarTLS</b> .
Private Key	-	The private key file needs to be uploaded only when <b>Encryption Type</b> is set to <b>StarTLS</b> .

- 6. Click Save.
- On the LDAP/E-directory Settings page, click Role Groups. The Role Groups page is displayed.
- 8. Click the icon for the new role group. The **Role Groups** page is displayed, see Figure 3-16.

Figure 3-16 Role Groups Page



9. Configure the parameters. For a description of the parameters, refer to Table 3-4.

**Table 3-4 Role Groups Parameter Descriptions** 


Parameter	Description	Setting
Group Name	Name of the role group.	Enter the group name.
Group Domain	Domain where the role group is located.	Enter the group domain.
Group Privilege	Permissions of the role group on the BMC.	Select a permission for the role group:  → Administrator: administrator permission  → Operator: operator permission  → User: viewer permission  → None: no permission
KVM Access	Whether the role group can access the KVM.	→ Select KVM Access. The role group can access the KVM.

Parameter	Description	Setting
		→ Clear KVM Access. The role group cannot access the KVM.
VMedia Access	Whether the role group can access the VMedia.	<ul> <li>→ Select VMedia Access. The role group cannot access the VMedia.</li> <li>→ Clear VMedia Access. The role group cannot access the VMedia.</li> </ul>

#### 10. Click Save.

- Configuring AD Server Authentication Parameters
  - 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
  - 2. Click External User Services. The External User Services page is displayed.
  - 3. Click **Active Directory Settings**. The **Active Directory Settings** page is displayed.
  - 4. Click **General Settings**. The **General Active Directory Settings** page is displayed, see Figure 3-17.

**Figure 3-17 General Active Directory Settings Page** 



5. Configure the parameters. For a description of the parameters, refer to Table 3-5.


**Table 3-5 Parameter Descriptions for the General Active Directory Settings** 

Parameter	Description	Setting
Enable Active di- rectory Authentica-	Whether to enable AD authentication.	→ Select Enable Active Directory Authentication to enable AD authentication.
tion		Clear Enable Active Directory Authentication to disable AD authentication.
Secret Username	Username for logging in to the AD server.	Enter the username consisting of 1–64 letters or digits.  If the username and password are not required, leave this parameter blank.

Parameter	Description	Setting
Secret Password	Password for logging in to the AD server.	Enter the password consisting of 6–127 characters.  If the username and password are not required, leave this parameter blank.
User Domain Name	Domain name of the AD server.	Enter the domain name of the user, for example,  MyDomain.com.
Domain Controller Server Address 1	Address 1 of the AD server.	Enter the IP address 1 of the AD server, which supports IPv4 and IPv6, and is required.
Domain Controller Server Address 2	Address 2 of the AD server.	Enter the IP address 2 of the AD server, which supports IPv4 and IPv6, and is optional.
Domain Controller Server Address 3	Address 3 of the AD server.	Enter the IP address 3 of the AD server, which supports IPv4 and IPv6, and is optional.

- 6. Click Save.
- 7. On the **Active Directory Settings** page, click **Role Groups**. The **Role Groups** page is displayed.
- 8. Click the icon for the new role group. The **Role Groups** page is displayed, see Figure 3-18.

Figure 3-18 Role Groups Page



9. Configure the parameters. For a description of the parameters, refer to Table 3-6.

**Table 3-6 Role Groups Parameter Descriptions** 

Parameter	Description	Setting
Group Name	Name of the role group.	Enter the group name.
Group Domain	Domain where the role group is located.	Enter the group domain.
Group Privilege	Permissions of the role group on the BMC.	Select a permission for the role group:  → Administrator: administrator permission  → Operator: operator permission  → User: viewer permission  → None: no permission
KVM Access	Whether the role group can access the KVM.	<ul> <li>→ Select KVM Access. The role group can access the KVM.</li> <li>→ Clear KVM Access. The role group cannot access the KVM.</li> </ul>
VMedia Access	Whether the role group can access the VMedia.	<ul> <li>→ Select VMedia Access. The role group cannot access the VMedia.</li> <li>→ Clear VMedia Access. The role group cannot access the VMedia.</li> </ul>

10. Click Save.

#### Verification

- If the LDAP server authentication parameters are configured, log in to the BMC Web portal on the LDAP server to check whether the login is successful.
- If the AD server authentication parameters are configured, log in to the BMC Web portal on the AD server to check whether the login is successful.

# 3.7.3 Configuring a KVM Mouse Mode

#### **Abstract**

This procedure describes how to configure the mouse mode used during remote control based on personal habits.




In addition to the BMC Web portal, the mouse mode can also be configured in the KVM. The mouse mode configured on the BMC Web portal and that configured in the KVM are automatically synchronized. The latest configured mouse mode shall prevail.

For a description of the mouse mode configurations in the KVM, refer to "3.8 Remotely Controlling a Server".

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click KVM Mouse Settings. The KVM Mouse Settings page is displayed, see Figure 3-19.

Figure 3-19 KVM Mouse Settings Page



3. Select a mouse mode as required. For a description of the mouse modes, refer to Table 3-7.

**Table 3-7 Mouse Mode Descriptions** 

Mouse Mode	Description
Relative Positioning (Linux)	Calculates the displacement of the local mouse relative to the server mouse, and transfers it to the server to make the mouse on the server move.
Absolute Positioning (Windows)	Transfers the absolute position of the local mouse to the server to make the mouse on the server move.
Other Mode (SLES-11 OS Installation)	Calculates the displacement of the local mouse relative to the center position, and transfers it to the server to make the mouse on the server move.

4. Click Save.

# 3.7.4 Configuring Remote Log Parameters

#### **Abstract**

This procedure describes how to configure remote log parameters to upload local logs (including login logs, operation logs, and system logs) to a remote log server.

#### **Steps**

#### **Configuring a Remote Log Destination**

1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.


- 2. Click Log Settings. The Log Settings page is displayed.
- 3. Click Remote Log Settings. The Remote Log Settings page is displayed, see Figure 3-20.

Figure 3-20 Remote Log Settings Page



4. Click any **Destination**. The **Remote Log Destination Settings** page is displayed, see Figure 3-21.

Figure 3-21 Remote Log Destination Settings Page



5. Configure the parameters. For a description of the parameters, refer to Table 3-8.

**Table 3-8 Parameter Descriptions for the Remote Log Destination** 


Parameter	Description	Setting
Enable Remote Log	Whether to upload local logs to a remote log server.	Select Enable Remote Log.
Remote Log Server	IP address or host name of the remote log server.	<ul> <li>Enter the IP address or host name of the remote log server.</li> <li>The IP address supports the IPv4 and IPv6 formats.</li> <li>The host name must comply with the FQDN format, with a maximum length of 255 characters.</li> </ul>
Remote Server Port	Port number of the remote server.	Enter the port number of the remote server. Port number range: 1–65535, 514 by default.
Transfer Content	Log type for remote transmission:  Audit log: Records user logins and logouts of the BMC Web portal, BMC command lines, and KVM information.  Operation log: Records the information about users' operations on the server, including manual operations and remote operations.  System log: Records log and alarm information generated during the operation of the server.	Select the type(s) of logs to be transmitted remotely.

6. Click Save.

### **Configuring a Remote Log Policy**

7. On the **Log Settings** page, click **Remote Log Policy**. The **Remote Log Policy** page is displayed, see Figure 3-22.

Figure 3-22 Remote Log Policy Page



8. Configure the parameters. For a description of the parameters, refer to Table 3-9.

**Table 3-9 Parameter Descriptions for the Remote Log Policy** 

Parameter	Description	Setting
Transport Protocol	Protocol used to upload remote logs.	Select a transport protocol.
Server Identity	Server identity type.	Select the type to identify the host.

- 9. Click Save.
- 10.(Optional) In the Send test log area, click Send. The Syslog test log is sent to the remote log server.

#### Verification

1. Log in to or log out of the BMC Web portal.



When configuring parameters in the **Transfer Content** area in Step 5, make sure **Audit Log** is selected. Otherwise, the login log generated from logging in/out the BMC Web portal will not be uploaded to the remote log server.

2. Check the remote log server to see if the newly generated login log is received.

### 3.7.5 Configuring the Event Log Storage Policy

#### **Abstract**

Event logs are the records of the events that occur during the operation of the server. This procedure describes how to configure the event log storage policy.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- Click Log Settings. The Log Settings page is displayed.
- 3. Click Log Policy. The Log Policy page is displayed, as shown in Figure 3-23.

Figure 3-23 Log Policy Page



- 4. Select the desired event log storage policy.
  - **Linear Storage Policy**: After the hard disk for storing event logs is full, all old logs are cleared and then new logs are stored.
  - Cyclic Storage Policy: After the hard disk for storing event logs is full, the oldest event logs are overwritten by the newly generated event logs.
- 5. Click Save.

# 3.7.6 Configuring VMedia Instance Parameters


#### **Abstract**

Before mounting a CD/DVD and HD on the KVM, you must configure the VMedia instance parameters.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Media Redirection Settings. The Media Redirection page is displayed.

3. Click **VMedia Instance Settings**. The **VMedia Instance Settings** page is displayed, see Figure 3-24.

Figure 3-24 VMedia Instance Settings Page



4. Configure the parameters. For a description of the parameters, refer to Table 3-10.

**Table 3-10 Parameter Descriptions for the VMedia Instance Settings** 

Parameter	Description	Setting
CD/DVD device instances	Number of CDs/DVDs on the client PC.	Select 1 by default.
Hard disk instances	Number of HDs on the client PC.	Select 1 by default.
Remote KVM CD/ DVD device in- stances	Number of CDs/DVDs mounted on the KVM.	Select 1 by default.
Remote KVM Hard disk instances	Number of HDs mounted on the KVM.	Select 1 by default.
Encrypt Media Redirection Pack- ets	Whether to encrypt files when uploading them remotely.	Clear Encrypt Media Redirection Packets.

5. Click Save.

## 3.7.7 Configuring Remote Session Parameters

#### **Abstract**

Before controlling a server remotely, you must configure the remote session parameters.

The server can be remotely controlled in the following ways:


- KVM
- VNC




You cannot remotely control the server through KVM and VNC simultaneously.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Media Redirection Settings. The Media Redirection page is displayed.
- Click Remote Session. The Remote Session page is displayed, see Figure 3-25 and Figure 3-26.

Figure 3-25 Remote Session Page-KVM



**Figure 3-26 Remote Session Page-VNC** 



4. Set the parameters. For a description of the parameters, refer to Table 3-11 and Table 3-12.

**Table 3-11 Parameter Descriptions for Remote Session-KVM** 

Parameter	Description	Setting
KVM (JView- er/H5Viewer)	Whether to remotely control the server through KVM.	Select KVM (JViewer/H5Viewer).
VNC	Whether to remotely control the server through VNC.	Clear <b>VNC</b> .
KVM Single Port Application	Whether to use the <b>443</b> port when the KVM is started in HTML mode.	When KVM Single Port Application is selected, Enable KVM Encryption is not available.
Keyboard Lan- guage	Keyboard language used during remote KVM operations.	The <b>Auto Detect(AD)</b> parameter is selected by default.
Virtual Media At- tach Mode	Whether to reconnect the virtual drive automatically when the network is disconnected.	Select a virtual media connection mode:  • Attach: not reconnected automatically.  • Auto Attach: reconnected automatically.
Automatically OFF Server Mon- itor When KVM Launches	Whether to automatically shut down the physical display during remote KVM operations.	The Automatically OFF Server Monitor When KVM Launches parameter is cleared by default.

**Table 3-12 Parameter Descriptions for Remote Session-VNC** 

Parameter	Description	Setting
KVM (JView-	Whether to remotely control	Clear KVM port number.
er/H5Viewer)	the server through KVM.	

Parameter	Description	Setting
VNC	Whether to remotely control the server through VNC.	Select VNC.
Password	Password used for remote server control through VNC.	The password consists of numbers, letters and special characters, and the length of the password does not exceed 8 digits.  If the password is empty, the default password is used. The default password is Supcnv9@.

5. Click Save.

## 3.7.8 Configuring IP Settings

#### **Abstract**

To re-plan the IP settings of the iSAC management network port or shared network port of the server, you must configure the IP address, subnet mask, default gateway, and other related information.

In most cases, **eth0** is the shared network port and **eth1** is the management network port. The shared network port can be used as a service network port or management network port. If the management network port is abnormal, the shared network port can be used as the management network port.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Network Settings**. The **Network Settings** page is displayed.
- Click Network IP Settings. The Network IP Settings page is displayed, see Figure 3-27 and Figure 3-28.

Figure 3-27 Network IP Settings Page (Shared Network Port)





Figure 3-28 Network IP Settings Page (Management Network Port)



4. Configure the parameters. For a description of the parameters, refer to Table 3-13.

**Table 3-13 Parameter Descriptions for the Network IP Address Configuration** 

Parameter	Description	Setting
Enable LAN	Whether to enable the network port.  The network port is selected from the LAN Interface list.	<ul> <li>Select Enable LAN. The network port is enabled.</li> <li>Deselect Enable LAN. The network port is disabled.</li> </ul>
LAN Interface	Current network port.	<ul> <li>To configure the management network port, select eth1.</li> <li>To configure the shared network port, select eth0.</li> </ul>
MAC Address	MAC address of the corresponding network port.	This parameter is displayed only and cannot be configured.
Enable IPv4	Whether the network port enables the IPv4 protocol.	<ul> <li>Select Enable IPv4. The IPv4 protocol is enabled.</li> <li>Clear Enable IPv4. The IPv4 protocol is disabled.</li> <li>The IPv4-related parameters can be configured only after Enable IPv4 is selected.</li> <li>To automatically obtain the IP address, select IPv4 DHCP.</li> <li>To manually configure the IP address, deselect IPv4 DHCP, and manually configure IPv4 Address, IPv4 Subnet and IPv4 Gateway.</li> <li>The IP addresses of the management network port and the shared network port must not be in the same network segment.</li> </ul>
Enable IPv6	Whether the network port enables the IPv6 protocol.	<ul> <li>Select Enable IPv6. The IPv6 protocol is enabled.</li> <li>Clear Enable IPv6. The IPv6 protocol is disabled.</li> <li>The IPv6-related parameters can be configured only after Enable IPv6 is selected.</li> <li>To automatically obtain the IP address, select IPv6 DHCP.</li> <li>To manually configure the IP address, deselect IPv6 DHCP, and manually configure IPv6 Address, Subnet Prefix Length and IPv6 Gateway.</li> <li>The IP addresses of the management network port and the shared network port must not be in the same network segment.</li> </ul>

Parameter	Description	Setting
Enable VLAN	Whether the network port en-	Select Enable VLAN. The network port can be
	ables VLAN.	added into a VLAN.
		Clear Enable VLAN. The network port cannot
		be added into a VLAN.
		The VLAN-related parameters can be configured
		only after Enable VLAN is selected.
		● VLAN ID: 1–4094.
		• VLAN Priority: 0–7, with 7 of the highest priori-
		ty.

5. Click Save.

## 3.7.9 Configuring Network Bonding

#### **Abstract**


If the shared network port eth0 and the iSAC management network port eth1 are bonded, you can access the BMC through the IP address of either network ports even if only one of the two ports is connected.

#### **Prerequisite**

The VLAN function of both the shared network port and the iSAC management network port has been disabled. For details, refer to "3.7.8 Configuring IP Settings".

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Network Settings**. The **Network Settings** page is displayed.
- 3. Click **Network Bond Configuration**. The **Network Bond Configuration** page is displayed, see Figure 3-29.

**Figure 3-29 Network Bonding Configuration Page** 



4. Set the parameters. For a description of the parameters, refer to Table 3-14.

**Table 3-14 Parameter Descriptions for Network Bonding** 

Parameter	Description	Setting
Enable Bonding	Whether to enable network bonding.	<ul> <li>If you select Enable Bonding, the network bonding function is enabled.</li> <li>If you clear Enable Bonding, the network bonding function is disabled.</li> </ul>
Bond Interface	Select the network port that provides the external network service.	<ul> <li>If you select eth0, the shared network port eth0 provides the external network service.</li> <li>if you select eth1, the iSAC management network port eth1 provides the external network service.</li> </ul>

5. Click Save.

# 3.7.10 Configuring the DNS


#### **Abstract**

To access the BMC Web portal through FQDN, you must configure the DNS information for the management network port and shared network port of the server.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Network Settings**. The **Network Settings** page is displayed.

3. Click DNS Configuration. The DNS Configuration page is displayed, see Figure 3-30.

**Figure 3-30 DNS Configuration Page** 





The **DNS Configuration** page is long, so only a part of it is displayed here.

4. Configure the parameters. For a description of the parameters, refer to Table 3-15.

**Table 3-15 DNS Configuration Parameter Descriptions** 

Parameter	Description	Setting
DNS Enabled	Whether to enable the DNS	Select <b>DNS Enabled</b> . The DNS service is en-
	service.	abled.
		Clear DNS Enabled. The DNS service is dis-
		abled.

Parameter	Description	Setting
mDNS Enabled	Whether to enable the multicast DNS access.	<ul> <li>Select mDNS Enabled. The multicast DNS service is enabled.</li> <li>Clear mDNS Enabled. The multicast DNS service is disabled.</li> </ul>
BMC Registration Settings	Whether to register DNS for eth1 (management network port) and eth0 (shared network port).	<ul> <li>Select Register BMC under eth0. The DNS is registered for eth0.</li> <li>Select Register BMC under eth1. The DNS is registered for eth1.</li> <li>The BMC registration methods include:         <ul> <li>Nsupdate: Uses a name server application to register on the DNS server.</li> <li>DHCP Client FQDN: Uses the DHCP option 81 to register on the DNS server.</li> <li>Hostname: Uses the DHCP option 12 to register on the DNS server.</li> </ul> </li> <li>If the DHCP server does not support the DHCP option 81, select Hostname.</li> </ul>
Domain Setting	Way to set the domain name.	<ul> <li>If Automatic is selected, the domain name is set automatically.</li> <li>If Manual is selected, you must set the domain name manually.</li> <li>The length of a domain name should not exceed 63 characters per label, and the length of the FQDN should not exceed 255 characters.</li> </ul>
Domain Name Server Setting	Way to set the domain name server.	<ul> <li>If Automatic is selected, the DNS server information is obtained automatically.</li> <li>If Manual is selected, you must configure the DNS server information manually, and configure Primary NTP Server, Secondary NTP Server and Tertiarydary NTP Server.         The Primary NTP Server parameter must be set, while others are optional. Primary NTP Server, Secondary NTP Server and Tertiarydary NTP Server cannot be set to the same value.     </li> </ul>

5. Click Save.

## Verification

1. On the DNS server, check the registration information about the BMC, including the domain name and host name.


For example, if the parameters are configured as shown in Table 3-16 on the **DNS Configuration** page, the domain name is **vantageo.com** and the host name **test111**.

**Table 3-16 Example of DNS Configuration Parameter** 

Parameter	Description
DNS Enabled	The DNS Enabled parameter is selected.
mDNS Enabled	The mDNS Enabled parameter is unselected.
BMC Registration Settings	The <b>Register BMC</b> parameter under eth1 is selected.  The <b>Hostname</b> parameter is selected for <b>Registration Method</b> .
Domain Setting	The <b>Manual</b> parameter is selected, and the <b>Domain Name</b> parameter is set as <b>vantageo.com</b>
Domain Name Server Setting	The Manual parameter is selected and Primary NTP Server is configured.  The IP address of Primary NTP Server must be in the same network segment as that of the management network port (eth1).

2. Visit the BMC Web portal through FQDN and check whether the **Welcome** page of the BMC Web portal is accessible, see Figure 3-31.

Figure 3-31 Welcome Page



# 3.7.11 Configuring a Hostname

#### **Abstract**

A hostname is used to identify a server.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Network Settings. The Network Settings page is displayed.
- 3. Click **Host Name Setting**. The **Host Name Setting** page is displayed, as shown in Figure 3-32.

**Figure 3-32 Hostname Setting Page** 



4. Set the parameters. For a description of the parameters, refer to Table 3-17.

**Table 3-17 Hostname Parameter Descriptions** 

Parameter	Description	Setting
Host Name Setting	Sets the hostname setting mode.	<ul> <li>Automatic: A hostname is automatically set by the system.</li> <li>Manual: A hostname needs to be manually entered in the Host Name text box.</li> </ul>
Host Name	Hostname of the server.	This parameter is required if <b>Host Name Settings</b> is set to <b>Manual</b> .  Enter the hostname. A maximum of 63 characters can be entered, including digits, letters, hyphen (-), and underscores (_). It cannot contain spaces and is case insensitive. The first character must be a letter or digit, and the last character cannot be a hyphen (-).

5. Click Save.


# 3.7.12 Configuring NCSI

#### **Abstract**

You can specify a shared network port by configuring the NCSI.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Network Settings. The Network Settings page is displayed.
- 3. Click **Sideband Interface (NC-SI)**. The **Sideband Interface (NC-SI)** page is displayed, see Figure 3-33.

Figure 3-33 Sideband Interface (NC-SI) Page



4. Configure the parameters. For a description of the parameters, refer to Table 3-18.

**Table 3-18 NCSI Configuration Parameter Descriptions** 

Parameter	Description	Setting
NCSI Mode	Way to specify a shared net-	Select the NCSI mode:
	work port.	Auto Failover Mode: When the shared net-
		work port is abnormal, the server automatically
		switches to a network port in normal status as
		the shared network port.
		If NCSI Mode is set to Auto Failover Mode, you
		do not need to set any other parameters.
		Manual Switch Mode: You must manually
		specify a network port as the shared network
		port.

Parameter	Description	Setting
		If NCSI Mode is set to Manual Switch Mode, you must set NCSI Interface, Channel Number and Package ID.
NCSI Interface	Name of the NCSI.	Select eth0 by default.
Channel Number	Network port number.	Select the number of the network port used as the shared network port.
Package ID	NIC ID.	Select the ID of the NIC where the shared network port is located.

5. Click Save.

## 3.7.13 Configuring Network Self-Adaptive Mode

#### Abstract


After the network self-adaptive mode is enabled, you can access the BMC through the IP address of the management network port regardless of whether the iSAC management network port or shared network port is in **UP** status.

#### **Prerequisite**

The network bonding function has been disabled. For details, refer to "3.7.9 Configuring Network Bonding".

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Network Settings. The Network Settings page is displayed.
- Click Network Adaptive Configuration. The Network Auto Settings page is displayed, see Figure 3-34.

Figure 3-34 Network Auto Settings Page



4. Set the parameters. For a description of the parameters, refer to Table 3-19.

**Table 3-19 Parameter Descriptions for Network Self-Adaptive Mode** 

Parameter	Description	Setting
Enable Network Auto	Whether to enable network self-adaptive mode.	<ul> <li>If you select Enable Network Auto, the network self-adaptive mode is enabled.</li> <li>If you clear Enable Network Auto, the network self-adaptive mode is disabled.</li> </ul>

5. Click Save.

# 3.7.14 Configuring LLDP

#### **Abstract**

After LLDP is enabled on a server, you can obtain the device information from adjacent network ports on the switch through LLDP packets.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Network Settings. The Network Settings page is displayed.
- 3. Click **LLDP Configuration**. The **LLDP Configuration** page is displayed, as shown in Figure 3-35.

Figure 3-35 LLDP Configuration Page



4. Set the parameters. For a description of the parameters, refer to Table 3-20.

**Table 3-20 LLDP Parameter Descriptions** 

Parameter	Description	Setting
Enable LLDP	Whether to enable LLDP.	<ul> <li>To enable LLDP, select Enable LLDP.</li> <li>To disable LLDP, deselect Enable LLDP.</li> </ul>
Work Mode	LLDP working mode.	Select a LLDP working mode:  Receive: only receives LLDP packets.  Send And Receive: sends and receives LLDP packets.

5. Click Save.

# 3.7.15 Querying RAID Information

#### **Abstract**

#### **RAID** information includes:

- Controller information: detailed information of the RAID controller, including the serial number, version number, and health status.
- Storage summary information: storage summary information of the RAID controller, including the number of physical devices, and that of logical devices.
- Physical device information: information of all the physical disks managed by the RAID controller.
- Logical device information: information of all the logical disks managed by the RAID controller
- BBU information: battery information of the RAID controller.
- Event record: event list of the RAID controller.
- NVMe device information: NVMe device information.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click RAID Management. The RAID Management page is displayed, see Figure 3-36.

**Figure 3-36 RAID Management Page** 



3. Perform the following operations as required.

То	Do
Query RAID controller information	<ul> <li>a. Click RAID Controller Information. The RAID Controller Information page is displayed.</li> <li>b. From the RAID Controller list, select the RAID controller you want to query. The information about the selected RAID controller is displayed in the lower part of the page.</li> <li>c. (Optional) In the RAID Event Log Statistics area, click Details. The Event Log page is displayed, where you can view the event logs of the RAID controller.</li> </ul>
Query storage summary	<ul> <li>a. Click Storage Summary. The Storage Summary page is displayed.</li> <li>b. From the RAID Controller list, select the RAID controller you want to query. The storage summary of the selected RAID controller is displayed in the lower part of the page.</li> <li>The storage summary of the RAID controller is described as follows: <ul> <li>Number of physical devices: number of physical hard disks.</li> <li>Number of logical devices: number of logical disks.</li> <li>Number of global hot spare disks: number of physical hard disks used as global hot spare disks: number of physical hard disks used as local hot spare disks: number of physical hard disks used as local hot spare disks.</li> </ul> </li> </ul>
Query physical device information	<ul> <li>a. Click Physical Devices Information. The Physical Devices Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the RAID controller you want to query. The information about all the physical disks managed by the selected RAID controller is displayed in the lower part of the page.  The State information in the physical disk information is described as follows: <ul> <li>Online: The member disk of the logical disk is online.</li> <li>Missing: The member disk of the logical disk is removed.</li> <li>Offline: The member disk of the logical disk is offline.</li> <li>Rebuild: Rebuild. The hard disk is rebuilding data to ensure data redundancy and integrity of the logical disk.</li> </ul> </li> </ul>

То	Do
	<ul> <li>Shield State: Protected. Temporary status of the diagnosis operation.</li> <li>Hotspare: Hot spare disk.</li> <li>Copyback: Copyback. A new disk is replacing a faulty member disk.</li> <li>Bootable: Boot disk.</li> <li>Unconfigured_good: Not configured, and the hard disk is available.</li> <li>Unconfigured_bad: Not configured, and the hard disk is not available.</li> <li>PredictiveFailure: Failure. The hard disk is unavailable.</li> <li>ExposedToOS: Pass-through disk. This state is displayed when the RAID controller card is set to pass-through mode or set to mixed mode but no RAID controller card is created.</li> <li>C.  (Optional) Click on the right of the physical hard disk. More action options are displayed.</li> </ul>
Query logical device information	<ul> <li>a. Click Logical Device Information. The Logical Device Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the RAID controller you want to query. The information about all the logical disks managed by the selected RAID controller is displayed in the lower part of the page.  The State information in the logical disk information is described as follows: <ul> <li>Optimal: Optimization.</li> <li>Degraded: Degraded.</li> <li>Rebuilt: Rebuilt.</li> <li>Initialization: Initialization.</li> <li>Offline: Offline.</li> </ul> </li> <li>C. <ul> <li>(Optional) Click</li> <li>Create Virtual Device. A logical disk is created.</li> </ul> </li> </ul>
Query BBU information	<ul> <li>a. Click BBU Information. The BBU Information page is displayed.</li> <li>b. From the RAID Controller list, select the RAID controller you want to be query. The BBU information of the selected RAID controller is displayed in the lower part of the page.</li> </ul>
View event logs	<ul> <li>a. Click Event Log. The Event Log page is displayed.</li> <li>b. From the Select the RAID Controller list, select the RAID controller you want to query. The event logs of the selected RAID controller are displayed in the lower part of the page.</li> </ul>

То	Do
Query the NVMe device infor-	Click NVMe Device Information. The NVMe Device Information page
mation	is displayed, showing the NVMe device information below.
	In the NVMe device list, you can turn on the UID indicator of an NVMe
	device.

# 3.7.16 Querying SAS IT Information

#### **Abstract**

#### **SAS IT** information includes:

- Controller information: detailed information of the SAS IT controller, including the serial number, version number, and health status. The SAS IT controller usually includes the LSI HBA card and SDLSA card.
- Physical device information: information of all the physical disks managed by the SAS IT controller.
- Logical device information: Information of all the logical disks managed by the SAS IT controller.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click SAS IT Management. The SAS IT Management page is displayed, see Figure 3-37.

Figure 3-37 SAS IT Management Page



3. Perform the following operations as required.

То-	Do-
Query SAS IT controller information	<ul> <li>a. Click SAS IT Controller Information. The SAS IT Controller Information page is displayed.</li> <li>b. From the SAS IT Controller list, select the SAS IT controller you want to query. The information about the selected SAS IT controller is displayed in the lower part of the page.</li> </ul>
Query physical device information	<ul> <li>a. Click Physical Device Information. The Physical Device Information page is displayed.</li> <li>b. From the Select the SAS IT Controller list, select the SAS IT controller you want to query. The information about all the physical disks</li> </ul>

То-	Do-
	managed by the selected SAS IT controller is displayed in the lower part of the page.
Query logical device information	<ul> <li>a. Click Logical Device Information. The Logical Device Information page is displayed.</li> <li>b. From the Select the SAS IT Controller list, select the SAS IT controller you want to query. The information about all the logical disks managed by the selected SAS IT controller is displayed in the lower part of the page.</li> </ul>

# 3.7.17 Configuring Services


#### **Abstract**

This procedure describes how to configure the status, secure port, non-secure port, and timeout for a service of the BMC.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Services. The Services page is displayed, see Figure 3-38.








Redfish is a server management specification. Based on the extensible platform management API, it uses the semantic RESTful interface to access the data defined in the model format for out-of-band system management. Redfish is applicable to the management and deployment of large-scale server cloud environment.

For a detailed description of Redfish, refer to the VANTAGEO Server Redfish Interface Description. For detailed steps to access the VANTAGEO Server Redfish Interface Description, refer to "6 Reference: Accessing Documents".

3. Click for the service to be configured. The **Service Configuration** page is displayed, see Figure 3-39.

**Figure 3-39 Service Configuration Page** 





This procedure uses the KVM service as an example. The operations for configuring other services are similar.

4. Configure the parameters. For a description of the parameters, refer to Table 3-21.

**Table 3-21 Service Parameter Descriptions** 

Parameter	Description	Setting		
Active	Whether to enable the service.	<ul> <li>Select Active. The service is available.</li> <li>Deselect Active. The service is not available.</li> </ul>		
Non-secure port	Non-secure port number of the service.	<ul> <li>Default non-secure port number of the Web service: 80.</li> <li>Default non-secure port number of the KVM service: 7578.</li> <li>Default non-secure port number of the CD media service: 5120.</li> <li>Default non-secure port number of the HD media service: 5123.</li> <li>The SSH service does not support non-secure ports.</li> <li>Default non-secure port number of the SNMP service: 161.</li> <li>Range of the non-secure port number: 1 – 65535.</li> </ul>		
Secure port	Secure port number of the service.	<ul> <li>Default secure port number of the Web service: 443.</li> <li>Default secure port number of the KVM service: 7582.</li> <li>Default non-secure port number of the CD media service: 5124.</li> <li>Default non-secure port number of the HD media service: 5127.</li> <li>Default secure port number of the SSH service: 22.</li> <li>Range of the secure port number: 1–65535.</li> </ul>		
Timeout	Timeout period after which the service exits if no operation is performed.	The timeout period of the Web service and KVM service ranges from 300 through 1800 seconds.		

Parameter	Description	Setting
		The timeout period of the SSH service ranges from 60 through 1800 seconds.
		The timeout period must be a multiple of 60.

#### Verification

- Set the status of the Redfish service to Active to enable query and configuration of the BMC through the Redfish interface.
  - For a detailed description of Redfish, refer to the VANTAGEO Server Redfish

    Interface Description. For detailed steps to access the VANTAGEO Server

    Redfish Interface Description, refer to "6 Reference: Accessing Documents".
- Set the status of the SNMP service to Active and configure the correct Non Secure Port to enable query and configuration of the BMC through the SNMP interface.
  - For a detailed description of SNMP, refer to the VANTAGEO Server SNMP Interface Description. For detailed steps to access the VANTAGEO Server SNMP Interface Description, refer to "6 Reference: Accessing Documents".

# 3.7.18 Configuring an Alarm Mailbox

## **Abstract**


To send the alarm information of the server to a specified mailbox, you must configure the alarm mailbox.

### **Prerequisite**

The SMTP server is configured. For details, refer to "4.12 Configuring the SMTP Server".

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **SMTP Settings**. The **SMTP Settings** page is displayed, see Figure 3-40.

Figure 3-40 SMTP Settings Page



3. Configure the parameters. For a description of the parameters, refer to Table 3-22.

**Table 3-22 Parameter Descriptions for the Alarm Box Configuration** 

Parameter	Description	Setting
Enable SMTP Support	Whether to send alarms to a specified mailbox.	Select Enable SMTP Support.
SMTP Server Address	IP address of the SMTP server.	Enter the IP address of the SMTP server.
SMTP Server Port	Port number of the SMTP server.	The port number range is 1–65535, and the default port number is 25.
Enables the TLS Support	Whether to enable TLS encryption.	To enable TLS encryption, select <b>Enables the TLS Support</b> .
SMTP Authentication	Whether to enable SMTP authentication.	To enable SMTP authentication, select SMTP Authentication, and set SMTP Username and SMTP Password.
Sender Email ID	Email address of the sender.	Enter the email address of the sender.
Receiving Email Address	Email address of a recipient.	Enter the email addresses of the recipients, which are separated with commas.
Email Subject	Subject of the alarm email.	Enter the subject of the alarm email.
Subject Attach	Whether to attach <b>Hostname</b> and <b>Asset Tag</b> to the subject.	Select the information to be attached.

#### Verification

- 1. Click the **Send Test Mail** button on the **SMTP Settings** page.
- 2. Check on the SMTP server whether a testing email is received.

# 3.7.19 Configuring SSL

## **Abstract**

To make a link to access the BMC Web portal to be a secure link, you must configure SSL. You can perform the following operations to configure SSL:

- 1. Upload the SSL certificate in your browser
- 2. Upload the SSL certificate on the BMC Web portal

## **Prerequisite**

The certificate file and private key file of the pem type are obtained.

### **Steps**

#### **Uploading the SSL Certificate in Your Browser**

- 1. On the **Settings** page of the browser (for example, Chrome) on the client PC, select **Privacy and security** page is displayed.
- 2. Click on the right of **Manage certificates** and upload the SSL certificate.

#### Uploading the SSL Certificate on the BMC Web Portal

- 3. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 4. Click SSL Settings. The SSL Settings page is displayed.
- Click Upload SSL certificate. The page for uploading the SSL certificate is displayed, see Figure 3-41.

Figure 3-41 Uploading the SSL Certificate



- 6. Select the prepared certificate file and private key file.
- 7. Click Upload.

#### Verification

In the address bar of your browser, enter the address of the BMC Web portal, and press **Enter**. Check whether the **Welcome** page is displayed and the address bar of the browser does not prompt "Not secure", see Figure 3-42.

Figure 3-42 Welcome Page



Figure 3-43 shows the page where the address bar of the browser prompts "Not secure".

**Figure 3-43 Not Secure Connection Page** 




# 3.7.20 Configuring the Default Firewall Policy

#### **Abstract**

If the existing firewall rules do not match, a server uses the default firewall policy.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **System Firewall**. The **System Firewall** page is displayed.
- 3. Click **Firewall Policy Settings**. The **Firewall Policy Settings** page is displayed, see **Figure** 3-44.

Figure 3-44 Firewall Policy Settings Page



- 4. Select White List or Black List.
  - White List: The users in the whitelist are allowed to access the server.
     If White List is enabled, you must configure an Allow rule first.
     The Allow rule can be any one or more of the IP address firewall rule, MAC address firewall rule or port firewall rule.
  - Black List: The users in the blacklist are not allowed to access the server.
- 5. Click Save Option.


# 3.7.21 Configuring an IP Address Firewall Rule

#### **Abstract**

This procedure describes how to configure an IP address firewall rule to allow or disallow the devices with the specified IP addresses to access the server.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **System Firewall**. The **System Firewall** page is displayed.
- 3. Click IP Address Firewall Rules. The IP Firewall Rules page is displayed.
- 4. Click Add New IP Rule. The Add IP Rule page is displayed, see Figure 3-45.

Figure 3-45 Add IP Rule Page



5. Configure the parameters. For a description of the parameters, refer to Table 3-23.

Table 3-23 Parameter Descriptions for the IP Address Firewall Rule

Parameter	Description	Setting	
IP Single (or) Range Start	Single IP address or the start address of an IP address segment.	<ul> <li>For a single IP address, enter this address.</li> <li>For an IP address segment, enter the start address.</li> </ul>	

Parameter	Description	Setting
IP Range End	End address of the IP address segment. This parameter is optional.	For an IP address segment, enter the end address.
Enable Timeout	Whether to enable the firewall timeout rule.	<ul> <li>Select Enable Timeout. The firewall rule is valid in a specified time period.         The time period can be set in Start Date, Start Time, End Date and End Time.         You can also select Only Working-day, so that the firewall rule is effective on working days.     </li> <li>If you do not select Enable Timeout, the firewall rule becomes valid immediately.</li> </ul>
Rule	Allow or Block.	Select the type of firewall rule:  • Allow: Allows the devices with the specified IP addresses to access the server.  • Block: Blocks the devices with the specified IP addresses from accessing the server.


# 3.7.22 Configuring a MAC Address Firewall Rule

#### **Abstract**

This procedure describes how to configure a MAC address firewall rule to allow or disallow the devices with the specified MAC addresses to access a server.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **System Firewall**. The **System Firewall** page is displayed.
- 3. Click MAC Firewall Rules. The MAC Firewall Rules page is displayed.
- 4. Click Add New MAC Rule. The Add New MAC Rule page is displayed, see Figure 3-46.

Figure 3-46 Add New MAC Rule Page



5. Configure the parameters. For a description of the parameters, refer to Table 3-24.

Table 3-24 Parameter Descriptions for the MAC Address Firewall Rule

Parameter	Description	Setting
MAC Single (or) Range Start	Single MAC address or the start address of a MAC address segment.	<ul> <li>For a single MAC address, enter this address.</li> <li>For a MAC address segment, enter the start address.</li> </ul>
MAC Range End	End address of a MAC address segment. This parameter is optional.	For a MAC address segment, enter the end address.  Only the last byte of the end MAC address can be different from the start MAC address, and a maximum of 64 MAC addresses are allowed between the end MAC address and the start MAC address.
Network Type	IPv4, IPv6 or Both.	Select the corresponding network type.
Enable Timeout	Whether to enable the firewall timeout rule.	<ul> <li>Select Enable Timeout. The firewall rule is valid in a specified time period.</li> <li>The time period can be set in Start Date, Start Time, End Date and End Time.</li> </ul>

Parameter	Description	Setting
		You can also select <b>Only Working-day</b> , so that the firewall rule is effective on working days.  If you do not select <b>Enable Timeout</b> , the firewall rule becomes valid immediately.
Rule	Allow or Block.	Select the type of firewall rule:  • Allow: Allows the devices with the specified MAC addresses to access the server.  • Block: Blocks the devices with the specified MAC addresses from accessing the server.


# 3.7.23 Configuring a Port Firewall Rule

#### Abstract

This procedure describes how to configure a port firewall rule to allow or disallow a device to access the server through a specified port.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click System Firewall. The System Firewall page is displayed.
- 3. Click Port Firewall Rules. The Port Firewall Rules page is displayed.
- 4. Click Add New Port Rule. The Add New Port Rule page is displayed, see Figure 3-47.

Figure 3-47 Add New Port Rule Page



5. Configure the parameters. For a description of the parameters, refer to Table 3-25.

**Table 3-25 Port Rule Parameter Descriptions** 

Parameter	Description	Setting
Port Single (or) Range Start	Single port or the start port of a port range.	<ul> <li>For a single port, enter the port number.</li> <li>For a port range, enter the start port number.</li> <li>Port range: 1–65535.</li> </ul>
Port Range End	End port. This parameter is optional.	For a port range, enter the end port number. Port range: 1–65535.
Protocol	Protocol type.	Select the corresponding protocol type.
Network Type	IPv4, IPv6 or Both.	Select the corresponding network type.
Send Direction	Source Port or Destination port.	Select the corresponding sending direction.
Enable Timeout	Whether to enable the firewall timeout rule.	<ul> <li>Select Enable Timeout. The firewall rule is valid in a specified time period.</li> <li>The time period can be set in Start Date, Start Time, End Date and End Time.</li> </ul>

Parameter	Description	Setting
		If you do not select <b>Enable Timeout</b> , the firewall rule becomes valid immediately.
Rule	Allow or Block.	Select the type of firewall rule:  Allow: Allows to access the server through the specified port.  Block: Blocks accessing the server through the specified port.

# 3.7.24 Creating a User

## Abstract

This procedure describes how to create a BMC user by using the user group management and user management functions.

To create a user, perform the following steps:

- 1. Add a user group
- 2. Add a user

### **Steps**

## **Adding a User Group**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Group Management**. The **Group Management** page is displayed, see Figure 3-48.

Figure 3-48 Group Management Page






The existing user group has a group name on the right of the user group icon, and the new user group has no group name. To add a user group, click the new user group icon.

3. Click the icon for the new user group. The **Group Management Configuration** page is displayed, see Figure 3-49.

**Figure 3-49 Group Management Configuration Page** 



4. Configure the parameters. For a description of the parameters, refer to Table 3-26.

**Table 3-26 Group Parameter Descriptions** 

Parameter	Description	Setting
Groupname	Name of the user group.	<ul> <li>Enter a user group name.</li> <li>The group name is a string composed of 4–16 letters, digits, "-", "_" or " @ ", which must start with a letter.</li> <li>Letters are case-sensitive.</li> </ul>

Parameter	Description	Setting
required privilege/optional privilege	Operation permissions of the users in the user group.	The permissions are divided into required permissions and optional permissions.  Required permission: Select at least one of the following permissions:  configure  operate  view  In most cases, the required permissions for the user group of each role are as follows:  Administrator: configure, operate, and view  Operator: operate and view  Viewer: view  Optional permission: Select one of the following permissions as needed.  KVM Access  VMedia Access  SNMP Access  In most cases, the optional permissions of each role user group are as follows:  Administrator: KVM Access, VMedia Access, and SN-MP Access  Operator: SNMP Access
SNMP Access level	SNMP access level.	When SNMP Access is selected for optional privilege, you must configure this parameter.  Select an SNMP access level, including:  Read Only  Read Write
SNMP Authentication Protocol	SNMP authentication protocol.	When SNMP Access is selected for optional privilege, you must configure this parameter.  Select an SNMP authentication protocol, including:  NONE SHA MD5 SHA256 SHA384 SHA512
SNMP Privacy Protocol	SNMP encryption mode.	When <b>SNMP Access</b> is selected for <b>optional privilege</b> , you must configure this parameter.  Select an SNMP encryption mode, including:  NONE

Parameter	Description	Setting
		• DES
		• AES
		• AES256
		If SNMP Authentication Protocol is set to NONE, SNMP
		Privacy Protocol can only be set to NONE. AES256 can be
		used together with only SHA256, SHA384, or SHA512.

## **Adding a User**

6. On the **Settings** page, click **User Management**. The **User Management** page is displayed, see Figure 3-50.

Figure 3-50 User Management Page





The existing user has a user name on the right of the user icon, and the new user has no user name. To add a user, click the new user icon. The first user in the upper left corner is reserved and cannot be created or modified.

7. Click the icon for the new user. The **User Management Configuration** page is displayed, see Figure 3-51.

0 User ID 7 Username test Password Size 16 bytes Password Confirm Password Enable User Access Dependent user group Please select **Email Format** AMI-Format Email ID test@vantageo.com Existing SSH Key Not Available Upload SSH Key

Figure 3-51 User Management Configuration Page

8. Configure the parameters. For a description of the parameters, refer to Table 3-27.

**Table 3-27 User Parameter Descriptions** 

Parameter	Description	Setting	
User ID	User ID.	Generated by the system automatically and cannot be configured.	
Username	User name.	<ul> <li>Enter a username.</li> <li>The username is a string composed of 4–16 letters, digits, "-", "_" or "@", which must start with a letter.</li> <li>Letters are case-sensitive.</li> </ul>	

Parameter	Description	Setting	
		It is not allowed to use anonymous, root, admin, users, no-body, username, or sysadmin as the username, and the username and password must not be the same.	
Password Size	Length of the password to be entered in Password/Confirm Password.	Select a password length.	
Password	User password.	<ul> <li>Enter the user password. It is allowed to enter letters, digits, and symbols. Letters are case-sensitive.</li> <li>The password must not contain spaces or tabs.</li> <li>If a strong password is enabled, the password must contain four types of characters (upper-case letters, lower-case letters, digits, and symbols).</li> </ul>	
Confirm Password	Confirm the user password.	Enter the password for confirmation, which must be the same as <b>Password</b> .	
Enable User Access	Whether to enable the user immediately.	The added user can take effect only after this option is selected.	
Dependent user group	User group that the user belongs to.	Select a user group for the user.  The user inherits the permissions of the user group that the user belongs to.	
Email Format	Format of emails sent by the BMC to the user.	Select an email format:  • AMI-Format: The email title format is " Alert from (host address) ". The emails in this format display sensor information, for example, sensor types and descriptions.  • FixedSubject-Format: The emails in this format display messages in accordance with user settings. The user must specify the email subject and messages in advance.	
Email ID	Email address of the user.	Enter an email address.	
Existing SSH Key	Displays the SSH key uploaded by the user.	-	
Upload SSH Key	Uploads a public SSH key to the server. The file size cannot exceed 4 KB.	Click and select a key file.	

# 3.7.25 Configuring Screen Recording Parameters

#### **Abstract**

By configuring screen recording parameters, you can specify the events that trigger screen recording and the recording duration.

The recorded videos can be viewed on the Video Log page.

## **Prerequisite**

To enable the screen recording function, you need to enable the KVM service. For details, refer to "3.7.17 Configuring Services".




The launch of a KVM or VNC session temporarily disables recording. After the KVM or VNC session is closed, recording is automatically resumed.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- Click Video Trigger Settings. The Video Trigger Settings page is displayed, as shown in Figure 3-52.

#### Figure 3-52 Video Trigger Settings Page



3. Set the parameters. For a description of the parameters, refer to Table 3-28.

**Table 3-28 Screen Recording Parameter Descriptions** 

Parameter	Description	Setting
Before Crash/Be- fore Reset/Before Power Off	Select the events that trigger screen recording.	Select the events that trigger screen recording.
Recording Dura- tion(s)	Select a recording duration.	Select a recording duration. Range: 10–60 seconds.
Enable/Disable	Whether to enable the screen recording function.	Select whether to enable the screen recording function.


# 3.7.26 Configuring a Boot Mode

#### Abstract

This procedure describes how to configure a boot mode, including the boot device and the application mode of the server.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Boot Option Settings**. The **Boot Option** page is displayed, see Figure 3-53.

**Figure 3-53 Boot Option Page** 



3. Configure the parameters. For a description of the parameters, refer to Table 3-29.

**Table 3-29 Boot Option Parameter Descriptions** 

Parameter	Description	
Boot Device	Hardware device used to boot the server system.	
	• no override: The first boot device is not set. The default boot mode set in	
	BIOS prevails, which is not controlled by the BMC.	
	PXE: The system is forcibly started through the network.	
	Hard Disk: The system is booted forcibly through the hard disk.	
	USB: The system is forcibly booted through USB.	
	CD ROM: The system is forcibly booted through the CD-ROM drive.	
	BIOS: After the server is booted, the BIOS menu is displayed.	
	<ul> <li>Remotely connected Hard Drive: The system is forcibly started through the remote hard disk.</li> </ul>	
Effective Way	Whether the reconfigured server boot is applied only once.	
	ONCE: only effective for this restart.	

Parameter	Description
	Persistent: permanently effective.

4. Click Save Option.

# 3.7.27 Modifying BIOS Parameters

#### **Abstract**

This procedure describes how to modify BIOS parameters on the Web portal of the BMC.




This function is applicable to only server models developed based the Hygon platform.

## **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click BIOS Setting. The BIOS Setting page is displayed, as shown in Figure 3-54.

Figure 3-54 BIOS Setting Page



- For the BIOS parameter that you want to modify, select the target value in the Modify column.
- 4. Click Save.



After the modification is saved, the target value is displayed in the **Modified Value** column. The modification takes effect after the server is restarted.

# 3.7.28 Configuring Login Parameters


#### **Abstract**

To ensure user account security, you must configure the login parameters.

## **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Login Settings. The Account Login Settings page is displayed, see Figure 3-55.

Figure 3-55 Account Login Settings Page



3. Configure the parameters. For a description of the parameters, refer to Table 3-30.

**Table 3-30 Parameter Descriptions for the Account Login Settings** 

Parameter		Description	Setting
Account Lock- out Setting	Account Lock- out	Whether to lock a user account when the number of times that the user enters incorrect passwords reaches Account Authentication Failure Times.	Select whether to enable account lockout:  • Enable: locks the user account when the number of times that the user enters incorrect passwords reaches Account Authentication Failure Times .
			<ul> <li>Enable: does not lock the user account when the number of times that the user enters incorrect passwords reaches Account Authentication</li> <li>Failure Times.</li> </ul>



Parameter		Description	Setting
			When this parameter is set to Enable, you must configure Account Authentication Failure Times and The Account Lockout Time.
	Account Au- thentication Failure Times	Number of authentication failures caused by incorrect passwords.	Enter the number of account authentication failures. The range is 0–10.
	The Account Lockout Time	Length of time for which an account is locked. Unit: minutes.	Enter the length of time for which an account is locked. The range is 1–1440.
Password Expired Time Setting	The Pass- word Expired Time	Whether to enable the password validity period.	After the password validity period is enabled, the account that expires fails to log in.
	The Expired Time	Validity period of the password in days.	Enter the validity period of the password, which ranges from 1 through 90.
Strong Pass- word Policy Setting	Strong Pass- word Policy	Whether to enable the strong password policy.	Select whether to enable the strong password policy. A strong password must contain at least eight characters, including uppercase and lowercase letters, digits, and symbols.
	Disable historical passwords	Number of historical pass- words that cannot be used as the new password.	Range: 0–5. The values 1–5 indicate that the new password cannot be the same as the last 1 to 5 passwords. The value 0 indicates that the new password can be the same as any historical password.
OS User Management Setting	Management Setting	Whether to enable the user management configuration function on the service side.  After the function is enabled, the BMC user information can be configured in the BIOS and OS.	Select whether to enable the user management configuration function on the service side.

# 3.7.29 Configuring Two-Factor Authentication

#### **Abstract**


Two-factor authentication requires another credential for access to the system in addition to a static password. It improves system security.



This function is applicable to only server models developed based the Hygon platform.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- Click Two-factor Authentication. The Two-factor Authentication page is displayed, as shown in Figure 3-56.

Figure 3-56 Two-factor Authentication Page



- 3. Select whether to enable two-factor authentication. Options:
  - enable: enables two-factor authentication.
  - disable: disables two-factor authentication.
- 4. Click Save.
- 5. (Optional) If two-factor authentication is enabled, click **Generate QR code**, and then scan the code and enter the correct token to bind your mobile number.



The bound mobile number will be used as the other credential in addition to the static password. In addition, the BMC time must be the same as the Internet time. Otherwise, the verification fails.

# 3.7.30 Configuring SNMP Parameters

#### **Abstract**

SNMP parameters are used by the BMC to send alarms and notifications to a third-party NMS . SNMP parameters include:

- SNMP Community: A community consists of SNMP and SNMP entities, and different communities are identified by community names. Community names can be used as the plaintext passwords between the management process and the agent process.
- SNMP Trap Configurations
- SNMP Trap Destinations: Destination address to which alarms and notifications are sent, including the IP address and port number.



SNMP parameters are provided by a third-party NMS.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click SNMP Settings. The SNMP Configurations page is displayed, see Figure 3-57.

### **Figure 3-57 SNMP Configurations Page**




3. Perform the following operations as required.


То	Do	
Configure the SNMP community	<ul> <li>a. Click SNMP Community. The SNMP Community page is displayed, see Figure 3-58.</li> <li>b. Determine whether to enable the V1/V2C set/get Policy function. If the V1/V2C set/get Policy function is enabled, the Set and Get operations are allowed to be performed in accordance with SNMPv1 or SNMPv2c.</li> <li>c. Click Save in the SNMP V1/V2C Set/Get Setting area.</li> </ul>	

То	Do		
	d. Set Read-Only Community , Confirm Read-Only Community ,		
	Read-Write Community , and Confirm Read-Write Community .		
	In most cases, Read-Only Community is set to		
	vantageo_public, and Read-Write Community is set to		
	platform by default.		
	e. Click Save in the Community Setting area.		
Configure SNMP Trap	a. Click SNMP Trap Configurations . The SNMP Trap Configurations		
	page is displayed, see Figure 3-59.		
	b. Select <b>Enable</b> in the <b>SNMP Trap Setting</b> area.		
	c. Select an alarm level from the Alarm Sending Level list.		
	Alarm levels include:		
	<ul> <li>Critical: Alarms of critical level are sent only.</li> </ul>		
	<ul> <li>Major: Alarms of major and critical levels are sent.</li> </ul>		
	<ul> <li>Minor: Alarms of minor, major, and critical levels are sent.</li> </ul>		
	<ul> <li>Normal: Alarms of normal, minor, major, and critical levels are</li> </ul>		
	sent.		
	d. Select a mode from the <b>Module Trap Mode</b> list.		
	Modes include:		
	<ul> <li>Event OID Mode: indicates that alarms are triggered by event.</li> </ul>		
	<ul> <li>Module OID Mode: indicates that alarms are triggered by module.</li> </ul>		
	e. Click Save in the SNMP Trap Setting area.		
	f. Enter a community name in the <b>Trap Community</b> text box and con-		
	firm it in the Confirm Trap Community text box in the SNMP Trap		
	Community Name Setting area.		
	g. Click <b>Save</b> in the <b>SNMP Trap Community Name Setting</b> area.		
	h. Go back to the <b>SNMP Configurations</b> page.		
	i. Click SNMP Trap Destinations . The SNMP Trap Destinations page		
	is displayed.		
	j. Click 🏲 . The <b>Trap Destination Configuration</b> page is displayed,		
	see Figure 3-60.		
	k. Configure the trap destination parameters. For a description of the parameters, refer to Table 3-31.		
	I. Click Save .		


Figure 3-58 SNMP Community Page



### Figure 3-59 SNMP Trap Setting Page



**Figure 3-60 Trap Destination Configuration Page** 



**Table 3-31 Trap Destination Parameter Descriptions** 

Parameter	Description	Setting
SNMP Destination Address	IP address of the server that receives alarms.	Enter the IP address in the IPv4 or IPv6 format.
SNMP Trap Port	Server port that receives alarms.	Enter the port number, with a range of 1–65535.  If there is a default port number, provide it.
SNMP Protocol Version	SNMP protocol type used for sending alarms.	Select a protocol type.
SNMP Trap User	User used for sending alarms.	When <b>SNMP Protocol Version</b> is set to <b>V3</b> , you must select a user with the SNMP permissions as the alarm sender.  For how to create a user with the SNMP permissions, refer to "4.20 Creating an SNMP User".

# 3.7.31 Configuring an Asset Tag

#### **Abstract**

This procedure describes how to modify the server asset tag when it needs to be updated.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Asset Tag Settings. The Asset Tag page is displayed, see Figure 3-61.

Figure 3-61 Asset Tag Page



- 3. Enter the asset tag name with a maximum of 63 characters.
- 4. Click Save.

# 3.7.32 Configuring the Server Location

#### **Abstract**

This procedure describes how to configure the server location.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Product Location**. The **Product Location** page is displayed, as shown in Figure 3-62

**Figure 3-62 Product Location Page** 



- 3. Enter the server location. Range: 0–64 characters, which include digits, letters, and special characters.
- 4. Click Save.

# 3.7.33 Configuring Disk Alarm Thresholds

#### **Abstract**

This procedure describes how to configuring disk alarm thresholds by using the **Monitor info** function. Once the hard disk usage reaches a threshold, an alarm of the corresponding level is raised.



The **Monitor Info** function is only provided for specific operating systems and monitoring tools.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Monitor info. The Monitor Information page is displayed, see Figure 3-63.

Figure 3-63 Monitor Information Page



- Enter the three thresholds for hard disk monitoring.
   Generally, the three thresholds are 75%, 85%, and 95% from low to high.
- 4. Click Save.

#### **Related Tasks**

On the **Monitor Information** page, you can view the usage of each disk and the monitoring information of the CPU, memory and I/O.

- CPU CUPS dynamic load(%): proportion of the used CPU resources to the server resources
- Memory CUPS dynamic load(%): proportion of the used memory resources to the server resources.



• IO CUPS dynamic load(%): proportion of the used I/O resources to the server resources.

# 3.7.34 Configuring an Alarm Source

#### Abstract

This procedure describes how to configure alarm sources by using the **Alarm Settings** function, including the **PSU** alarm, disk alarm and network port alarm.

- PSU alarm: When a power module is not present, an alarm is raised.
- Disk alarm: When a hard disk is not present, an alarm is raised.
- Net port alarm: When the network cable corresponding to the network port is removed or not properly connected, an alarm is raised.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Alarm Settings. The Alarm Configuration page is displayed, see Figure 3-64.


**Figure 3-64 Alarm Configuration Page** 




3. Perform the following operations as required.

То	Do
Configure the PSU alarm	<ul> <li>a. Click PSU Alarm Configuration. The PSU Alarm Configuration page is displayed, see Figure 3-65.</li> <li>b. Select the power supply whose alarms need to be reported.</li> <li>c. Click Save.</li> </ul>
Configure the disk alarm	<ul> <li>a. Click Disk Alarm Configuration. The DISK Alarm Configuration page is displayed, see Figure 3-66.</li> <li>b. Select the hard disk whose alarms need to be reported.</li> <li>c. Click Save.</li> </ul>
Configure the network port alarm	<ul> <li>a. Click NetPort Alarm Configuration. The NetPort Alarm Configuration page is displayed, see Figure 3-67.</li> <li>b. Select whether to enable the network port alarm.</li> <li>Select NetPort to enable the network port alarm.</li> <li>Deselect NetPort to disable the network port alarm.</li> <li>C. Click Save.</li> </ul>


Figure 3-65 PSU Alarm Configuration Page



**Figure 3-66 Disk Alarm Configuration Page** 



**Figure 3-67 NetPort Alarm Configuration Page** 



# 3.7.35 Configuring a Serial Port Output Mode

#### **Abstract**

The serial port output modes on the panel include:

• COM1: The print information in the BIOS phase is output. The BIOS can be configured.

COM2: There is no output in the BIOS phase and the system hot key cannot be responded.
 The print information in the OS phase is output.

### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Panel Uart Settings. The Panel Uart page is displayed, see Figure 3-68.

#### Figure 3-68 Panel Uart Page



- 3. Select a serial port output mode.
- 4. Click Save Option.


# 3.7.36 Configuring the Cooling Mode

#### Abstract

This procedure describes how to set the cooling mode in accordance with the storage scenario of the server to improve the server performance.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- Click Cooling Mode Management. The Cooling Mode Management page is displayed, see Figure 3-69.

**Figure 3-69 Cooling Mode Management Page** 



3. Select a cooling mode as required.

If	Then
There is space above the top surface of the server, and the server is insensitive to noise	Select Normal Mode under Automatic Policy.
Servers are stacked together, and there is no space between them	Select High Performance Mode under Automatic Policy.
The server is placed in an office or other areas that are sensitive to noise	Select <b>Low Noise Mode</b> under <b>Automatic Policy</b> , and leave some space above the top surface of the server.
The fan rotation speed needs to be set manually for the server	Select Manual Policy and enter Speed Percentage.



**Speed Percentage** indicates the ratio of the current speed of the fan to its maximum speed.



**Manual Policy** is applicable to only special scenarios and temporary adjustment. Use this function with care.

4. Click Save Option.

# 3.7.37 Querying GPU Information

#### **Abstract**

By querying the GPU information, you can learn about the basic information of the GPU on the server, including the model and version number.

# **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click GPU Information. The GPU Management page is displayed, see Figure 3-70.

### Figure 3-70 GPU Management Page




# 3.7.38 Configuring a Power-On Policy

## **Abstract**

By using the power-on restoration policy function, you can configure the power-on/power-off status of the host when the system is to restore its power after it is powered off.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- Click Power Restore Policy. The Power Restore Policy page is displayed, see Figure 3-71.

Figure 3-71 Power Restore Policy Page



- 3. Select a power-on policy.
  - always-off: When the system is powered off and then restores power, the host is in the power-off status.
  - always-on: When the system is powered off and then restores power, the host is in the power-on status.
  - previous: When the system is powered off and then restores power, the host is in the status the same as that before the power-off.
- 4. Click Save Option.

# 3.7.39 Configuring the VGA Output Mode

## **Abstract**

VGA output modes include:

- Front: Signals are output from the front VGA interface.
- Rear: Signals are output from the rear VGA interface. The rear VGA interface is selected by default.

The front VGA interface cannot display the 80-code startup process. If debugging is required, you must connect the display to the rear VGA interface.



The VGA output mode needs to be configured for only server models developed based the Hygon platform.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click VGA Output. The VGA Output Config page is displayed, see Figure 3-72.

Figure 3-72 VGS Output Config Page



- 3. Select a VGA output mode.
- 4. Click Save Option.

# 3.7.40 Configuring Power-On Delay Parameters


#### **Abstract**

This procedure describes how to configure power-on delay parameters for off-peak power-on.

# **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Power On delay Settings**. The **Power On delay Settings** page is displayed, see Figure 3-73.

Figure 3-73 Power On Delay Settings Page



3. Configure the parameters. For a description of the parameters, refer to Table 3-32.

**Table 3-32 Parameter Descriptions for the Power-On Delay** 

Parameter	Description	Setting
Enable power on delay	Whether to enable the power-on delay function.	<ul> <li>Select Enable power on delay. The power-on delay function is enabled.</li> <li>Deselect Enable power on delay. The power-on delay function is disabled.</li> </ul>
Delay Strategy	Power-on delay mode.	<ul> <li>Custom Type: The power-on delay mode:</li> <li>Custom Type: The power-on delay time is user-defined.</li> <li>If Custom Type is selected, Custom Delay Power On Time is also required.</li> <li>Custom Delay Power On Time ranges from 1 through 120 seconds.</li> <li>Random Type: The power-on delay time is generated by the system automatically.</li> </ul>

4. Click Save.

# 3.7.41 Querying Pass-Through Disk Information


#### Abstract

Pass-through disks are hard disks directly connected to the PCH or a CPU rather than a RAID controller card.

By querying the information about a pass-through disk, you can learn about the corresponding CPU, capacity, and model of the pass-through disk, and turn on the UID indicator of the pass-through disk.

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Direct Harddisk Management**. The **Direct Harddisk Management** page is displayed, see Figure 3-74.

Figure 3-74 Direct Harddisk Management Page





Controller BDF is the controller of the PCH or CPU.

3. (Optional) To turn on the UID indicator, click for the corresponding hard disk.



After the indicator is turned on, its status in the **LED Status** column is changed to **LED ON**, and the button is activated. You can click to turn off the UID indicator.

# 3.8 Remotely Controlling a Server

### **Abstract**

If the server cannot be controlled on-site, you can control it remotely on the client PC.


## **Prerequisite**

To start the KVM in JAVA mode, the JRE is installed on the client PC, for example, jre-8u191

# **Steps**

 From the menu bar in the left pane, select Remote Control. The Remote Control page is displayed, see Figure 3-75.

**Figure 3-75 Remote Control Page** 



2. Perform the following operations as required.

То	Do
Start the KVM in HTML mode	<ul> <li>a. Click Launch KVM (HTML). The Remote KVM (HTML) window is displayed, see Figure 3-76.</li> <li>b. Perform the operations as required.</li> <li>For a description of the operations, refer to Table 3-33.</li> </ul>
Start the KVM in JAVA mode	<ul> <li>a. In the search box in the lower left corner of the client PC, enter Java.</li> <li>b. In the search result, select Java. The Java Control Panel dialog box is displayed.</li> <li>c. Click Security. The Security window is displayed.</li> <li>d. Click Edit Site List. The Exception Site List dialog box is displayed.</li> <li>e. Click Add to add the address of the BMC Web portal.</li> <li>f. Click OK to return to the Security window.</li> <li>g. Click OK.</li> <li>h. On the Remote Control page of the BMC Web portal, click Launch KVM (JAVA). A dialog box indicating whether to keep jview-er.jnlp is displayed.</li> <li>i. Click Keep.</li> <li>j. In the lower left corner of the browser, click jviewer.jnlp. A dialog box is displayed.</li> <li>k. Click Continue. The Do you want to run this application? dialog box is displayed.</li> </ul>

То	Do
	<ul> <li>I. Select I accept the risk and want to run this app. and click Run. The Untrusted Connection dialog box is displayed.</li> <li>m. Click Yes. The Remote KVM (JAVA) page is displayed, see Figure 3-77.</li> <li>n. Perform the operations as required. For a description of the operations, refer to Table 3-34.</li> </ul>
Reset KVM	When the KVM is not smooth, click <b>Reset KVM</b> to reset the KVM.  After resetting the KVM, you must wait for several seconds before starting the KVM.



Before starting the KVM in one mode, you must disable the KVM in another mode. For example, before starting the KVM in JAVA mode, you must disable the KVM started in HTML mode.

# Figure 3-76 Remote KVM (HTML) Window




Table 3-33 Descriptions for the Remote KVM (HTML) Operations

Operation	Description
Stop KVM	Click Stop KVM. The Remote KVM (HTML) window is closed.
Mount a local ISO file	Click Browse File on the right of CD Image, and select the ISO file from the client PC.

Operation	Description
	b. Click Start Media.
Display the notifications received	Click A.
Lock the host display	Lock the host display through either of the following ways:  Click  Select Video > Display OFF.  After the host display is locked, if another user wants to view the host page, a permission request is sent. The user can view the host page only when being authorized by the current active user.
Unlock the host display	Unlock the host display through either of the following ways:  Click Select Video > Display ON.  The button is changed to
Pause a remote control screen	Select Video > Pause Video.
Resume a remote control screen	Select Video > Resume Video.
Refresh a remote control screen	Select Video > Refresh Video.
Capture the current screen	Select Video > Capture Screen.
Set a video decoding mode  Switch the mouse show mode	<ul> <li>a. Select Video &gt; Compression Mode.</li> <li>b. Select a video decoding mode from the displayed submenu.</li> <li>Show the cursor: Select Mouse and Show Client Cursor.</li> </ul>
on the client	Hide the cursor: Select Mouse and deselect Show Client Cursor.
Set a mouse mode	<ul> <li>Set the absolute mouse mode: Select Mouse and then select Absolute Mouse Mode.         In absolute mouse mode, the absolute position of the local mouse is transferred to the server to make the mouse on the server move.     </li> <li>Set the relative mouse mode: Select Mouse and then select Relative Mouse Mode.         In relative mouse mode, the displacement of the local mouse relative to the server mouse is calculated and transferred to the server to make the mouse on the server move.     </li> <li>Set other mouse mode: Select Mouse and then select Other Mouse Mode.</li> </ul>

Operation	Description
	In other mouse mode, the displacement of the local mouse relative to the center location is calculated and transferred to the server to make the mouse on the server move.
Set keyboard layout	<ul> <li>a. Select Keyboard.</li> <li>b. In the displayed submenu, select the keyboard layout, including English U.S, German and Japanese. English U.S is selected by default.</li> </ul>
Set a key sending mode	Select Send Keys.     Select a key sending mode from the displayed submenu.
Set shortcut keys	<ul><li>a. Select Hot Keys.</li><li>b. Select Add Hot Keys from the displayed submenu.</li><li>c. In the displayed dialog box, add or clear shortcut keys.</li></ul>
Set video recording time length	<ul> <li>a. Select Video Record &gt; Record Settings. The Record Settings dialog box is displayed.</li> <li>b. Set the video recording time length with a range of 1–1800 seconds.</li> <li>c. Click OK.</li> </ul>
Record a video	Select Video Record > Record Video.
Stop recording	Select Video Record > Stop Recording.
Shut down the server	Shut down the server through either of the following ways:  • Select Power > Immediate shutdown.  • Click .
Power on the server	Start the server through either of the following ways.  • Select Power > Power On Server.  • Click
Perform a cold reboot	Select <b>Power &gt; Power Cycle Server</b> .  Cold reboot means that the server is started after it is shut down. During the restart, the server is offline.
Perform a warm reboot	Select <b>Power &gt; Reset Power</b> .  Warm reboot means that the server is restarted when it is not shut down.  During the restart, the server is not offline.
Shut down the operating system of the server	Select Power > Orderly shutdown.
View the users using remote control	Select Active Users.

Figure 3-77 Remote KVM (JAVA) Window




Table 3-34 Descriptions for the Remote KVM (JAVA) Operations

Operation	Description
Pause a remote control screen	Pause a remote control screen through one of the following ways:  Select Video > Pause Redirection.  Click Press Alt+P.
Resume a remote control screen	Resume the remote control screen through one of the following ways:  Select Video > Resume Redirection.  Click  Press Alt+R.
Refresh a remote control screen	Refresh the remote control screen through either of the following ways:  Select Video > Refresh Video.  Press Alt+E.
Switch the host screen display mode	To display the remote screen on the host: Select Video > Turn ON     Host Display.

Operation	Description
	<ul> <li>Not to display the remote screen on the host: Select Video &gt; Turn         OFF Host Display.         Note: You can use either of the following methods to rapidly switch between the remote screen display modes of the host.         <ul> <li>Click</li> <li>Press Alt+N.</li> </ul> </li> </ul>
Capture the current screen	Capture the current screen through either of the following ways:  Select Video > Capture Screen.  Press Alt+S.
Set a video decoding mode	a. Select Video > Compression Mode.     b. Select a video decoding mode from the displayed submenu.
Set the video display quality	<ul> <li>a. Select Video &gt; DCT Quantization Table.</li> <li>b. Select the video display quality from the displayed submenu.</li> <li>Note: The video display quality is divided into eight levels from 0 through 7, with video quality degraded in turn.</li> </ul>
Send a default key combination to the server	<ul> <li>a. Select Keyboard. The keyboard submenu is displayed.</li> <li>b. Select the shortcut key to be sent.</li> <li>Note: There are two sending types of default shortcut keys by default:</li> <li>Hold Down: The corresponding shortcut key is always pressed until the selection of the shortcut key is canceled. You can also press the corresponding button in the lower right corner of the window.</li> <li>Press and Release: The corresponding shortcut key is sent once and released immediately.</li> </ul>
Define a key combination	<ul> <li>a. Select Keyboard &gt; Hot Keys &gt; add Hot Keys. The User Defined Macros page is displayed.</li> <li>b. Click add. The Add Macros page is displayed.</li> <li>c. Press and then release the user-defined key combination.</li> <li>d. Click OK.</li> </ul>
Send a user-defined key combination to the server	<ul><li>a. Select Keyboard &gt; Hot Keys.</li><li>b. In the displayed submenu, select the self-defined keyboard shortcut to be sent.</li></ul>
Enable full keyboard support	<ul> <li>Enable full keyboard support: Select Keyboard and then select Full Keyboard Support.</li> <li>Disable full keyboard support: Select Keyboard and then deselect Full Keyboard Support.</li> </ul>
Switch mouse show mode on the client	<ul> <li>Show the cursor: Select Mouse and then select Show Cursor.</li> <li>Hide the cursor: Select Mouse and then deselect Show Cursor.</li> <li>Note: You can use either of the following methods to rapidly switch between the mouse display modes on the client.</li> </ul>

Operation	Description
	Press Alt+C.  Click
Set a mouse mode	<ul> <li>a. Select Mouse &gt; Mouse Mode.</li> <li>b. Select a mouse mode from the displayed mouse mode submenu.</li> <li>Absolute mouse mode: transfers the absolute position of the local mouse to the server to make the mouse on the server move.</li> <li>Relative mouse mode: calculates the displacement of the local mouse relative to the server mouse, and transfers it to the server to make the mouse on the server move.</li> <li>Other mouse mode: calculates the displacement of the local mouse relative to the center position, and transfers it to the server to make the mouse on the server move.</li> </ul>
Set the network bandwidth	a. Select <b>Options &gt; Bandwidth</b> .     b. Select the bandwidth from the displayed submenu.
Switch the encryption status of the mouse/keyboard	<ul> <li>Enable mouse/keyboard encryption: Select Options and then select Keyboard/Mouse Encryption.</li> <li>Disable mouse/keyboard encryption: Select Options and then deselect Keyboard/Mouse Encryption.</li> </ul>
Set the scaling mode of a remote screen	<ul> <li>a. Select Options &gt; Zoom.</li> <li>b. In the displayed submenu, set the zoom scale of the remote screen.</li> <li>Zoom In: zooms in the remote screen.</li> <li>Zoom Out: zooms out the remote screen.</li> <li>Actual Size: displays the remote screen in the proportion of 100%.</li> <li>Fit to Client Resolution: displays the remote screen in the resolution of the local client system.</li> <li>Fit to Host Resolution: displays the remote screen in the resolution of the remote server system.</li> </ul>
Send an IPMI command to the server	<ul> <li>a. Select Options &gt; Send IPMI Command. The IPMI Command Dialog window is displayed.</li> <li>b. Enter the IPMI command.</li> <li>c. Click Send.</li> <li>Note: The IPMI command supports hex format and ASCII format.</li> </ul>
Set a GUI language	Select Options > GUI Languages.     Select the GUI language from the displayed submenu. Only English is supported in the current version.
Set the privilege request mode	<ul> <li>a. Select Options &gt; Block Privilege Request.</li> <li>b. Select a privilege request block mode from the displayed submenu.</li> <li>Allow only Video: Privilege requests in the system are automatically granted access to video.</li> </ul>

Operation	Description
	Deny Access: Privilege requests in the system are blocked.
Request all permissions	Select Options > Request Full Permission.
Mount a local ISO file	<ul> <li>a. Open the Virtual Media window through either of the following ways:</li> <li>Select Media &gt; Virtual Media Wizard, and switch to the CD/DVD tab.</li> <li>Click Click Browse and select a local ISO file.</li> <li>C. Click Connect.</li> </ul>
Mount a local disk	<ul> <li>a. Select Media &gt; Virtual Media Wizard, and switch to the Hard Disk/USB tab.</li> <li>b. Select a local disk drive letter or click Browse and then select the image file of the local disk.</li> <li>c. Click Connect.</li> </ul>
Mount a local folder	<ul> <li>a. Create a new ISO file on the client PC</li> <li>b. Open the Virtual Media window through either of the following ways: <ul> <li>Select Media &gt; Virtual Media Wizard, and switch to the Hard Disk/USB tab.</li> <li>Click</li> </ul> </li> <li>c. Select Physical Drive &gt; Folder Path or Logical Drive &gt; Folder Path .</li> <li>d. Click Browse and select a local folder path.</li> <li>e. Set Size and Image Path.</li> <li>f. Click Connect.</li> <li>Note: Size must be the n-th power of 2, such as 2, 4 and 8. Image Path should be the same as the new ISO file path.</li> </ul>
Set keyboard layout	Select <b>Keyboard Layout</b> .     Select the keyboard layout from the displayed submenu.
Open the soft keyboard	Click .
Configure video recording	<ul> <li>a. Select Video Record &gt; Settings. The Video Record window is displayed.</li> <li>b. Set the video recording time length in seconds and the video storage position.</li> <li>c. Click OK.</li> <li>Note: The video recording time length ranges from 1 through 1800 seconds.</li> </ul>
Record a video	Start recording a video through either of the following ways:     Select Video Record > Start Record.

Operation	Description
	<ul> <li>Click</li> <li>b. (Optional) Stop recording a video through either of the following ways:</li> <li>Select Video Record &gt; Stop Record.</li> <li>Click</li> <li>C. After the preset recording time length is reached or the recording is stopped manually, click OK. The recorded video file is saved to the VideoCaptures folder in the preset path.</li> </ul>
Set the server power mode	<ul> <li>a. Select Power.</li> <li>b. Select a server power option from the displayed submenu.</li> <li>The server power options are as follows:</li> <li>Reset Server: restarts the system without shutting down the power supply (warm reboot).</li> <li>Immediate Shutdown: shuts down the server immediately by shutting down the power supply.</li> <li>Orderly Shutdown: shuts down the server in order through program control.</li> <li>Power On Server: starts the server.</li> <li>Power Cycle Server: shuts down the server and restarts it (cold reboot).</li> </ul>
Check active users	View the users using remote control through either of the following ways:  Select Active Users.  Click

# 3.9 Controlling the Server Power Supply


# **Abstract**

If the server power supply cannot be controlled on-site, you can control the server remotely on the client PC for power-on, power-off, restart, and BMC resetting.

# **Steps**

1. From the menu bar in the left pane, select **Power Control**. The **Power Control** page is displayed, see Figure 3-78.

**Figure 3-78 Power Control Page** 



2. Perform the following operations as required.

То	Do
Shut down the server	a. Select Power Off. b. Click Perform Action.
Power on the server	a. Select Power On. b. Click Perform Action.
Perform a cold reboot	<ul> <li>a. Select Power Cycle.</li> <li>b. Click Perform Action.</li> <li>Cold reboot means that the server is started after it is shut down. During the restart, the server is offline.</li> </ul>
Perform a warm reboot	<ul> <li>a. Select Hard Reset.</li> <li>b. Click Perform Action.</li> <li>Warm reboot means that the server is restarted when it is not shut down.</li> <li>During the restart, the server is not offline.</li> </ul>
Shut down the operating system of the server	a. Select ACPI Shutdown.     b. Click Perform Action.     ACPI shutdown refers to the operation of simulating the shutdown button of the operating system to shut down the operating system.
Reset the BMC	Click <b>Reset BMC</b> .  After the BMC is reset, you can log in to the Web portal again.
Enable the power supply anti-misoperation function	<ul> <li>a. Select Enable.</li> <li>b. Click Save.</li> <li>After the function is enabled, the server that is in power-on state will not be powered off if the power button is pressed for a short period (within 10 seconds).</li> </ul>
Disable the power supply anti-misoperation function	a. Select <b>Disable</b> .  b. Click <b>Save</b> .



То	Do
	After the function is disabled, the power button takes effect immediately
	when it is pressed.

# 3.10 NIC Information Query

# 3.10.1 Querying Ethernet NIC Information

#### **Abstract**

By querying the Ethernet NIC information, you can learn about the detailed information about the NIC and its port on the server.

#### Context

The Ethernet NIC uses the IP protocol, and it is connected to an Ethernet switch through optical fibers or twisted pairs.

The Ethernet NIC has optical interfaces and electrical interfaces.

- Optical interface: Data is transmitted through optical fibers.
- Electrical interface: Data is transmitted through twisted pairs. The common interface type is RJ45.

# **Steps**

From the menu bar in the left pane, select Network Device > NIC Information. The NIC page is displayed, see Figure 3-79.

#### Figure 3-79 NIC Page





The rate of the onboard NIC cannot be self-adaptive.

# 3.10.2 Querying FC NIC Information

### **Abstract**

By querying the FC NIC information, you can learn about the detailed information about the FC NIC and its port on the server.

#### Context

The FC NIC is also called fiber NIC, which uses the fiber channel protocol and is generally connected to a fiber channel switch through optical fibers.

The FC NIC has optical interfaces and electrical interfaces:

- Optical interface: Data is transmitted through optical fibers.
- Electrical interface: Data is transmitted through twisted pairs. The common interface type is D89 or HSSDC.

#### **Steps**

 From the menu bar in the left pane, select Network Device > FC Information. The FC page is displayed, see Figure 3-80.

#### Figure 3-80 FC Page



Some of the parameters in the FC information are described as follows:

- Healthy State: indicates the health status of the FC NIC, including healthy and faulty.
- Status: indicates the connection status of the ports of the FC NIC, including connected and disconnected.
- WWNN: indicates the globally unique identifier of the FC NIC.
- WWPN: indicates the globally unique identifier of the port of the FC NIC.



- → A single-port FC NIC has one WWNN and one WWPN.
- → A dual-port FC NIC has one WWNN and two WWPNs.

# 3.11 Fan Information and Air Intake Temperature Query

# 3.11.1 Querying Fan Information

#### **Abstract**

By querying fan information, you can learn about internal fans of the server.

### **Steps**

 From the menu bar in the left pane, select Fan&Temperature > Fan Information. The Fan Information page is displayed, see Figure 3-81.

Figure 3-81 Fan Information Page

Fan No.	Present	Fan Speed(RPM)	Fan Pwm Ration(%)	Healthy State
1	Yes	4112	50	Normal
2	Yes	0	50	Fault
3	Yes	4092	50	Normal
4	Yes	4115	50	Normal
5	Yes	4152	50	Normal
6	Yes	4101	50	Normal
7	Yes	4124	50	Normal
8	Yes	4115	50	Normal



- The Fan Speed(RPM) column displays the current speed of each fan.
- The Fan Pwm Ratio(%) column displays the ratio of the current speed of a fan to the maximum speed of the fan.

# 3.11.2 Querying Air Intake Temperatures

#### **Abstract**

This procedure describes how to query air intake temperatures to learn about the air intake temperature changes of the server.



The server supports the high-temperature power-off function. If this function is enabled, the server is powered off after the air inlet temperature reaches the preset threshold, avoiding damages to the server hardware. To ensure service operation stability, it is recommended to disable this function.

## **Steps**

From the menu bar in the left pane, select Fan&Temperature > Inlet Temperature. The Inlet Temperature page is displayed, as shown in Figure 3-82.

Figure 3-82 Inlet Temperature Page

2. (Optional) To save the temperature statistics (which are stored for a maximum of 60 hours on the BMC) to the local PC, click **Download**.

# 3.12 Power Supply Management

# 3.12.1 Configuring System Power Control Parameters

#### Abstract


System power includes:

- Capped power: Peak power of the server.
- **Threshold power**: An alarm is raised when the power of the server exceeds the threshold. By configuring system power control parameters, you can set the capped power and threshold power.

## **Steps**

From the menu bar in the left pane, select Power Management > System Power Limit.
 The System Power Limit page is displayed, see Figure 3-83.

Figure 3-83 System Power Limit Page



2. Perform the following operations as required.

То	Do	
Set the capped power	<ul> <li>a. In the Power Limit Set area, select Enable Limit.</li> <li>b. In the Power Limit Value text box, enter the capped power, with a range of 1–32767.</li> <li>c. Click Save Option in the Power Limit Set area.</li> </ul>	
Set the threshold power	<ul> <li>a. In the Power Limit Set area, select Enable Threshold.</li> <li>b. In the Power Threshold Value text box, enter the threshold power, with a range of 5–32767.</li> <li>c. Click Save Option in the Power Threshold Set area.</li> </ul>	

# 3.12.2 Collecting System Power Statistics

## **Abstract**

System power statistics show the fluctuations of system power in a designated period of time.

## **Steps**

1. From the menu bar in the left pane, select **Power Management > System Power Statistics**. The **System Power Statistics** page is displayed, see Figure 3-84.

Real 509 Watts
Time
Power
Power

Time Range
recent one hour

War Power

Max P

Figure 3-84 System Power Statistics Page

- 2. From the **Time Range** list, select a time range. A page is displayed, showing the system power statistics in the selected time range.
- 3. (Optional) To download historical data to the local PC, click **Download System Power**Statistics.

# 3.12.3 Querying Power Supply Information

#### Abstract

By querying power supply information, you can learn about the power supplies of the server.

# **Steps**

 From the menu bar in the left pane, select Power Management > Power Information. The Power Information page is displayed, see Figure 3-85.

Figure 3-85 Power Information Page





Power supply input types include:

- AC
- HVDC
- LVDC

# 3.12.4 Setting the Power Mode


#### **Abstract**

If all the power supplies are configured for a server and the power supply models are the same, the power mode can be set on the Web portal of the BMC. In other cases, you can set the power mode only through the CLI of the BMC.

# **Steps**

 From the menu bar in the left pane, select Power Management > Power Mode. The Power Mode Settings page is displayed, see Figure 3-86.

Figure 3-86 Power Mode Settings Page



2. Set the parameters. For a description of the parameters, refer to Table 3-35.

**Table 3-35 Parameter Descriptions for Power Supply Mode** 

Parameter	Description	Setting
Balance Mode	Whether the power modules supply power in load balancing mode.	<ul> <li>If you select Balance Mode, the power modules supply power in load balancing mode.</li> <li>If you clear Balance Mode, the power modules do not supply power in load balancing mode.</li> </ul>

Parameter	Description	Setting
Active-standby Mode	Whether the power modules supply power in active-standby mode.	<ul> <li>If you select Active-standby Mode, the power modules supply power in active-standby mode, and the active power supply must be specified.</li> <li>If you clear Active-standby Mode, the power modules do not supply power in active-standby mode.</li> </ul>

3. Click Save.

# 3.13 Querying KPIs

## **Abstract**

KPIs include the following:

- Chassis KPIs
  - → Static data: chassis health status.
  - → Dynamic data: includes the air inlet temperature, air outlet temperature, power input voltage, and power output voltage.
- CPU KPIs
  - → Static data: CPU details, including the number of CPU cores, maximum frequency, and model.
  - → Dynamic data: includes CPU temperature, total power, and dynamic load.

By querying the KPIs, you can learn about the operational status of the server.

## **Steps**

1. From the menu bar in the left pane, select **Key Performance**. The **KPI Overview** page is displayed, as shown in Figure 3-87.

Figure 3-87 KPI Overview Page



2. Perform the following operations as required.

То	Do
Query the static data of chassis KPIs	<ul> <li>a. In the upper area, click Chassis KPI and then Static Data. The static data of chassis KPIs is displayed, as shown in Figure 3-88.</li> <li>b. (Optional) If the value of Chassis Health Score is not 100, click the score to view the detailed score deduction items.</li> </ul>
Query the dynamic data of chassis KPIs	<ul> <li>a. In the upper area, click Chassis KPI and then Dynamic Data. The dynamic data of chassis KPIs is displayed, as shown in Figure 3-87.</li> <li>b. Click Detail for an indicator to check the indicator details.</li> </ul>
Query the static data of CPU KPIs	<ul><li>a. In the upper area, click CPU KPI and then Static Data. The static data of CPU KPIs is displayed, as shown in Figure 3-89.</li><li>b. Check CPU details.</li></ul>
Query the dynamic data of CPU KPIs	<ul> <li>a. In the upper area, click CPU KPI and then Dynamic Data. The dynamic data of CPU KPIs is displayed, as shown in Figure 3-90.</li> <li>b. Click Detail for an indicator to check the indicator details.</li> </ul>

**Figure 3-88 Static Data of Chassis KPIs** 




Figure 3-89 Static Data of CPU KPIs




Figure 3-90 Dynamic Data of CPU KPIs



# 3.14 Maintenance Management

# 3.14.1 Querying Firmware Information

### **Abstract**


By querying the firmware information, you can learn about the firmware version of each board on the server. If a firmware version is low and there are upgrade files for higher version, you can upgrade the firmware of the corresponding board.

#### Context

The board firmware versions include EPLD, BMC, FRU and BIOS.

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- Click Firmware Information. The Firmware Information page is displayed, see Figure 3-91.

Figure 3-91 Firmware Information Page





If LTC is displayed in the Version Auxiliary Information, the manufacturer of the EPLD on the main-board is the Lattice Semiconductor Corporation.

# 3.14.2 Restoring Factory Defaults

#### **Abstract**

By restoring factory defaults, you can restore the server configuration items (for example, the network, user, SNMP configuration and startup mode) to factory defaults.



Do not perform any operation during restoration.

After factory defaults are restored, the server is restarted.

- From the menu bar in the left pane, select Maintenance. The Maintenance page is displayed.
- Click Restore Factory Defaults . The Restore Factory Defaults page is displayed, see Figure 3-92.

Figure 3-92 Restore Factory Defaults Page



3. Click Restore Factory Defaults.

# 3.14.3 Configuring a System Administrator

## **Abstract**

By configuring a system administrator, you can enable or disable the system administrator to access the BMC backend command line system and configure the password for the system administrator to log in to the BMC backend command line system.

# **Steps**

- From the menu bar in the left pane, select Maintenance. The Maintenance page is displayed.
- Click System Administrator. The System Administrator page is displayed, see Figure 3-93.

Figure 3-93 System Administrator Page



3. Configure the system administrator parameters. For a description of the parameters, refer to Table 3-36.

**Table 3-36 System Administrator Parameter Descriptions** 

Parameter	Description	Setting
Username	Username used to log in to the BMC backend command line system.	This parameter is read only, and you do not need to configure it.
	command line system.	

Parameter	Description	Setting
Enable User Access	Whether to enable the system administrator to access the BMC backend command line system.	To enable the system administrator to access the BMC back-end command line system, select Enable User Access.  To disable the system administrator to access the BMC back-end command line system, deselect Enable User Access.
Change Password	Whether to change the login password of the system administrator. The default passwords depend on the server models and BMC versions. For details, refer to 5 Reference: Default Passwords.	<ul> <li>To change the login password for the system administrator, select Change Password , and enter Password and Confirm Password .         Range of password length: 8–64 characters.</li> <li>If the login password for the system administrator does not need to be changed, deselect Change Password .</li> </ul>
Strong Password	Whether to enable the strong password policy.	The password must contain four types of characters (uppercase letters, lowercase letters, digits, and symbols).  To enable the strong password policy, select Strong Password.  To disable the strong password policy, deselect Strong Password.

4. Click Save.

# 3.14.4 Upgrading Firmware

## **Abstract**

If the firmware on the mainboard of a server needs an upgrade, you can upload the firmware online for upgrade.

If multiple firmware versions need an upgrade, the following sequence is recommended:

FRU firmware
 After the FRU firmware is upgraded, the BMC is automatically restarted to apply the new version.

## 2. BMC firmware

The Web portal of the BMC temporarily supports the upgrade of the active BMC firmware only. After the active BMC firmware is upgraded, the BMC is automatically restarted to apply it

3. EPLD firmware

After the EPLD firmware is upgraded, the new version takes effect only after the server is restarted. Therefore, it is recommended that you stop the services running on the server before the upgrade.

#### 4. BIOS firmware

After the BIOS firmware is upgraded, the new version takes effect only after the server is restarted. Therefore, it is recommended that you stop the services running on the server before the upgrade.

- If the BIOS firmware is upgraded when the server is powered off, the upgraded BIOS firmware takes effect directly.
- If the BIOS firmware is upgraded when the server is powered on, the upgraded BIOS
  firmware is displayed as a standby version on the Web portal and takes effect automatically after the server is powered off and restarted. It takes time for the new version to
  take effect automatically. During this period, firmware upgrade is not allowed.

#### 5. VR firmware



If a firmware version fails to be upgraded during version upgrade, you must upgrade it again.

## **Prerequisite**


You have obtained the version upgrading files.



The firmware upgrade files can be downloaded on the Web portal ( <a href="https://vantageo.com">https://vantageo.com</a>) of the servers.

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- 2. Click Firmware Update. The Firmware Update page is displayed, see Figure 3-94.

#### Figure 3-94 Firmware Update Page



In the **Version Upgrade** area, click
sion file.



Only one version file can be selected at a time. When the firmware version is updated, the firmware type is automatically matched.

- 4. (Optional) Select the following check box as needed if the BIOS firmware is upgraded.
  - Effect Bios Immediately: When the server is powered on and the BIOS firmware is upgraded, the server is automatically powered off and then powered on to make the upgraded firmware take effect.
  - **Upgrade BIOS Without Inheriting Configuration**: After the upgraded BIOS firmware takes effect, the default BIOS configuration is restored.
  - **Upgrade BIOS Without Inheriting Configuration**: After the upgraded BIOS firmware takes effect, the default BIOS configuration is restored.



When the server is powered on, the upgraded BIOS firmware takes effect after the server is powered off, power cycled, or hard rebooted.

5. Click **Start firmware update**. The firmware upgrade progress is displayed below.



#### Notice

During the version upgrade process, it is not allowed to switch to another page. Otherwise, the version upgrade process is interrupted.



After the BIOS firmware and BMC firmware are upgraded, the **Other Firmware Update** page is refreshed as follows:

- BIOS firmware: When the server is powered on, the firmware version number generated after upgrade is displayed in the BIOS Version to be effective column, and Active is displayed in the operation column. When the server is powered off, the firmware version number generated after upgrade is displayed in the Running BIOS Version, and switch is displayed in the operation column.
- BMC firmware: The firmware version number generated after upgrade is displayed in the **Master BMC Ver** column, and the version number originally displayed in the **Master BMC Ver** column is displayed in the **Slave BMC Ver** column.
- 6. (Optional) When the BIOS firmware is upgraded, and **Effect Bios Immediately** is not selected, click **Active** in the **operation** column of the **BIOS Version Information**.



The server is powered off and then powered on automatically to make the upgraded firmware take effect.

#### **Related Tasks**

Perform the following operations as required.

То	Do
Perform a switchover between the running BIOS version and the BIOS version to be effective	In the BIOS Version Information area, click switch.
Perform a switchover between the active and standby BMC versions	In the BMC Version Information area, click switch.



- After the switchover between the running BIOS version and the BIOS version to be effective, the server is automatically restarted.
- After the switchover between the active and standby BMC versions, the BMC is automatically restarted.

# 3.14.5 Exporting Data in One Click

## **Abstract**

By exporting data in one click, you can export the log data of the BMC to the local PC. The exported log file name is <code>bmcinfo\_SN.tar.gz</code>, which is stored in the default download directory of the browser.




If the SN of the server cannot be queried, the name of the exported log file is <code>bmcinfo\_UnknownProductSN.tar.gz</code>.

## **Steps**

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- 2. Click **Expert Data**. The **Download Expert Data** page is displayed, see Figure 3-95.

Figure 3-95 Download Expert Data Page



3. Click **Download Data**. The download progress is displayed, see Figure 3-96.

Figure 3-96 Download Progress Page





Figure 3-97 shows the downloaded page.

Figure 3-97 Download Completed Page



# 3.14.6 Backing Up BMC Configurations

## Abstract

Before replacing the mainboard of the server, you must export the BMC configurations. After the mainboard is replaced, you can import the BMC configurations.

- 1. Select Maintenance. The Maintenance page is displayed.
- Click Backup Configuration. The Backup Configuration page is displayed, see Figure 3-98.

Figure 3-98 Backup Configuration Page



3. Perform the following operations as required.

То	Do
Export configurations	<ul> <li>a. Click Export Configuration. The Export Configuration page is displayed.</li> <li>b. Click Download Configuration.</li> </ul>
Import configurations	<ul> <li>a. Click Import Configuration. The Import Configuration page is displayed.</li> <li>b. Click Click Upload Configuration.</li> </ul>

# 3.14.7 Updating PCIe Topology

#### Abstract

If there are changes on the hardware configuration on a server, such as unplugging and plugging the Riser card, changing the NVMe wiring, the PCIe slot topology information assigned by the BMC changes accordingly. Once the PCIe topology changes, the BMC Web portal will report the **30840** alarm, at which point the PCIe topology needs to be updated.

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- 2. Click **PCle Topology Update**. The **PCle Topology Update** page is displayed, see Figure 3-99.

Figure 3-99 PCIe Topology Update Page



3. Click Update.

# 3.15 Fault Diagnosis Management

# 3.15.1 Triggering an NMI

## **Abstract**

When the server is faulty, you can try to trigger an NMI by using the **NMI Control** function and then perform fault diagnosis.



The **NMI Control** function is used when the server operating system cannot be used. This function is disabled when a server is operating properly.

## **Steps**

From the menu bar in the left pane, select Fault Diagnose > NMI Control. The NMI Control page is displayed, see Figure 3-100.

Figure 3-100 NMI Control Page



2. Click Trigger NMI.

#### 3.15.2 Enabling Auto-Capture

#### **Abstract**

This procedure describes how to enable the last-screen capture function for the server for fault diagnosis.

Screenshots are captured automatically when the following conditions are met:

- The server restarts after a fatal error (for example, a CPU fault) occurs.
- The BMC triggers Hard Reset.
- The BMC triggers **Power Cycle**.
- The BMC triggers Power Off.

For a description of the power supply-related operations triggered by the BMC, refer to "3.9 Controlling the Server Power Supply".




If the KVM operates, the auto-capture function becomes invalid. Therefore, you must disable the KVM before using this function.

#### **Steps**

 From the menu bar in the left pane, select Fault Diagnose > Screenshots. The Screen Captured page is displayed, see Figure 3-101.

Figure 3-101 Screen Captured Page



- 2. Select whether to enable the automatic last-screen capture function.
  - Close: Not captured automatically.

- Open: When the triggering conditions are met, the last screen of the server is automatically captured and displayed in the lower part of the page.
- 3. Click Perform Action.

### 3.15.3 Manually Capturing Screenshots

#### **Abstract**

This procedure describes how to capture the current screen of the server for fault diagnosis.




If the KVM operates, the manual screenshot capture function becomes invalid. Therefore, you must disable the KVM before using this function.

#### **Steps**

 From the menu bar in the left pane, select Fault Diagnose > Manual Screenshots. The Manual Screenshots page is displayed, see Figure 3-102.

Figure 3-102 Manual Screenshots Page



2. Perform the following operations as required.

То	Do
Capture a screenshot of the current screen	Click <b>Manual Screenshots</b> . The screenshot of the current screen is displayed in the lower part of the page.
Delete a captured screenshot	Click Delete Screenshots.

## 3.15.4 Querying POST Codes

#### **Abstract**

POST codes record the status of the server during power-on.

This procedure describes how to check POST codes for fault diagnosis.

#### **Steps**

 From the menu bar in the left pane, select Fault Diagnose > PostCode. The System post code page is displayed, as shown in Figure 3-103.

Figure 3-103 System post code Page



2. Check Server on off status, This post code, and Last post code.

### 3.15.5 Downloading Host Logs

#### **Abstract**

If there is a fault, the serial port prints host logs. You can download these logs for troubleshooting.

#### **Steps**

1. From the menu bar in the left pane, select **Fault Diagnose > Host Log**. The **Host Log** page is displayed, see Figure 3-104.

#### Figure 3-104 Host Log Page



2. Click download.

# **Chapter 4**

# **Common Operations**

#### **Table of Contents**

Logging In to the BMC Management Backend in SSH Mode	148
Logging In to the BMC Management Backend Through the Serial Port	150
Logging In to the Web Portal of the BMC Through the Shared Network Port	153
Modifying the BMC Address	154
Querying Server Information	157
Managing RAIDs	158
Installing the Operating System Remotely	162
Resetting the BMC	168
Querying and Configuring a Temperature Policy	169
Querying and Configuring Services	172
Configuring the NTP Server	175
Configuring the SMTP Server	177
Configuring SNMP Trap	178
Handling Network Port Alarms	181
Exporting BMC Logs	181
Upgrading the BMC Version	186
Restoring Factory Defaults	188
Backing Up BMC Configurations	189
dentifying a Liquid-Cooled Server	189
Creating an SNMP Licer	101

## 4.1 Logging In to the BMC Management Backend in SSH Mode

#### Abstract

You can log in to the BMC management backend in SSH mode to configure the BMC.

### **Prerequisite**

The client PC is installed with the SSH software, for example, PuTTY.




The operations for different SSH software are similar. This procedure describes how to configure the *PuTTY* software.

#### **Steps**

1. On the client PC, open the *PuTTY* software. The **PuTTY Configuration** dialog box is displayed, see Figure 4-1.

**Figure 4-1 PuTTY Configuration Dialog Box** 



2. Configure the parameters. For a description of the parameters, refer to Table 4-1.

Table 4-1 Pu	TTY Configurat	ion Paramete	r Descriptions
--------------	----------------	--------------	----------------

Parameter	Description	Setting
Category	Operation type.	Select <b>Session</b> .
Host Name (or IP address)	Host name or IP address.	Enter the IP address of the iSAC management network port or shared network port.
Port	Port number.	Enter 22.
Connection type	Connection type.	Select SSH.

- 3. Click **Open**. The command line window is displayed.
- 4. Enter the account and password of the administrator.



The default administrator username is <code>sysadmin</code>. The default administrator password depends on server models and BMC versions. For details, refer to 5 Reference: Default Passwords.

5. Press Enter to log in to the management backend of the BMC.

# 4.2 Logging In to the BMC Management Backend Through the Serial Port

#### **Abstract**

When neither the iSAC management network port nor the shared network port can access the BMC, you can log in to the BMC management backend through the serial port to configure the BMC.

#### **Prerequisite**

The client PC is installed with SSH software, for example, PuTTY.



The operations for different SSH software are similar. This procedure describes how configure the PuTTY software.

- If the client PC converts the serial port through the USB port, the driver for converting the serial port through the USB port must be installed.
- A serial cable is available.

#### **Steps**

1. Connect the client PC to the serial port on the rear panel of the server through a serial cable.

For the position of the serial port on the rear panel, refer to Figure 4-2.

Figure 4-2 Position of the Serial Port





The positions of the serial ports on the rear panels of servers are basically the same. This procedure uses the position of the serial port on the rear panel of an 2230-RE server as an example.

2. Press and hold the UID indicator on the front panel of the server for eight seconds. The serial port is switched to the BMC debugging serial port mode.

For the position of the UID indicator on the front panel, see Figure 4-3.

Figure 4-3 Position of the UID Indicator






The positions of the UID indicators on the front panels of servers are basically the same. This procedure uses the position of the UID indicator on the front panel of an 2230-RE server as an example.

- 3. On the **Device Manager** page on the client PC, query the serial port connected with the serial cable.
- 4. On the client PC, open the *PuTTY* software. The **PuTTY Configuration** dialog box is displayed, see Figure 4-4.

**Figure 4-4 PuTTY Configuration Dialog Box** 



5. Configure the parameters. For a description of the parameters, refer to Table 4-2.

**Table 4-2 PuTTY Configuration Parameter Descriptions** 

Parameter	Description	Setting
Category	Operation type.	Select <b>Session</b> .
Serial line	Serial port.	Enter the serial port queried in Step 3.
Speed	Speed.	Enter 115200.
Connection type	Connection type.	Select <b>Serial</b> .

- 6. Click **Open**. The command line window is displayed.
- 7. Enter the account and password of the administrator.



The default administrator username is <code>sysadmin</code>. The default administrator password depends on server models and BMC versions. For details, refer to 5 Reference: Default Passwords.

8. Press Enter to log in to the management backend of the BMC.

# 4.3 Logging In to the Web Portal of the BMC Through the Shared Network Port

#### **Abstract**

In addition to the iSAC management network port, you can also log in to the Web portal of the BMC through the shared network port.

#### **Steps**

1. Perform the following operations as required.

То	Do
Modify the network configuration of the shared network port through the Web portal of the BMC	<ul> <li>a. From the menu bar in the left pane, select Settings. The Settings page is displayed.</li> <li>b. Click Network Settings. The Network Settings page is displayed.</li> <li>c. Click Sideband Interface (NC-SI). The Sideband Interface (NC-SI) page is displayed.</li> <li>d. Configure the following parameters: <ul> <li>NCSI Mode: Select Manual Switch Mode.</li> <li>NCSI Interface: Select eth0.</li> </ul> </li> <li>e. Click Save.</li> <li>f. On the Network Settings page, click Network IP Settings. The Network IP Settings page is displayed.</li> <li>g. Configure the following parameters: <ul> <li>Enable LAN: Select Enable LAN.</li> <li>LAN Interface: Select eth0.</li> <li>Select Enable IPv4, and configure IPv4 Address, IPv4 Subnet and IPv4 Gateway.</li> </ul> h. Click Save.</li> </ul>
Modify the network configura- tion of the shared network port through BIOS	<ul> <li>a. In the BIOS window, select iSAC &gt; BMC Network Configuration. The BMC Network Configuration window is displayed.</li> <li>b. Configure the gateway-related parameters in the NIC (Shared) area.</li> <li>c. Press F4 to save the configuration and exit.</li> </ul>

2. Connect the shared network port to the client PC through a network cable.



The shared network port can be connected to the client PC directly through a network cable or a network device.

In most cases, the onboard service port marked as **1** is the shared port. For the position of the shared port on the rear panel, see Figure 4-5.

Figure 4-5 Position of the Shared Port





The positions of the shared ports on the rear panels of servers are basically the same. This procedure uses the position of the shared port on the rear panel of an 2230-RE server as an example.

Log in to the Web portal of the BMC on the client PC.For details, refer to "3.1 Logging In to the Web Portal of the BMC".

## 4.4 Modifying the BMC Address


#### **Abstract**

To re-plan the BMC address of the server, you must modify the IP address, subnet mask and default gateway of the iSAC management network port or shared network port.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Network Settings**. The **Network Settings** page is displayed.
- 3. Click **Network IP Settings**. The **Network IP Settings** page is displayed, see Figure 4-6.

Figure 4-6 Network IP Settings Page



4. Configure the parameters. For a description of the parameters, refer to Table 4-3.

**Table 4-3 Parameter Descriptions for the Network IP Address Configuration** 

Parameter	Description	Setting
Enable LAN	Whether to enable the network port.  The network port is selected from the LAN Interface list.	Select <b>Enable LAN</b> . The network port is enabled.
LAN Interface	Current network port.	<ul> <li>To configure the management network port, select eth1.</li> <li>To configure the shared network port, select eth0.</li> </ul>
MAC Address	MAC address of the corresponding network port.	This parameter is displayed only and cannot be configured.
Enable IPv4	Whether the network port enables the IPv4 protocol.	<ul> <li>Select Enable IPv4. The IPv4 protocol is enabled.</li> <li>Clear Enable IPv4. The IPv4 protocol is disabled.</li> <li>The IPv4-related parameters can be configured only after Enable IPv4 is selected.</li> <li>To automatically obtain the IP address, select IPv4 DHCP.</li> <li>To manually configure the IP address, deselect IPv4 DHCP, and manually configure IPv4 Address, IPv4 Subnet and IPv4 Gateway.</li> </ul>
Enable IPv6	Whether the network port enables the IPv6 protocol.	<ul> <li>Select Enable IPv6. The IPv6 protocol is enabled.</li> <li>Clear Enable IPv6. The IPv6 protocol is disabled.</li> <li>The IPv6-related parameters can be configured only after Enable IPv6 is selected.</li> <li>To automatically obtain the IP address, select IPv6 DHCP.</li> <li>To manually configure the IP address, deselect IPv6 DHCP, and manually configure IPv6 Index, IPv6 Address, Subnet Prefix Length and IPv6 Gateway.</li> </ul>
Enable VLAN	Whether the network port enables VLAN.	<ul> <li>Select Enable VLAN. The network port can be added into a VLAN.</li> <li>Clear Enable VLAN. The network port cannot be added into a VLAN.</li> <li>The VLAN-related parameters can be configured only after Enable VLAN is selected.</li> </ul>

Parameter	Description	Setting
		• VLAN ID: 1–4094.
		• VLAN Priority: 0-7, with 7 of the highest priori-
		ty.

5. Click Save.

## 4.5 Querying Server Information

#### **Abstract**


Before reporting a fault or replace the corresponding hardware, a user must query the server information, including:

- Serial No.
- CPU
- Memory
- NIC

#### **Steps**

1. From the menu bar in the left pane, select **Overview**. The **Overview** page is displayed, see Figure 4-7.

Figure 4-7 Overview Page






On the Overview page, you can view Product Serial Number, CPU and Memory Capacity.

From the menu bar in the left pane, select Network Device > NIC Information. The NIC page is displayed, see Figure 4-8.

Figure 4-8 NIC Page





On the NIC page, you can view the Ethernet NIC information.

 From the menu bar in the left pane, select Network Device > FC Information. The FC page is displayed, see Figure 4-9.

#### Figure 4-9 FC Page





On the **FC** page, you can view the **FC** NIC information.

## 4.6 Managing RAIDs

#### **Abstract**

You can perform the following common operations to manage RAIDs:

- Querying the RAID controller information
- Querying the physical device information

- Creating a RAID
- Setting a RAID as the boot disk

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click RAID Management. The RAID Management page is displayed, see Figure 4-10.

Figure 4-10 RAID Management Page




3. Perform the following operations as required.

То	Do
Query the RAID controller information	<ul> <li>a. Click RAID Controller Information. The RAID Controller Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the RAID controller you want to query. The information about the selected RAID controller is displayed in the lower part of the page.</li> <li>c. (Optional) In the RAID Event Log Statistics area, click Details. The Event Log page is displayed, where you can view the event logs of the RAID controller.</li> </ul>
Query the physical device information	<ul> <li>a. Click Physical Device Information. The Physical Device Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the RAID controller you want to query. The information about all the physical disks managed by the selected RAID controller is displayed in the lower part of the page.  The State information in the physical disk information is described as follows: <ul> <li>Online: The member disk of the logical disk is online.</li> <li>Missing: The member disk of the logical disk is removed.</li> <li>Offline: The member disk of the logical disk is offline.</li> <li>Rebuild: Rebuild. The hard disk is rebuilding data to ensure data redundancy and integrity of the logical disk.</li> <li>Shield State: Protected. Temporary status of the diagnosis operation.</li> <li>Hotspare: Hot spare disk.</li> <li>Copyback: Copyback. A new disk is replacing a faulty member disk.</li> </ul> </li></ul>

То	Do
	<ul> <li>Bootable: Boot disk.</li> <li>Unconfigured_good: Not configured, and the hard disk is available.</li> <li>Unconfigured_bad: Not configured, and the hard disk is not available.</li> <li>PredictiveFailure: Failure. The hard disk is unavailable.</li> <li>ExposedToOS: Pass-through disk. This state is displayed when the RAID controller card is set to pass-through mode or set to mixed mode but no RAID controller card is created.</li> <li>C.</li> <li>(Optional) Click on the right of the physical hard disk. More actions are displayed.</li> </ul>
Create a RAID	<ul> <li>a. Click Logical Device Information. The Logical Device Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the controller to which the RAID to be created belongs.</li> <li>c. Click Create Virtual Device. The Create Virtual Device page is displayed, see Figure 4-11.</li> <li>d. Configure the following key parameters: <ul> <li>RAID Controller Name: Select the controller to which the RAID to be created belongs.</li> <li>RAID Level: Select the corresponding RAID level.</li> <li>Logical Device Name: Enter the RAID name.</li> <li>Initialization: Select Quick Initialization.</li> <li>UnConfigured Physical Drives: Select the disk required to create a RAID.</li> <li>The other parameters are set to the default values.</li> <li>e. Click Save.</li> </ul> </li> </ul>
Set a RAID as the boot disk	<ul> <li>a. Click Logical Device Information. The Logical Device Information page is displayed.</li> <li>b. From the Select the RAID Controller list, select the controller that the RAID belongs to.</li> <li>c. Click for the RAID that you want to set as the boot disk.</li> <li>d. Click .</li> </ul>

Figure 4-11 Create Virtual Device Page



## 4.7 Installing the Operating System Remotely

#### **Abstract**

If the operating system cannot be installed on-site, you can install it remotely on the client PC.

The operations for remote OS installation include:

- 1. Disable media redirection configurations
- 2. Configure a boot mode
- 3. Install the operating system

#### **Prerequisite**


- The ISO image file of the operating system is obtained.
- The RAID configuration of the system disk of the server is completed.
- If the KVM is started in JAVA mode, the JRE is installed on the client PC, for example, jre-8u191.

#### **Steps**

#### **Disabling Media Redirection Configurations**


- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Media Redirection Settings. The Media Redirection page is displayed.
- 3. Click **VMedia Instance Settings**. The **VMedia Instance Settings** page is displayed, see Figure 4-12.

Figure 4-12 VMedia Instance Settings Page



- 4. Deselect Encrypt Media Redirection Packets.
- 5. Click Save.
- 6. On the **Media Redirection** page, click **Remote Session**. The **Remote Session** page is displayed, see Figure 4-13.

Figure 4-13 Remote Session Page




- 7. Deselect Enable KVM Encryption.
- 8. Click Save.

#### **Configuring a Boot Mode**

9. On the **Settings** page, click **Boot Option Settings**. The **Boot Option** page is displayed, see Figure 4-14.

Figure 4-14 Boot Option Page




- 10. Select CD ROM and Persistent.
- 11. Click Save Option.

#### **Installing the Operating System**

12. From the menu bar in the left pane, select **Remote Control**. The **Remote Control** page is displayed, see Figure 4-15.

**Figure 4-15 Remote Control Page** 



13. Perform the following operations as required.

То	Do
Start the KVM in HTML mode	<ul> <li>a. Click Launch KVM (HTML). The Remote KVM (HTML) window is displayed, see Figure 4-16.</li> <li>b. Click Browse File on the right of CD Image, and select the ISO image file from the client PC.</li> <li>c. Click Start Media and load the ISO image file.</li> <li>d. Select Power &gt; Reset Server and restart the server. The page for installing the operating system is displayed.</li> </ul>
Start the KVM in JAVA mode	<ul> <li>a. In the search box in the lower left corner of the client PC, enter Java.</li> <li>b. In the search result, select Java. The Java Control Panel dialog box is displayed.</li> <li>c. Click Security. The Security window is displayed.</li> <li>d. Click Edit Site List. The Exception Site List dialog box is displayed.</li> <li>e. Click Add to add the address of the BMC Web portal.</li> <li>f. Click OK to return to the Security window.</li> <li>g. Click OK.</li> <li>h. On the Remote Control page of the BMC Web portal, click Launch KVM (JAVA). A dialog box indicating whether to keep jview-er.jnlp is displayed.</li> <li>i. Click Keep.</li> </ul>

То	Do	
	j. In the lower left corner of your browser, click <code>jviewer.jnlp</code> . A dia-	
	log box is displayed.	
	k. Click Continue. The Do you want to run this application? dialog	
	box is displayed.	
	Select I accept the risk and want to run this app. and click Run.	
	The <b>Untrusted Connection</b> dialog box is displayed.	
	m. Click <b>Yes</b> . The <b>Remote KVM (JAVA)</b> page is displayed, see Figure	
	4-17.	
	n. Select Media > Virtual Media Wizard, and switch to the CD/DVD	
	tab.	
	O. Click <b>Browse</b> and select the ISO image file from the client PC.	
	p. Click Connect.	
	q. Select <b>Power &gt; Reset Server</b> and restart the server. The page for in-	
	stalling the operating system is displayed.	



Before starting the KVM in one mode, you must disable the KVM in another mode. For example, before starting the KVM in JAVA mode, you must disable the KVM started in HTML mode.

Figure 4-16 Remote KVM (HTML) Window





Figure 4-17 Remote KVM (JAVA) Window



## 4.8 Resetting the BMC

#### **Abstract**

If you cannot log in to the BMC Web portal, you must reset the BMC.

You can reset the BMC through one of the following ways:

- Reset the BMC by logging in to the server
- Reset the BMC by using a SSH tool (for example, PuTTY)
- Reset the BMC by using the ipmitool
- Reset the BMC by powering off the server

#### **Prerequisite**

- If the BMC is reset by using the ipmitool, the port number of the **ipmi** service is set to **623**.
- If the BMC is reset by using the ipmitool, the BMC address is successfully pinged with the ipmitool.

#### **Steps**

- Reset the BMC by logging in to the server
  - 1. Log in to the server as the root user.
  - 2. Run the following commands to reset the BMC:

```
# modprobe ipmi_si
# modprobe ipmi_devintf
# ipmitool mc reset cold
```

- Reset the BMC by using a SSH tool
  - 1. Log in to the BMC management backend by using the SSH tool.

Enter the following parameters for login:

- → Host Address: BMC address
- → Username: sysadmin
- → Password: refer to 5 Reference: Default Passwords
- → Port: 22
- 2. Run the following command to reset the BMC:
  - # reboot
- Reset the BMC by using the ipmitool
  - 1. In the ipmitool, run the following command to reset the BMC:
    - → Warm boot: ipmitool -I lan -H 10.43.211.200 -U root -P Superuser9! mc reset warm Sent warm reset command to MC
    - → Cold reboot: ipmitool -I lan -H 10.43.211.200 -U root -P Superuser9! mc reset cold Sent cold reset command to MC

The parameters in the command are described as follows:

- → **10.43.211.200**: BMC address
- → root: username
- → Superuser9!: password
- Reset the BMC by powering off the server
  - 1. Power off the server without services.
  - 2. Power on the server.

## 4.9 Querying and Configuring a Temperature Policy

#### **Abstract**

A temperature policy refers to the policy of whether to shut down a server after the server temperature reaches a specified threshold.


You can set the temperature thresholds on the BMC Web portal, and query and configure a temperature policy by using the ipmitool.

#### **Steps**

#### **Setting Temperature Thresholds**

- 1. From the menu bar in the left pane, select **Sensor**. The **Sensor Reading** page is displayed.
- In the Normal Sensors area, click the sensor with the keyword INPUT\_TEMP in its name.
   The Sensor detail page is displayed.
- 3. Click **Change Thresholds**. The **Sensor Thresholds** page is displayed, see Figure 4-18.

Figure 4-18 Sensor Thresholds Page



4. Configure the parameters. For a description of the parameters, refer to Table 4-4.

Table 4-4 Te	emperature	<b>Threshold</b>	Descri	ptions
--------------	------------	------------------	--------	--------

Parameter	Description	Setting
Upper Non-recov- erable	A fatal alarm is raised when the temperature reaches the threshold.	It is set to 55 by default.
Upper Critical	A critical alarm is raised when the temperature reaches the threshold.	It is set to 50 by default.
Upper Non-critical	A minor alarm is raised when the temperature reaches the threshold.	It is set to 45 by default.



When the threshold specified in **Upper Critical** is reached, the server is shut down.

5. Click Save.

#### **Querying and Configuring a Temperature Policy**

6. In the ipmitool tool, run the following command to query the temperature policy:

ipmitool -I lan -H 10.43.211.200 -U root -P Superuser9! raw 0x2e 0xd6 0x3e 0x0f 0

The parameters in the command are described as follows:

- 10.43.211.200: BMC address
- root: username
- Superuser9!: password

The values returned after the command is run are described as follows:

- 1: indicates that the over-temperature shutdown policy is enabled.
- **0**: indicates that the over-temperature shutdown policy is disabled.
- 7. (Optional) To adjust the temperature policy, run the following command to configure the temperature policy:

ipmitool -I lan -H 10.43.211.200 -U root -P Superuser9! raw 0x2e 0xd6 0x3e 0x0f 0 1

The last byte in the command is described as follows:

- 1: indicates that the over-temperature shutdown policy is enabled.
- **0**: indicates that the over-temperature shutdown policy is disabled.

## 4.10 Querying and Configuring Services

#### **Abstract**

By default, the BMC provides the following services:


- web
- kvm
- VirtualMedia-CD
- VirtualMedia-HD
- ssh
- snmp
- redfish
- vnc
- ipmi

To query or modify the parameters of the services above, you can query and configure services.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Services**. The **Services** page is displayed, see Figure 4-19.

Figure 4-19 Services Page



3. Perform the following operations as required.


То	Do
View the active sessions of a service	a. Click on the left of a service. The number of the active sessions is expanded under this service.

То	Do
	<ul> <li>b. Click on the right of the service. The Service Sessions page is displayed, see Figure 4-20.</li> <li>On the Service Sessions page, you can view the detailed information of the active sessions.</li> <li>C. (Optional) To terminate a session, click for the session.</li> </ul>
Set parameters for a service	<ul> <li>a. Click on the right of a service. The Service Configuration page is displayed, see Figure 4-21.  This procedure uses the KVM service as an example. The operations for configuring other services are similar.</li> <li>b. Configure the parameters. For a description of the parameters, refer to Table 4-5.</li> <li>c. Click Save.</li> </ul>

#### Figure 4-20 Service Sessions Page



**Figure 4-21 Service Configuration Page** 



**Table 4-5 Service Parameter Descriptions** 

Parameter	Description	Setting
Active	Whether to enable the service.	<ul> <li>Select Active. The service is available.</li> <li>Deselect Active. The service is not available.</li> </ul>
Non-secure port	Non-secure port number of the service.	Default non-secure port number of the Web service: 80.

Parameter	Description	Setting
		<ul> <li>Default non-secure port number of the KVM service: 7578.</li> <li>Default non-secure port number of the CD media service: 5120.</li> <li>Default non-secure port number of the HD media service: 5123.</li> <li>The SSH service does not support non-secure ports.</li> <li>Default non-secure port number of the SNMP service: 161.</li> <li>Default non-secure port of the VNC service: 5900.</li> <li>Range of the non-secure port number: 1 – 65535.</li> </ul>
Secure port	Secure port number of the service.	<ul> <li>Default secure port number of the Web service: 443.</li> <li>Default secure port number of the KVM service: 7582.</li> <li>Default non-secure port number of the CD media service: 5124.</li> <li>Default non-secure port number of the HD media service: 5127.</li> <li>Default secure port number of the SSH service: 22.</li> <li>Default secure port number of the VNC service: 5901.</li> <li>Range of the secure port number: 1–65535.</li> </ul>
Timeout	Timeout period after which the service exits if no operation is performed.	<ul> <li>The timeout period of the Web service and KVM service ranges from 300 through 1800 seconds.</li> <li>The timeout period of the SSH service ranges from 60 through 1800 seconds.</li> <li>The timeout period must be a multiple of 60.</li> </ul>

# **4.11 Configuring the NTP Server**

#### **Abstract**

The time on the BMC is synchronized from the NTP server.

The operations for configuring the NTP server include:

- Enable the NTP service: Provides the NTP service for the devices whose time needs to be synchronized.
- 2. Modify the registry: Modifies the registry parameters related to the NTP service.
- 3. Restart the NTP service: Applies the modified registry parameters.



This procedure describes how to perform the operations on a PC with the Windows 10 operating system.

#### **Steps**

#### **Enabling the NTP Service**

- 1. Right-click **This PC** on the desktop, and then select **Manage** from the shortcut menu. The **Computer Management** window is displayed.
- 2. From the navigation tree in the left pane, select **Services and Applications > Services**. The **Services** window is displayed.
- 3. In the service list, right-click **Windows Time** and select **Start** from the shortcut menu.

#### **Modifying the Registry**

- 4. Press Windows+R. The Run dialog box is displayed.
- 5. In the **Open** text box, enter regedit, and click **OK**. The **Registry Editor** window is displayed.
- 6. Modify the registry parameters. For a description of the parameters, refer to Table 4-6.

#### **Table 4-6 Registry Parameter Descriptions**

Registry Path	Parameter	Value
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\W32Time\Config	AnnounceFlags	5
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\W32Time\TimeProviders\NtpServer	Enabled	1

#### **Restarting the NTP Service**

- 7. In the **Open** text box in the **Run** dialog box, enter cmd, and click **OK**. The command line window is displayed.
- 8. Run the following command to stop the NTP service:
  - C:\>net stop w32time
- 9. Run the following command to start the NTP service:
  - C:\> net start w32time

10. Run the following command to verify that the NTP server is configured successfully:

C:\>w32tm /stripchart /computer:127.0.0.1

If the output time is displayed after the command is run, it indicates that the configuration is successful.

## 4.12 Configuring the SMTP Server

#### **Abstract**

The SMTP server receives alarm emails from the BMC.

The operations for configuring the SMTP server include:

- 1. Install the SMTP server: Provides the SMTP service for the BMC.
- 2. Configure the IP address and port number: After the same IP address and port number are configured on the Web page of the BMC, the alarm emails (if any) are sent to the default path C: \inetpub\mailroot\Drop on the SMTP server.



This procedure describes how to perform the operations on a PC with the Windows Server 2012 R2 operating system. The operations for other Windows Server operating systems are similar.

#### **Steps**

#### Installing the SMTP Server

- 1. Press Windows+R. The Run dialog box is displayed.
- 2. In the **Open** text box, enter <code>servermanager</code>, and click **OK**. The **Server Manager** window is displayed.
- 3. Click Add Roles and Features. The Add Roles and Features Wizard window is displayed.
- 4. Select Role-based or feature-based installation.
- 5. Click Next.
- 6. Select Select a server from the server pool, and then select the server from Server Pool.
- 7. Click **Next** until the **Features** step in **Add Roles and Features Wizard** is displayed.
- 8. Select SMTP Server.
- 9. Click Install.

#### **Configuring the IP Address and Port Number**

- 10. In Control Panel > System and Security > Administrative Tools, double-click Internet Information Services (IIS) 6.0 Manager.
- 11. Right-click **SMTP Virtual Server #1**, and select **Properties** from the shortcut menu. The **[SMTP Virtual Server #1] Properties** dialog box is displayed.

12. From the **IP address** list, select the corresponding IP address.



The selected IP address is that of the server selected in Step 6.

- 13. Switch to the **Delivery** tab.
- 14. Click **Outbound connections**. The **Outbound Connections** dialog box is displayed.
- 15. In the **TCP port** text box, enter 25.
- 16. Click **OK**.

## 4.13 Configuring SNMP Trap

#### **Abstract**

SNMP Trap parameters are used by the BMC to send alarms and notifications to a third-party NMS.



SNMP Trap parameters are provided by a third-party NMS.

#### **Steps**


- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **SNMP Settings**. The **SNMP Settings** page is displayed, see Figure 4-22.

#### Figure 4-22 SNMP Settings Page



3. Click **SNMP Trap Configurations**. The **SNMP Trap Configurations** page is displayed, see Figure 4-23.

Figure 4-23 SNMP Trap Configurations Page



- 4. Select Enable in the SNMP Trap policy area.
- 5. Select an alarm level from the **Alarm Sending Level** list.


Alarm levels include:

- Critical: Alarms of critical level are sent only.
- Major: Alarms of major and critical levels are sent.
- **Minor**: Alarms of minor, major, and critical levels are sent.
- Normal: Alarms of normal, minor, major, and critical levels are sent.
- 6. Select a mode from the Module Trap Mode list.

Modes include:

- Event OID Mode: indicates that alarms are triggered by event.
- Module OID Mode: indicates that alarms are triggered by module.
- 7. Click **Save** in the **SNMP Trap Setting** area.
- 8. Enter a community name in the **Trap Community** text box and confirm it in the **Confirm Trap Community** text box in the **SNMP Trap Community Name Setting** area.
- 9. Click Save in the SNMP Trap Community Name Setting area.
- 10. Return to the **SNMP Settings** page.
- 11. Click **SNMP Trap Destinations**. The **SNMP Trap Destinations** page is displayed.
- <sup>12</sup>. Click ▶. The **Trap Destination Configuration** page is displayed, see Figure 4-24.

**Figure 4-24 Trap Destination Configuration Page** 



13. Configure the parameters. For a description of the parameters, refer to Table 4-7.

**Table 4-7 Trap Destination Parameter Descriptions** 

Parameter	Description	Setting
SNMP Destination Address	IP address of the server that receives alarms.	Enter the IP address in the IPv4 or IPv6 format.
SNMP Trap Port	Server port that receives alarms.	Enter the port number, with a range of 1–65535.  If there is a default port number, provide it.
SNMP Protocol Version	SNMP protocol used for sending alarms.	Select a protocol version.
SNMP Trap User	User used for sending alarms.	When <b>SNMP Protocol Version</b> is set to <b>V3</b> , you must select a user with the SNMP permissions as the alarm sender.  For a description of the authentication protocol and private protocol, refer to "3.7.24 Creating a User".

14.(Optional) Click **send** in the **Send Trap test event** area. A test event is sent to the Trap destination.



If the information indicating "sent successfully" is displayed on the page, it indicates that the SNMP Trap function is normal.

15. Click Save.

# 4.14 Handling Network Port Alarms


#### **Abstract**

If the network port is not connected with a network cable, a net port alarm is reported, indicating "NetPort Down or Cable Disconnected". Network port alarms can be handled through the **Net-Port Alarm Configuration** function.

#### **Steps**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click Alarm Settings. The Alarm Settings page is displayed.
- 3. Click **NetPort Alarm Configuration**. The **NetPort Alarm Configuration** page is displayed, see Figure 4-25.

Figure 4-25 NetPort Alarm Configuration Page



- 4. Deselect **NetPort** to disable network port alarms.
- 5. Click Save.

# 4.15 Exporting BMC Logs

You can export BMC logs through the following ways:

- Export BMC logs in one click. For details refer to "4.15.1 Exporting Data in One Click".
- Export BMC logs by category. For details, refer to "4.15.2 Exporting BMC Logs by Category".
- Export logs through the SSH command line (SSH). For details, refer to "4.15.3 Exporting Logs Through the Command Line (SSH)".
- Export logs through the command line (serial port). For details, refer to "4.15.4 Exporting Logs Through the Command Line (Serial Port)".

# 4.15.1 Exporting Data in One Click

#### **Abstract**

By exporting data in one click, you can export the log data of the BMC to the local PC. The exported log file name is <code>bmcinfo\_SN.tar.gz</code>, which is stored in the default download directory of the browser.




If the SN of the server cannot be queried, the name of the exported log file is <code>bmcinfo\_UnknownPro-ductSN.tar.gz</code>.

# **Steps**

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- 2. Click Expert Data. The Download Expert Data page is displayed, see Figure 4-26.

Figure 4-26 Download Expert Data Page



3. Click **Download Data**. The download progress is displayed, see Figure 4-27.

Figure 4-27 Download Progress Page





Figure 4-28 shows the downloaded page.

Figure 4-28 Download Completed Page



# 4.15.2 Exporting BMC Logs by Category

### **Abstract**

**BMC** logs include:

- Login log: records user login and logout information.
- Operation log: records users' operations.
- System log: records log and historical alarm information generated during the operation of the server.
- Event log: records events generated during the operation of the server.




The operations for exporting logs of the above categories are similar. This procedure describes how to export operation logs.

### **Steps**

From the menu bar in the left pane, select Alarms & Logs > Operation Log. The Operation Log page is displayed, see Figure 4-29.

Figure 4-29 Operation Log Page



#### 2. Perform the following operations as required.

То	Do
Filter logs by date	Click in the <b>Filter by Date</b> area and set the start date and end date for querying operation logs.
Filter logs by keyword	<ul><li>a. In the Filter by Keyword text box, enter a keyword.</li><li>b. Press Enter. The results filtered by the keyword are displayed on the page.</li></ul>
Save logs to the local PC	Click <b>Download Operation Logs</b> and save the operation logs to the local PC.

# 4.15.3 Exporting Logs Through the Command Line (SSH)

### **Abstract**

If the BMC Web portal is faulty, you can connect to the BMC remotely through SSH and export logs in one click in command line mode.

#### **Steps**

- 1. Connect to the BMC by using the SSH tool.
- 2. Run the following commands in the command line to export logs:
  - # cd /etc/init.d/
  - # ./expert data.sh



- 3. Download the log file to the local PC by using the SFTP function.
- 4. Run the following commands in the command line to delete the BMC log file:
  - # cd /var/video
  - #rm bmcinfo.tar.gz

# 4.15.4 Exporting Logs Through the Command Line (Serial Port)

#### **Abstract**

If the network is abnormal and cannot be connected to the BMC, you can export logs through the serial port.

#### **Steps**

- 1. Connect the serial port of the BMC by using a DB9 serial port cable.
- 2. Press and hold the UID indicator on the server panel for eight seconds until the indicator flashes blue.
- 3. Use a serial port tool to connect to the serial port of the BMC.
- 4. After the connection is established, log in to the serial port with the account and password.
- 5. Run the following commands in the command line to export logs:
  - # cd /etc/init.d/
  - # ./expert\_data.sh



After the logs are exported, they are stored in the /var/video/bmcinfo.tar.gz directory.

- 6. Run the following command to back up the log file to the /mnt/nandflash0/ directory:
  - # cp /var/video/bmcinfo.tar.gz /mnt/nandflash0/



You can download log files to the local PC by using the SFTP function after the network is restored.

# 4.16 Upgrading the BMC Version

#### **Abstract**

To upgrade the firmware version of the BMC, you can load the version file online for firmware upgrade.



- After the BMC firmware is upgraded, the BMC is reset automatically.
- During the upgrade process, in case of any upgrade failure, you must upgrade the version again.

#### **Prerequisite**

The version upgrade file for the BMC is obtained.




The firmware upgrade files can be downloaded on the **Software Download** page on the Web portal ( <a href="https://vantageo.com">https://vantageo.com</a>) of the servers and storage products.

## **Steps**

- From the menu bar in the left pane, select Maintenance. The Maintenance page is displayed.
- 2. Click Firmware Update. The Other Firmware Update page is displayed, see Figure 4-30.

Figure 4-30 Other Firmware Update Page



In the Version Upgrade area, click version file.

In the displayed dialog box, select a BMC version file.



Only one version file can be selected at a time. When the firmware version is updated, the firmware type is automatically matched.

4. Click **Start firmware update**. The firmware upgrade progress is displayed below.



During the version upgrade process, it is not allowed to switch to another page. Otherwise, the version upgrade process is interrupted.



The firmware version number generated after upgrade is displayed in the **Master BMC Ver** column, and the version number originally displayed in the **Master BMC Ver** column is displayed in the **Slave BMC Ver** column.

#### **Related Tasks**

If the switchover between the active and standby BMC versions is required, click **switch** in the **BMC Version Information**.

# 4.17 Restoring Factory Defaults

#### **Abstract**

By restoring factory defaults, you can restore the server configuration items (for example, the network, user, SNMP configuration and startup mode) to factory defaults.



Do not perform any operation during restoration. After factory defaults are restored, the server is restarted.

#### **Steps**

- 1. From the menu bar in the left pane, select **Maintenance**. The **Maintenance** page is displayed.
- Click Restore Factory Defaults. The Restore Factory Defaults page is displayed, see Figure 4-31.

Figure 4-31 Restore Factory Defaults Page



3. Click Restore Factory Defaults.

# 4.18 Backing Up BMC Configurations

#### **Abstract**

Before replacing the mainboard of a server, you must export the BMC configurations. After the mainboard is replaced, you can import the BMC configurations.



Only product serial numbers can be exported in this version.

# **Steps**

- 1. From the menu bar in the left pane of the BMC Web portal, select **Maintenance**. The **Maintenance** page is displayed.
- Click Backup Configuration. The Backup Configuration page is displayed, see Figure 4-32.

Figure 4-32 Backup Configuration Page



3. Perform the following operations as required.

То	Do
Export configurations	<ul><li>a. Click Export Configuration. The Export Configuration page is displayed.</li><li>b. Click Download Configuration.</li></ul>
Import configurations	<ul> <li>a. Click Import Configuration. The Import Configuration page is displayed.</li> <li>b. Click Click Upload Configuration.</li> </ul>

# 4.19 Identifying a Liquid-Cooled Server

#### **Abstract**

A liquid-cooled server differs from a non-liquid-cooled server in that the former has a leakage ( **LEAKAGE**) sensor.

# **Steps**

- 1. From the menu bar in the left pane, select **Sensor**. The **Sensor Reading** page is displayed.
- 2. In the **Discrete Sensor States** area, check whether the **LEAKAGE** sensor exists, as shown in Figure 4-33.

Figure 4-33 Checking the LEAKAGE Sensor

Sensor Name	State
↔ CPU_STATUS_01	Processor Presence Detected
↔ CPU_STATUS_02	Processor Presence Detected
<b>⊗</b> Critical_INT	
■ EVENT_LOG	
♣ FAN_STATUS_01	Device Inserted / Device Present
♣ FAN_STATUS_02	Device Inserted / Device Present
♣ FAN_STATUS_03	Device Inserted / Device Present
♣ FAN_STATUS_04	Device Inserted / Device Present
⊟ HDD_STATUS_00	Drive Presence
⊟ HDD_STATUS_01	Drive Presence
⊟ HDD_STATUS_02	Drive Presence
⊟ HDD_STATUS_03	Drive Presence
☐ HDD_STATUS_04	Drive Presence
☐ HDD_STATUS_05	Drive Presence
⊟ HDD_STATUS_06	Drive Presence
☐ HDD_STATUS_07	Drive Presence
☐ HDD_STATUS_08	Drive Presence
⊟ HDD_STATUS_09	Drive Presence
A HDD_STATUS_10	Drive Presence
☐ HDD_STATUS_11	Drive Presence
☐ HDD_STATUS_50	Drive Presence
☐ HDD_STATUS_51	Drive Presence
INTRUSION	Status Normal
1 LEAKAGE	Transition to OK



If the **LEAKAGE** sensor exists, the server is a liquid-cooled server. The **State** column displays the state of the sensor.

# 4.20 Creating an SNMP User

#### **Abstract**


When configuring SNMP trap destinations, if SNMPv3 is used, you must select a user with the SNMP permissions as the alarm sender. This procedure describes how to create an SNMP user on the **Group Management** and **User Management** pages.

#### **Steps**

#### **Adding a User Group**

- 1. From the menu bar in the left pane, select **Settings**. The **Settings** page is displayed.
- 2. Click **Group Management**. The **Group Management** page is displayed, as shown in Figure 4-34.

Figure 4-34 Group Management Page






A user group icon with a name on the right indicates an existing user group. A user group icon without a name is a placeholder for a new user group. To add a user group, click a user group icon without a name.

3. Click a user group icon without a name. The **Group Management Configuration** page is displayed, as shown in Figure 4-35.

**Figure 4-35 Group Management Configuration Page** 



4. Set the parameters. For a description of the parameters, refer to Table 4-8.

**Table 4-8 User Group Parameter Descriptions** 

Parameter	Description	Setting
Groupname	Name of the user group.	<ul> <li>Enter a user group name.</li> <li>The group name is a string composed of 4–16 letters, digits, "-", "_" or "@", which must start with a letter.</li> <li>Letters are case-sensitive.</li> </ul>
required privi- lege/optional privi- lege	Operation permissions of the users in the user group.	The permissions are divided into required permissions and optional permissions.  ■ Required permissions: Select at least one of the following permissions:  → configure  → operate  → view



Parameter	Description	Setting
		In most cases, the required permissions for each user group are as follows:  → Administrator: configure, operate, and view  → Operator: operate and view  → Viewer: view  ● Optional permissions: Select one of the following permissions as needed.  → KVM Access  → VMedia Access  → SNMP Access  In most cases, the optional permissions for each user group are as follows:  → Administrator: KVM Access, VMedia Access, and SNMP Access  → Operator: SNMP Access  → Viewer: not applicable
SNMP Access Level	SNMP access level.	Select an SNMP access level, including:  Read Write Read Only
SNMP Authentication Protocol	SNMP authentication protocol.	Select an SNMP authentication protocol, including:  NONE SHA MD5 SHA256 SHA384 SHA512
SNMP Privacy Protocol	SNMP encryption mode.	Select an SNMP encryption mode, including:  NONE  DES  AES  AES256  If SNMP Authentication Protocol is set to NONE, SNMP  Privacy Protocol can only be set to NONE. AES256 can be used together with only SHA256, SHA384, or SHA512.

5. Click **Save**.

# **Creating a User**

6. On the **Settings** page, click **User Management**. The **User Management** page is displayed, as shown in Figure 4-36.

Figure 4-36 User Management Page






A user icon with a name on the right indicates an existing user. A user icon without a name is a place-holder for a new user. To add a user, click a user icon without a name. The first user icon in the upper left corner is reserved by the system and no user creation or modification operation can be performed.

7. Click a user icon without a name. The **User Management Configuration** page is displayed, as shown in Figure 4-37.

**Figure 4-37 User Management Configuration Page** 



8. Set the parameters. For a description of the parameters, refer to Table 4-9.

**Table 4-9 User Parameter Descriptions** 

Parameter	Description	Setting
User ID	User ID.	Generated by the system automatically and cannot be configured.
Username	User name.	<ul> <li>Enter a username.</li> <li>The username is a string composed of 4–16 letters, digits, "-", "_" or "@", which must start with a letter.</li> <li>Letters are case-sensitive.</li> </ul>

Parameter	Description	Setting
		The username cannot be anonymous, root, admin, users, nobody, username, or sysadmin, and the username and password must not be the same.
Password Size	Length of the password to be entered in Password/Confirm Password.	Select a password length.
Password	User password.	<ul> <li>Enter the user password. It is allowed to enter letters, digits, and symbols. Letters are case-sensitive.</li> <li>The password must not contain spaces or tabs.</li> <li>If a strong password is enabled, the password must contain four types of characters (upper-case letters, lower-case letters, digits, and symbols).</li> </ul>
Confirm Password	Confirm the user password.	Enter the password for confirmation, which must be the same as <b>Password</b> .
Enable User Access	Whether to enable the user immediately.	The added user can take effect only after this option is selected.
Dependent user group	User group that the user belongs to.	Select a user group. For how to add a user group, refer to Adding a User Group. The user inherits the permissions of the user group that the user belongs to.
Email Format	Format of emails sent by the BMC to the user.	Select an email format:  • AMI-Format: The email title format is " Alert from (host address) ". The emails in this format display sensor information, for example, sensor types and descriptions.  • FixedSubject-Format: The emails in this format display messages in accordance with user settings. The user must specify the email subject and messages in advance.
Email ID	Email address of the user.	Enter an email address.
Existing SSH Key	Displays the SSH key uploaded by the user.	-
Upload SSH Key	Uploads a public SSH key to the server. The file size cannot exceed 4 KB.	Click and select a key file.

9. Click Save.

# **Chapter 5**

# Reference: Default Passwords

The default administrator username for logging in to the BMC of a server is sysadmin. The default administrator password depends on server models and BMC versions. For details, refer to Table 5-1.

#### **Table 5-1 Default Password Descriptions**

Server Model	BMC Version	Default Password
2230-RE	Versions earlier than V03.20.01.10	superuser
	V03.20.01.10 and later	Superuser@123



After logging in to the BMC by using the default password, you must change it immediately. It is recommended that you change the password to a strong password.

# **Chapter 6**

# **Reference: Accessing Documents**

#### **Abstract**

Documents are readily available at VANTAGEO



This procedure takes *VANTAGEO Server SNMP Interface Description* as an example, and other documents can be accessed by similar steps.


# **Prerequisite**

You have registered successfully at VANTAGEO

## **Steps**


- 1. In the address bar of your browser, enter https://vantageo.com and press Enter. The home page is displayed.
- 2. Click **Login** in the upper right corner. The **User Login** page is displayed, see Figure 6-1.

Figure 6-1 User Login Page




- 3. Enter the username, password, and verification code.
- 4. Click **Login** to log in the **VANTAGEO** website.
- 5. Select **Products** on the menu. The **Products** page is displayed, see Figure 6-2.

Figure 6-2 Products Page



6. On the server list of servers at the lower part of the page, click the server that the document to be accessed is about, for example 2230-RE, and the **2230-RE** page is displayed, see Figure 6-3.

Figure 6-3 2230-RE Page



- 7. In the **document** list, select **Interface Description**, and all the documents about interface description are display on the right side of the page.
- 8. Click **Download** to the right of **Vantageo Server SNMP Interface Description**, and download the document.



# **Figures**

Figure 1-1 BMC Hardware Interfaces	•••••	8
Figure 1-2 BMC Management Software Architecture	•••••	9
Figure 2-1 Position of the iSAC Management Network Port	•••••	. 15
Figure 2-2 Welcome Page		16
Figure 2-3 Security Alarm		17
Figure 2-4 Home Page		18
Figure 3-1 Welcome Page		20
Figure 3-2 Sensor Reading Page		24
Figure 3-3 Sensor Detail Page		25
Figure 3-4 System Inventory—Block Diagram		26
Figure 3-5 CPU1 Details Page		27
Figure 3-6 System Inventory—Table		27
Figure 3-7 FRU Page		28
Figure 3-8 Current Alarm Page		29
Figure 3-9 Audit Log Page		30
Figure 3-10 Operation Log Page		31
Figure 3-11 System Log Page		32
Figure 3-12 Event Log Page		33
Figure 3-13 Date & Time Page		35
Figure 3-14 Configure Date & Time Page		37
Figure 3-15 General LDAP Settings Page		39

Figure 3-16 Role Groups Page	41
Figure 3-17 General Active Directory Settings Page	43
Figure 3-18 Role Groups Page	44
Figure 3-19 KVM Mouse Settings Page	46
Figure 3-20 Remote Log Settings Page	47
Figure 3-21 Remote Log Destination Settings Page	47
Figure 3-22 Remote Log Policy Page	49
Figure 3-23 Log Policy Page	50
Figure 3-24 VMedia Instance Settings Page	51
Figure 3-25 Remote Session Page-KVM	52
Figure 3-26 Remote Session Page-VNC	53
Figure 3-27 Network IP Settings Page (Shared Network Port)	55
Figure 3-28 Network IP Settings Page (Management Network Port)	56
Figure 3-29 Network Bonding Configuration Page	59
Figure 3-30 DNS Configuration Page	60
Figure 3-31 Welcome Page	63
Figure 3-32 Hostname Setting Page	. 64
Figure 3-33 Sideband Interface (NC-SI) Page	65
Figure 3-34 Network Auto Settings Page	67
Figure 3-35 LLDP Configuration Page	68
Figure 3-36 RAID Management Page	. 69
Figure 3-37 SAS IT Management Page	. 71
Figure 3-38 Services Page	. 72
Figure 3-39 Service Configuration Page	73

Figure 3-40 SMTP Settings Page	76
Figure 3-41 Uploading the SSL Certificate	78
Figure 3-42 Welcome Page	78
Figure 3-43 Not Secure Connection Page	79
Figure 3-44 Firewall Policy Settings Page	79
Figure 3-45 Add IP Rule Page	81
Figure 3-46 Add New MAC Rule Page	83
Figure 3-47 Add New Port Rule Page	85
Figure 3-48 Group Management Page	86
Figure 3-49 Group Management Configuration Page	87
Figure 3-50 User Management Page	89
Figure 3-51 User Management Configuration Page	90
Figure 3-52 Video Trigger Settings Page	92
Figure 3-53 Boot Option Page	94
Figure 3-54 BIOS Setting Page	95
Figure 3-55 Account Login Settings Page	96
Figure 3-56 Two-factor Authentication Page	98
Figure 3-57 SNMP Configurations Page	99
Figure 3-58 SNMP Community Page	101
Figure 3-59 SNMP Trap Setting Page	101
Figure 3-60 Trap Destination Configuration Page	102
Figure 3-61 Asset Tag Page	103
Figure 3-62 Product Location Page	103
Figure 3-63 Monitor Information Page	104

Figure 3-64	Alarm Configuration Page	. 105
Figure 3-65	PSU Alarm Configuration Page	. 106
Figure 3-66	Disk Alarm Configuration Page	. 107
Figure 3-67	NetPort Alarm Configuration Page	. 107
Figure 3-68	Panel Uart Page	. 108
Figure 3-69	Cooling Mode Management Page	. 109
Figure 3-70	GPU Management Page	. 110
Figure 3-71	Power Restore Policy Page	. 111
Figure 3-72	VGS Output Config Page	. 112
Figure 3-73	Power On Delay Settings Page	. 112
Figure 3-74	Direct Harddisk Management Page	. 114
Figure 3-75	Remote Control Page	115
Figure 3-76	Remote KVM (HTML) Window	116
Figure 3-77	Remote KVM (JAVA) Window	119
Figure 3-78	Power Control Page	124
Figure 3-79	NIC Page	125
Figure 3-80	FC Page	126
Figure 3-81	Fan Information Page	127
Figure 3-82	Inlet Temperature Page	128
Figure 3-83	System Power Limit Page	129
Figure 3-84	System Power Statistics Page	130
Figure 3-85	Power Information Page	130
Figure 3-86	Power Mode Settings Page	131
Figure 3-87	KPI Overview Page	132

Figure 3-88 Static Data of Chassis KPIs	133
Figure 3-89 Static Data of CPU KPIs	134
Figure 3-90 Dynamic Data of CPU KPIs	134
Figure 3-91 Firmware Information Page	135
Figure 3-92 Restore Factory Defaults Page	135
Figure 3-93 System Administrator Page	136
Figure 3-94 Firmware Update Page	139
Figure 3-95 Download Expert Data Page	141
Figure 3-96 Download Progress Page	142
Figure 3-97 Download Completed Page	142
Figure 3-98 Backup Configuration Page	143
Figure 3-99 PCIe Topology Update Page	144
Figure 3-100 NMI Control Page	144
Figure 3-101 Screen Captured Page	145
Figure 3-102 Manual Screenshots Page	146
Figure 3-103 System post code Page	147
Figure 3-104 Host Log Page	147
Figure 4-1 PuTTY Configuration Dialog Box	149
Figure 4-2 Position of the Serial Port	151
Figure 4-3 Position of the UID Indicator	151
Figure 4-4 PuTTY Configuration Dialog Box	152
Figure 4-5 Position of the Shared Port	154
Figure 4-6 Network IP Settings Page	155
Figure 4-7 Overview Page	157

Figure 4-8 N	IIC Page	158
Figure 4-9 F	C Page	158
Figure 4-10	RAID Management Page	159
Figure 4-11	Create Virtual Device Page	161
Figure 4-12	VMedia Instance Settings Page	163
Figure 4-13	Remote Session Page	164
Figure 4-14	Boot Option Page	165
Figure 4-15	Remote Control Page	166
Figure 4-16	Remote KVM (HTML) Window	167
Figure 4-17	Remote KVM (JAVA) Window	168
Figure 4-18	Sensor Thresholds Page	170
Figure 4-19	Services Page	172
Figure 4-20	Service Sessions Page	173
Figure 4-21	Service Configuration Page	174
Figure 4-22	SNMP Settings Page	178
Figure 4-23	SNMP Trap Configurations Page	179
Figure 4-24	Trap Destination Configuration Page	180
Figure 4-25	NetPort Alarm Configuration Page	181
Figure 4-26	Download Expert Data Page	182
Figure 4-27	Download Progress Page	183
Figure 4-28	Download Completed Page	184
Figure 4-29	Operation Log Page	185
Figure 4-30	Other Firmware Update Page	188
1Figure 4-31	Restore Factory Defaults Page	189

Figure 4-32 Backup Configuration Page	190
Figure 4-33 Checking the LEAKAGE Sensor	191
Figure 4-34 Group Management Page	192
Figure 4-35 Group Management Configuration Page	192
Figure 4-36 User Management Page	194
Figure 4-37 User Management Configuration Page	195
Figure 6-1 User Login Page2	200
Figure 6-2 Products Page2	201
Figure 6-3 2230-RE Page2	203

# **Glossary**

#### A/D

- Analog to Digital

#### AC

- Alternating Current

#### **ACPI**

- Advanced Configuration and Power Interface

#### AD

- Active Directory

#### **AES**

- Advanced Encryption Standard

#### **API**

- Application Programming Interface

# **ASCII**

- American Standard Code for Information Interchange

# BBU

- Battery Backup Unit

# **BIOS**

- Basic Input/Output System

#### **BMC**

- Baseboard Management Controller

#### CA

- Certificate Authentication

# CD

- Compact Disk

#### **CLI**

- Command Line Interface

#### **CPU**

- Central Processing Unit

# **CRPS**

- Common Redundant Power Supplies

#### **DCMI**

- Data Center Manageability Interface

#### **DES**

- Data Encryption Standard

#### **DHCP**

- Dynamic Host Configuration Protocol

#### **DNS**

- Domain Name Server

#### DVD

- Digital Versatile Disc

# **EPLD**

- Erasable Programmable Logic Device

#### FC

- Fiber Channel

## **FQDN**

- Fully Qualified Domain Name

# FRU

- Field Replaceable Unit

#### **GPIO**

- General Purpose Input Output

# **GPU**

- Graphics Processing Unit

#### GUI

- Graphical User Interface

# **HBA**

- Host Bus Adapter

#### HD

- Hard disk

#### **HSSDC**

- High Speed Serial Data Connector

#### **HTML**

- HyperText Markup Language

# **HTTPS**

- Hypertext Transfer Protocol Secure

# **HVDC**

- High-Voltage Direct Current

#### 1/0

- Input/Output

#### ID

- Identification

## ΙE

- Internet Explorer

### ΙP

- Internet Protocol

#### **IPMI**

- Intelligent Platform Management Interface

#### IPv4

- Internet Protocol Version 4

#### IPv6

- Internet Protocol Version 6

#### ISO

- International Organization for Standardization

#### IT

- Information Technology

#### JRE

- Java Runtime Environment

#### **KVM**

- Keyboard, Video and Mouse

#### LAN

- Local Area Network

#### **LDAP**

- Lightweight Directory Access Protocol

#### **LLDP**

- Link Layer Discovery Protocol

# **LPC**

- Lower order Path Connection

## LSI

- Large Scale Integration

#### **LVDC**

- Low-Voltage Direct Current

#### **MAC**

- Media Access Control

#### MD5

- Message Digest 5 Algorithm

#### **NCSI**

- Network Controller Sideband Interface

#### **NIC**

- Network Interface Card

#### **NMI**

- Non-Maskable Interrupt

#### **NMS**

- Network Management System

#### **NTP**

- Network Time Protocol

# **NVMe**

- Non-Volatile Memory Express

#### os

- Operating System

#### PC

- Personal Computer

#### **PCH**

- Platform Controller Hub

## **PCle**

- Peripheral Component Interconnect Express

#### **PECI**

- Platform Environment Control Interface

#### **PSU**

- Power Supply Unit

#### **PWM**

- Pulse-Width Modulation

#### **PXE**

- Preboot eXecution Environment

#### **RAID**

- Redundant Array of Independent Disks

#### **RMCP**

- Remote Management Control Protocol

#### SAS

- Serial Attached SCSI

#### **SFTP**

- Secure File Transfer Protocol

#### **SGPIO**

- Serial GPIO

#### **SHA**

- Secure Hash Algorithm

#### **SMBUS**

- System Management BUS

# **SMTP**

- Simple Mail Transfer Protocol

## SN

- Serial Number

#### **SNMP**

- Simple Network Management Protocol

#### SOC

- System on Chip

#### **SSH**

- Secure Shell

#### **SSL**

- Secure Sockets Layer

# **TLS**

- Transport Layer Security

#### UID

- Unit Identification Light

#### USB

- Universal Serial Bus

#### **UTC**

- Universal Time Coordinated

# **VGA**

- Video Graphic Adapter

#### **VLAN**

- Virtual Local Area Network

#### **VNC**

- Virtual Network Computing

#### **VNC**

- Virtual Network Console

## VR

- Voltage Regulator

### **WWNN**

- World Wide Node Name

#### **WWPN**

- World Wide Port Name

# **iSAC**

- Integrated Server Administrator Controller